

10/00

Kundendienst/Service



* SERVICE MANUAL * TNC 407 / 415

Changes/Developments

We are constantly working on technical improvements of our products.

For this reason, details described in this manual may differ slightly from your control. In this case, please order a revised service manual from us.

Duplication

This manual is provided subject to the condition that no part of it shall be duplicated in any form without our prior consent.

Issue 10/00

valid for the software versions	TNC 407	= 243 07 .,	version 07
	TNC 415	= 243 05 ., 259 91 .,	version 10
	TNC 407	= 243 02 .,	version 01
	TNC 415	= 259 96 259 97	version 01)

Contents Service Manual TNC 407/415

How to use this Service Manual	1
Minor Error Messages	2
Major Error Messages and their Causes	3
Logic Unit LE 417/415	4
Connector Designation and Pin Layout	5
Board description	6
Grounding diagram	7
Power Supply	8
Keyboard Unit TE 400/410	9
Visual Display Unit BC 110/110B	10
Encoders	11
Handwheel HR 130/330	12
3D-Touch Probe Systems	13
Data Interfaces	14
External Data Transfer	15
Analog Outputs	16
PLC Inputs and Outputs	17
Test Units	18
Exchange instructions	19
Machine Parameters	20

Page 1

ıa	pie of Contents Pa	ge
1.	How to use this service manual	3
2.	Minor error messages	A
2:1	Causes of minor error messages	
3.	Major error messages and their causes	6
ı.	Logic unit LE 407/415	11
.1	Designation of the logic unit LE 407	11
.2	Designation of the logic unit LE 41 5	12
.3	Hardware components of the logic unit	13
5.	Connector designation and pin layout	14
.1	Connectors on the logic units	14
.2	Connectors on the PLC boards	21
i.3	Connectors on the keyboard units	24
5.4	Connectors on the visual display units	27
5.	Board description	29
' .	Grounding diagram	30
-		
3.	Power supply	32
.1	External power supply requirements	32
3.2	Power supply of the visual display units	34
3.3	Power supply of the NC-Part.	35
3.4	Checking the power supply	36
3.5	Measuring points on the boards	38
3.6	Power supply of the PLC-Part	40
3.7	Buffer battery	42
).	Keyboard unit TE 400/410	43
.1	Overview	43
.2	Checking the keyboard unit	44
10.	Visual display unit BC 1 10/110B	48
10.1	Overview	48
0.2	Checking the visual display unit	48
11.	Encoders	49
1.1	Error messages	49
1.2	Error causes.	49
11.3	Checking the encoders	49
12.	Handwheel HR 130/330	51
12.1	Overview	51
12.2	Checking the handwheel HR 130/330	51
12.3	Error messages	51

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 2

Kundendienst

13.	3D touch probe system	52
13.1	Overview	52
13.2	Error messages	53
14.	Data interfaces	54
14.1	Operating modes	54
14.2	Interface configuration and allocation of the operating modes	55
14.3	Connecting cables and adaptors for the RS 232C data interface	56
14.4	Machine parameters for the data interfaces	. 56
14.5	Error messages	59
15.	External data transfer	63
15.1	Data transfer menu	63
15.2	Overview of all files in the RAM	65
15.3	External data output	65
15.4	Downloading external data	
16.	Analog outputs	74
16.1	Specifications	74
	Checking the analog outputs.	
16.2	Switching over the position display.	
16.3		_
16.4	Feed adjustment	
16.5	Offset adjustment	77
17.	PLC inputs and outputs	
17.1	Specifications	79
17.2	Checking the PLC inputs and outputs	
17.3	Further diagnosis possibilities in the PLC mode	82.1
17.4	Output "Control Ready for Operation" and	
	Acknowledgement for test "Control Ready for Operation".	. 83
18.	Test units	86
18.1	Test load unit for the power supply assembly	
18.2	Test units for PLC inputs and outputs	86
18.3	Measuring adaptor	87
18.4	Encoder diagnostic set	88.1
19.	Exchange instructions.	89
19.1	General remarks.	89
19.2	Exchanging the logic unit	93
19.3	Exchanging the TNC 415 processor board	
19.4	Exchanging the TNC 41 5 CLP board	
19.5	Exchanging the PLC board and the graphics board of TNC 407/415	
19.5	Exchanging the TNC 407 processor board	101
19.0	Exchanging the rive 407 processor board	103
19. <i>1</i> 19.8	Exchanging the PLC I/O board PL 400	105
19.8	Exchanging the EPROMs.	107
20.	Machine parameters	108
		-

SERVICE MANUAL TNC 407/415

issue: Ø1.09.1995

Page 3

1. How to use this Service Manual

The service manual TNC 407/415 can be used to diagnose, locate and eliminate errors on machine tools controlled by TNC.

In order to correctly judge the problems in an NC-controlled machine tool, fundamental knowledge of the machine tool and its drives, as well as their interaction with the control and the measuring systems is required. Incorrect behaviour of the machine tool can also result from improper use of the control, NC-programming errors and incorrect or not properly optimized machine parameter.

For further information in this respect please refer to the

- .Documentation of the Machine Tool Manufacturer
- .Operating Manual (HEIDENHAIN)
- .Technical Manual (HEIDENHAIN).

The manual for the machine tool manufacturer is not enclosed with every control as is the operating manual. In general, it is only supplied to the machine tool manufacturer and is updated by HEIDENHAIN, Traunreut. Therefore, it is absolutely necessary to contact the machine tool manufacturer, if errors occur that are due to a machine parameter or to the interface of the control. Support will, however, also be provided by the service department of HEIDENHAIN, Traunreut. and HEIDENHAIN agencies. Telephone numbers, addresses and telex/fax numbers can be found on the back side of the cover page and on the back side of this service manual.

Paae 4

2. Minor Error Messages

The TNC 407/415 features a comprehensive integrated monitoring system to avoid input or operation errors, to locate errors and technical defects of the entire equipment (TNC, measuring system, machine tool, cables etc.). The monitoring system is a fixed component of the TNC hardware and software; it is always active when the control is switched on. If a technical defect or an operation error is detected, an error message in plain language is displayed on the screen.



To erase minor error messages, press

Further error messages are described in the

- -Operating Manual TNC 407/415
 - -Technical Manual

Documentation by the machine tool manufacturer

Operating Instructions FE 401 B.

ERROR MESSAGE	Section
AXIS DOUBLE PROGRAMMED	13.2
START POSITION INCORRECT	13.2
TOUCH POINT INACCESSIBLE	13.2
RANGE exceeded	13.2
BAUD RATE NOT POSSIBLE	14.5
OPERATION PARAMETERS ERASED	2.1
CYCL-PARAMETER INCORRECT	13.2
FAULTY RANGE DATA	13.2
DATA MEDIUM MISSING	14.5
DATA MEDIUMEMPIY	14.5
DATA MEDIUM WRITE-PROTECTED	14.5
ROTATION NOT PERMITTED	13.2
PLANE WRONGLY DEFINED	13.2
LIMIT SWITCH <axis></axis>	2.1
ERR: 001	14.5
ERR: 002	14.5
FRR: 003	14.5
ERR: 004	14.5
ERR: 010	14.5
ERR: 012	14.5
ERR: 013	14.5
ERR: 014	14.5
ERR: 100	14.5
FRR: 102	14.5
ERR: 103	14.5

ERROR MESSAGE	Section
ERR: 104	14.5
ERR: 105	14.5
ERR: 106	14.5
ERR: 107	14.5
ERR: 108	14.5
EMERGENCY STOP	17.3
EXT. IN-/OUTPUT NOT READY	14.5
WRONG OPERATING MODE	14.5
WRONG PROGRAM DATA	14.5
SCALING FACTOR NOT PERMITTED	13.2
ME: TAPE END	14.5
HANDWHE EL DEFECTIVE	12.3
HANDWHEEL ?	12.3
PLC PROGRAM NOT TRANSLATED	2.1
POSI <u>TIONING ERROR</u>	2.1
PROGRAM INCOMPLETE	14.5
EXCHANGE BUFFERBATTERY	8.7
INTERFACE: ALREADY ASSIGNED	14.5
MIRRORING NOT PERMITTED	13.2
RELAY EXT. DC VOLTAGE MISSING	17.3
POWER INTERRUPTED	2.1
EXCHANGE TOUCH PROBE BATTERY	13.2
STYLUS ALREADY IN CONTACT	13.2
PROBE SYSTEM NOT READY	13.2
TIME LIMIT EXCEEDED	13.2



2.1. Causes of Minor Error Messages

OPERATING PARAMETERS ERASED

With new and exchange controls, the machine parameters are always erased.

Software exchanged with different software versions.

- Defective buffer batteries, accumulator or capacitor

RAM error on the processor board

LIMIT SWITCH X+

The preset **software limit switch** has been reached during traverse with the directional keys.

- "Automatic" operating mode:

The calculated position of the current block is beyond the software limit switch range or beyond the additional limit (set with MOD function >AXIS-LIMIT<). The positioning is not performed.

Machine Parameters for the Software Limit Switches

	x+	Х-	Y+	Y-	z+	Z-
Default setting	910.0	920.0	910.1	920.1	910.2	920.2
Activation via PLC	911 .o	921 .0	911.1	921.1	911.2	921.2
Activation via PLC	912.0	922.0	912.1	922.1	912.2	922.2

	IV+	IV-	V +	V-
Default setting	910.3	920.3	910.4	920.4
Activation via PLC	911.3	921.3	911.4	921.4
Activation via PLC	912.3	922.3	912.4	922.4

POWER INTERRUPTED

After a reset signal of the power supply (e.g. line voltage drops) Important machine parameters may have been changed; e.g. MP210, MP410.3, MP730, MP3240.1. MP7210. MP7310

POSITIONING ERROR

- The servo lag monitor set in the machine parameters MP1410 or MP1710 has responded. (Check the run-in behaviour of the axis; readjust, if necessary)

PLC PROGRAM NOT TRANSLATED

- After editing, the PLC program must be compiled (translated) anew. Use the soft key >Compile< or switch off the control!

[&]quot;Manual" operating mode:



SERVICE MANUAL TNC 407/415

01.09.1995

Kundendienst Page 5.1

PLC: ERROR 00	Marker	2924	
to	to		set
PLC: ERROR 99	Marker	3023	

Instead of "PLC: ERROR 00 to 99" another dialog may be displayed with customized PLC programs For further information, please contact your machine tool manufacturer.

Kundendienst Page 6

3. Major Error Messages and their Causes

The integrated monitoring system distinguishes between minor and gross errors. Gross errors are characterized by a **blinking display (e.g.** malfunctions of the encoders, of the drives and data processing errors).

In the case of gross errors, the control opens the contact **Control Ready for Operation**. This causes an emergency stop of the machine tool.

By switching off the main switch or by pressing provided that the error cause has been eliminated.

, the "emergency stop" state can be reset,

Display (blinking)

rror Cause

PROCESSOR CHECK ERROR XY

- L = 0 CRC sum control data incorrect
 - 1 CRC sum machine parameter incorrect
 - 2 Check sum NC memory incorrect
 - 3 Test plane incomplete / will not run
 - 4 Crosstalk between data bits in the RAM
 - 5 Crosstalk between addresses in the RAM
 - 6 Stack overflow
 - **7** CRC sum PLC program ASCII
 - 8 CRC sum PLC program OP-code
 - 9 CRC sum test-section
 - A Software error
 - B Wrong interrupt (differentiation with register V0)
 - C Time slice overflow
 - D Command stack overflow control loop
 - E Wrong command main processor
 - F Wrong display mode main processor
 - G Wrong boot command
 - H Verify error with boot command "Load"
 - Wrong supplementary command with boot command "Test"
 - J Boot logon successful
 - K EPROM-comparison CLP
 - L Wrong command CLP processor
 - M Operating voltage beyond tolerance range
 - N No PLC texts in PLC chip
 - 0 Axis 4 and/or 5 paraxial with export version
 - P Inhibited software function activated (function
 - Q TNC 415 without CLP or geometry CPU
 - R PLC activates at least 2 commands from the Q-parameters (M2713) and zero shift (M2716).

= CPU number 1 = main processor

2 = geometry processor

3 = CLP processor

If the error message "PROCESSOR CHECK ERROR XY" (XY = code; see above) comes up repeatedly, send the **complete logic unit** to HEIDENHAIN for repair. Please indicate the **error message and the code.**

Xundendienst 28.10.2000

Pane 7

Display (blinking)	Error	Cause		
REMORESTER AND CONTROL OF SECURITION OF SECU				
ERROR IN PLC-PROGRAM XX		NC start		complement missing
		Rapid traverse		
		Directional key latch		
		Feed enable		
	1E	PLC positioning	X 1)	
	IF		Y 1)	
	1G		Z 1)	
	1H	" <i>-</i>	4 ¹⁾	
	11	Directional key	x +	
	1J		X-	_ " =
	1 K	<u> </u>	Y+	
	IL	II 🎫	Y-	
	1M	II <u>=</u>	z+	
	IN	_ " _	Z-	
	10	" _	4+	
	1P		4-	
	IQ	More than one of the (M03, M04. M05) are		
	24	Jog increment pos.	X+	
	2A 2B	" "	X-	
	2C	_	Λ- Υ+	
			Y-	и
	2D	!!		_ • _"_
	2E	= " 	Z+	<u> </u>
	2F	 "	Z-	_ " = 11
	2G	- " -	4+	" <u>"</u>
	2H	W.	4-	• " -
	21	- "	5+	= " =
	2K	ll se	5-	_
	2L			" =
	2M	Directional key	5+	- "
	2N		5-	
	2P	PLC positioning	5	
	50	Excessive nesting (to one another)	o man	y modules nested inside
	51		n attem	pt to acquire data from
		the STACK, although	it was	empty)
	52	STACK overflow (an a	attemp	t to load too much data
		onto the STACK)	•	
	53	Time-out (the permiss	sible p	rogram run-time has
		been exceeded by m		
		subprogram structure		
	54	CASE-arguments are		than the number of
		entries in the table.	. 95.	
	55	No access to error tex	kts / dia	alog texts.
	9	tivo with compatibility		

Notes:

1) Only active with compatibility mode TNC 355

programmed, although the Logic accumulator does not

contain a definite value)



Traunreut · @ (0.86.69) 31 - 0

Display (blinking) **Error Cause** ERROR IN PLC-PROGRAM X 7 Called label has not been defined No end-program condition found (the program does not contain an EM instruction, or it contains a JP instruction without a following LBL instruction) 9 Program is too long (RAM-overflow) (insufficient memory for the program code which is to be generated) xx = 10Assign with parenthesis (an =, S, SN, R, RN, or PSinstruction has been programmed, although arithmetic 11 parentheses are open) Excessive nesting of parentheses (more than 16 12 parentheses are open) Jump within a gating sequence (unconditional jump has been programmed, although the gating sequence was 13 not closed with an Assign.) "Close Parentheses" without "Open Parentheses" la "Close Parentheses" command was programmed, 14 although no parentheses were open) Label within parentheses (a LBL instruction has been 15 programmed, although parentheses are open) Label within a gating sequence (a LBL instruction has been programmed, although the previous gating was 16 not closed with an Assign.) Jump within parentheses (a jump instruction has been 17 programmed, although parentheses are open) Parentheses open at end of block (an EM instruction has been programmed, although parentheses are open) 18 Label defined twice 19 Word Assign missing (a Logic instruction has been programmed, although the previous Word-gating was not closed with an Assign) 20 Logic Assign missing (a Word instruction has been programmed, although the previous Logic-gating was not closed with an Assign) 21 Word accumulator not loaded (a Word Assign or gating has been programmed, although the Word accumulator does not contain a definite value) 22 Logic accumulator not loaded (a Logic Assign has been

 Ø1.Ø9.1995

 Kundendienst
 Page 7.2

Display (blinking)	Error Cause
ERROR IN PLC-PROGRAM X	23 Accumulators not loaded on "open parentheses" (an
(continued)	A[,AN[,O[,ON[or XON[command has been programmed, although neither the word nor the logic accumulator has been gated or loaded.)
	Incorrect type of the parentheses result (a different type has been calculated in the parentheses from that which was defined in the "open parentheses"
	command, i.e. logic instead of word or vice versa.) 25 Conditional jump with incorrect logic accumulator (a conditional jump has been programmed, although the logic accumulator does not contain a definite value.)
	26 Empty CASE-instruction
	27 "END-CASE" missing

Notes:



Kundendienst Page 8

Display (blinking)

Error Cause

GROSS POSITIONING ERROR <AXIS> YA

Position (Servo Lag) Monitoring

Operation with feed precontrol: position monitoring range exceeded (range determined in MP 1420.x)

Operation with servo lag: servo lag monitoring range exceeded (determined in MP 1720.x)

GROSS POSITIONING ERROR <AXIS> YB

Monitoring of the Analog Voltage Limit

The nominal voltage calculated by the control has reached its limit of \pm 10 V (only with feed precontrol).

GROSS POSITIONING ERROR <AXIS> YC

Movement Monitoring

The voltage difference calculated by the control has reached the limit programmed in the machine parameter MP 1140.x.

GROSS POSITIONING ERROR <AXIS> YD

Standstill Monitoring

The deviation from the nominal position of an axis in standstill has exceeded the value programmed in the machine parameter MP 1110.x.

GROSS POSITIONING ERROR <AXIS> YE

Monitoring of the Offset Voltage

The offset voltage limit of 100 mV has been reached during an automatic offset adjustment with MP 1220. (see section 16.5)

Y = CPU number

1 = main processor 2 = geometry processor

3 = CLP processor

Error Location

When the error message "GROSS POSITIONING ERROR" is displayed, the error may be located in any element of the closed loop.

e.g. Error in control (e.g. CLP board)

Excessive offset voltage at the servo amplifier Incorrect speed adjustment at the servo amplifier Monitoring function of servo amplifier has responded

(e.g. monitoring of current intensity)
Electrical defect at the servo amplifier
Mechanical error (bearing, spindle, guides)
Excessive mechanical forces on a drive



Display (blinking)	Error Cause
MEASURING SYSTEM <axis> DEFECTIVE YA</axis>	A = Signal amplitude error
MEASURING SYSTEM <axis> DEFECTIVE YB</axis>	B = Signal frequency error
MEASURING SYSTEM <axis> DEFECTIVE YC</axis>	C = Error with distance-coded scale
	Y = CPU number 1 = main processor 2 = geometry processor 3 = CLP processor
	Possible error causes: Encoder not connected Cable damaged Glass scale contaminated or damaged - Scanning head defective Encoder monitoring system defective
WRONG REFERENCE POINT	Wrong reference mark spacing entered with distance-coded linear encoders (counting error caused by the measuring system or the LOGIC UNIT)
TNC OPERATING TEMP.	Temoerature inside the LOGIC UNIT has exceeded +70" C
EMERGENCY STOP DEFECTIVE YX	YX = 1(1. Emergency-stop test 1) 2. Emergency-stop test 1. 3. Emergency-stop test
	Error during the test routine for the output "Control Ready for Operation" (see section 17.4)
EMERGENCY STOP PLO	This error message is only generated if the marker 2815 is set without additional marker (M2924M3023).
to PLC: ERROR 00 1) to PLC: ERROR 99 11	Marke 2924 r to and marker 2815 set Marke 3023 r

¹⁾ Instead of "PLC: ERROR 00 to 99" another dialog may be displayed with customized PLC programs. For further information, please contact your machine tool manufacturer.

Value of the second of the sec

Error Cause Display (blinking) CHECK SUM ERROR YX -NC 407: CRC-sum main processor EPROM CHIP 1/2 IΑ CRC-sum main processor EPROM CHIP 3/4 1B ID CRC-sum PLC chip Check sum calculation ΙX -NC 415A: YΑ CRC-sum main processor EPROM CHIP 1/2 YC CRC-sum main processor EPROM CHIP 3/4 ΥD CRC-sum PLC chip YΕ CRC-sum Gem chip CHIP 7 CRC-sum CLP boot chip ΥR Check sum calculation ΙX 'NC 415B, TNC 425: CRC-sum main processor EPROM CHIP 1/2 YΑ CRC-sum main processor EPROM CHIP 3/4 YΒ CRC-sum geometry processor EPROM CHIP 5/6 YC CRC-sum PLC chip ΥD YΕ CRC-sum Gem chip CHIP 7 CRC-sum CLP boot chip ΥR IX Check sum calculation Y = CPU number 1 = main processor 2 = geometry processor 3 = CLP processor

CRC = Cyclic Redundancy Check

If the error message "CHECK SUM ERROR YX" comes up repeatedly, send the **complete LOGIC UNIT** to HEIDENHAIN for repair. Please **indicate the check sum error.**



Page 11


4. Logic Unit LE 407 / 415

JOHANNES HEIDENHAIN GmbH


-i3292 Traunreut · 🕾 (08669) 31-0


4.1 Designation of the Logic Unit LE 407


Logic Unit LE 407 without PLC I/O board (PL 400)



PLC I/O board (PL 400)









Page 12


4.2.Designation of the Logic Unit LE 415

Logic Unit LE 415 **without** PLC I/O board (PL 400)



Option: PLC I/O board (PL 400)





Ssue: 01.09.1995 Page 13

4.3 Hardware Components of the Logic Unit

The logic unit consists of the following components:

Power supply
 Processor board
 PLC board
 PLC I/O board PL 400 (optional)
 PLC analog board PA 110 (optional)

Following the components used in the different logic units are listed:

4.3.1 Components Overview TNC 407 / 415

Board Overview

LE 407 A	256 113								
LE 407 A	255 444								
LE 4 07 A	261 092								
LE 407 A	264 430						Ī		
-									
LE 415/E	251 481								
LE 415/E	258 993								
LE 415/E	264 429								
Processor	Boards								
253 251 .		X	Х	X					
255 924				<u> </u>					X
256 235								Х	
261 073							Х	1	
265 219				ı		X			
			l					J	
PLC Graphi	cs Boards								
253 373				x					Х
265 218		хI	хI			Χ	X	Χ	
CLP Boards	S				ĺ		1		
253 248			Х	X	ļ			1	
265 218		X							
Power Sup	ply Boards								
236 484 08				Х					Х
236 484 09		X	Х			Χ	Х	Х	
236 484 10		Х	Χ	Χ		Χ	Χ	Х	Χ
PL 400 (opt	ianal\								
	lionai)	-							
252 855	iionai)	Χ	Χ	Χ		Χ	Χ	Χ	Χ
		X	Χ	Χ		Χ	Χ	Χ	Χ
PA 110 (op					[X	Х	Х	X
		X	X	X	[X	X	X	Х

Page 14






5. Connector Designation and Pin Layout

5.1 Connectors on the Logic Units

5.1.1 Connector Designation LE 407





Issue: 01.09.1995 Page 15


5.1.2 Connector Designation LE 415

D-83292 Traunreut · @ (08669) 31-0

ower Supply CLP Board Processor PLC and

Board

Graphics Board



CLP Board

XI = encoder 1 [~]

X2 = encoder 2 [~]

X3 = encoder 3 [~]

X4 == encoder 4 [~]

X5 = encoder 5 [JL]

encoder 6 [JL] X6 =

nominal value output 1, 2, 3, 4, 5. S X10 = ref. pulse inhibit

X12 = touch probe system

B **=**=

PLC and Graphics Board

signal ground

x41 = PLC output

X42 = PLC input

X43 = visual display unit (BC 110)

X44 = 24V supply for PLC

X45 = TNC operating panel (TE)

X46 = machine operating panel

X47 = PLC I/O board (PL) or

PLC analog board (PA)

Processor Board

X21 = data interface RS 232C

X22 = data interface RS 422

X23 = serial handwheel interface

Power **Supply**

X31 = 24V supply for LE

Page 16

5.1.3 Pin Layout: POWER SUPPLY TNC 407/415

X31 Power Supply

terminal block

Assignment	Pin No.
+ 24 V	1
0 V	2





5.1.4. Pin Layout: PROCESSOR BOARD TNC 407

X1, X2, X3, X4 Encoder Inputs 1, 2, 3, 4 X8 Nominal Value Outputs 1, 2, 3, 4, 5, S

Sinusoidal input

Flange socket with female insert (9-pin)

Signal Designation	Pin No.
0° +	1
0° -	2
90° +	5
90° -	6
RP+	7
RP -	8
+ 5V (UP)	3
0V (U _N)	4
internal shield	9
external shield = housing	housing

Flange socket with female insert (15-pin)

Signal Designation	Pin No.
analog output 1	1
analog output 2	3
analog output 3	5
analog output 4	7
analog output 5	4
analog output S-axis	8
0V analog output 1	9
0V analog output 2	11
0V analog output 3	13
0V analog output 4	14
0V analog output 5	6
0V analog output S-axis	15
external shield = housing	housing
do not assign	2, 10, 12

X5, X6 Encoder Inputs 5, 6

Square-wave input

Flange socket with female insert (12-pin)

Signal Designation	Pin No.
Ua1	5
-Ua1	6
Ua2	8
-Ua2	1
Ua0	3
-Ua0	4
UaS	does not exist
-UaS	7
+ 5V (sensor line) *	2
+ 5V (UP)	12
0V (sensor line) *	11
0V (U _N)	. 10
shield = housing	9 (via spring)

X12 Touch Probe System

Flange socket with female insert (7-pin)

Signal Designation	Pin No.
internal shield	1
ready for operation	3
start	4
+ 15V	5
+ 5V (UP)	6
-battery warning	7
OV (U _N)	8
trigger signal	9
- trigger signal	10
do not assign	2
do not assign	11 to 15

^{*} The sensor line is connected to the corresponding supply lines in the unit.

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995

Kundendienst Page 17

X21 Data Interface RS 232C

Flange socket with female insert (25-pin)

Signal Designation	Pin No.
shield	1
-RxD	2
-TxD	3
CTS	4
RTS	5
DTR	6
GND	7
DSR	20
external shield	housing
do not assian	8 to 19
	21 to 25

X22 Data Interface RS 422

Flange socket with female insert (15-pin)

Signal Designation	Pin No.
shield	1
RxD	2
CTS	3
TxD	4
RTS	5
DSR	6
DTR	7
GND	8
-RxD	9
-CTS	10
-TxD	11
-RTS	12
-DSR	13
-DTR	14
do not assign	15



X23 Serial Handwheel Interface

Flange socket with female insert (9-pin, D-Sub)

Pin No.	Assignment HR 130/330	Assignment HR 332
1, 3. 5	n.c.	n.c.
Λ	± 12V	+ 12V
۷	U V	V V
6	DTR	DTR
<u>a</u>	n.c.	n.c.
8	RXD	RXD
7	do not assign	TXD
housing	external shield = housing	external shield = housing

5.1.5. Pin Layout: CLP BOARD TNC 415

XI, X2, X3, X4, X5 Encoder Inputs 1 to 5 X10 Ref. Pulse Inhibit *

see section 5.1.4 XI, X2, X3, X4

X6 Encoder Input 6 see section 5.1.4 X5, X6

X8 Nominal Value Output 1, 2, 3, 4. 5. \$

see section 5.1.4 X8

XI2 **Touch Probe System see** section 5.1.4 X12

Signal Designation	Pin No.
shield	1
ref. pulse inhibit X1	2
ref. pulse inhibit X2	3
ref. pulse inhibit X3	4
ref. pulse inhibit X4	5
ref. pulse inhibit X5	6
ref. pulse inhibit X6	7
OV (PLC)	9
do not assign	8

Flange socket with female insert (15-pin)

^{*} no longer required

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 18

X21 Data Interface RS 232C

see section 5.1.4 X21

X23 Handwheel HR 130/330

see section 5.1.4 X23

X22 Data Interface RS 422

see section 5.1.4 X22

5.1.7 Pin Layout: PLC GRAPHICS BOARD TNC 407/415

X41 PLC Output

Flange socket with female insert (37-nin)

Pin No.	Assignment
1	00
2	01
3	02
4	03
5	04
6	05
7	06
8	07
9	08
10	09
11	010
12	011
13	012
14	013
15	014
16	015
17	016
18	017
19	018
20	019
21	020
22	021
23	022
24	023
25	0244)
26	0254)
27	0264)
28	0274)
29	0284)
30	0294)
31	0304)
32	do not assign
33	0V (PLC) ¹⁾
34	control ready for operat
35, 36, 37	24V can be switched o
	via EMERG.STOP (PLC)

X42 PLC Input

Flange socket with female insert (37-pin)

Pin No.	Assignment
1	10
2	11
3	12
4	I3: acknowledgement for test
	"Control Ready for Operation"
5	14
6	15
7	16
8	17
9	18
10	19
11	l10
12	l11
13	l12
14	l13
15	l14
16	l15
17	l16
18	l17
19	[18
20	119
21	120
22	121
23	122
24	123
25	24
26	125
27	126
28	127
29	128
30	129
31	130
32	l31
33, 34	do not assign
35, 36, 37	0V (PLC) ²⁾
housing	external shield

housing

external shield

¹⁾ Internal test potential for tests

²⁾ External power supply for the outputs that can be switched off. Connect preferably via connector X44, pin 1.

³⁾ External reference potential for the PLC supply. Connect preferably via X44, pin 3.

⁴⁾ Cannot be switched off via EMERGENCY STOP.

Issue: 01.09.1995

Paae 19

X43 Visual Display Unit (BC 1 10) Flange socket with female insert (15-pin)

Pin No.	Assignment
1, 8, 11	GND
2 to 6, 12, 13	do not assign
7	R
9	VSYNC
10	HSYNC
14	G
15	В

X 4 4 Power Supply for the PLC

Terminal block

Pin No.	Assignment
1	+ 24V can be switched off
	via EMERG.STOP
2	+ 24V cannot be switched
	off via EMERG.STOP
٦	ΛV

X45 TNC Operating Panel (TE)

Flange socket with female insert (37-pin)

Pin No.	Assignment	
1	RLO	
2	RL1	
3	RL2	
4	RL3	
5	RL4	,
6	RL5	
7	RL6	
8	RL7	
9	RL8	
10	RL9	
11	RL10	
12	RL11	
13	RL12	key matrix
14	RL13	
15	RL14	
16	RL15	
17	RL16	
18	RL17	
19	RL18	
20	SL0	
21	SL1	
22	SL2	
23	SL3	
24	SL4	
25	SL5	
26	SL6	
27	SL7	
28	RL19	
29	RL20	
30	do not assign	
31	RL21	
32	RL22	key matrix
33	RL23	
34	spindle override	
35	feed override (wiper)	
36	+ 5V override pot	
37	0V override pot	
housing	external shield	



Page 20 Kundendienst

X46 Machine Operating Panel Flange socket with female insert (37-pin)

DR. JOHANNES HEIDENHAIN GmbH

292 Traunreut · 🕾 (0.86.69) 31-0

Pin No. **Assignment** l128 I129 Ο2 О3 О5 0V (PLC)1) 0V (PLC)1) + 24V (PLC)2) + 24V (PLC)2)

X47 PLC I/O Board (PL) Flange socket with female insert (25-pin)

Pin No.	Assignment
1, 2, 3	0V
4	serial (N 2
5, 6, 17, 18	do not assign
7	-RESET
8	-WRITE EXTERN
9	WRITE EXTERN
10	-A5
11	-A3
12	-A1
13	shield
14, 15, 16	+ 12V
19	serial IN 1
20	EMERG.STOP
21	-serial out
22	serial out
23	-A4
24	-A2
25	-A0

¹⁾ PLC reference potential for the outputs 00 to 07


²⁾ PLC supply voltage routed via fuse for the inputs II 28 to II 52.

Page 21

Issue: Ø1.Ø9.1995 Kundendienst

5.2 Connectors on the PLC Boards

5.2.1 Connector Designation PLC I/O Board PL 400



Issue: 01.09.1995 Page 22

5.2.2 Pin Layout of the 1st and 2nd PLC I/O Board PL 400

X1

<u> </u>		
Pin No.	Assignment	
	1st PL 400	2nd PL 400
1	O32	O64
2	O33	O65
· 3	O34	O66
4	O35	O67
5	O36	O68
6	037	O69
7	O38	070
8	O39	071
9	O40	072
10	041	073
11	O42	074
12	do not	assign

X4

/X-T		
Pin No.	Assignment	1
	1st PL 400	2nd PL 400
1	I126	1254
2	174	1202
3	173	1201
4	172	1200
5	l71	1199
6	170	1198
7	169	l197
8	168	1196
9	167	1195
10	166	l194
11	165	l193
12	164	1192

X2

X2	T	
Pin No.	Assignment	
	1st PL 400	2nd PL 400
1	O43	O75
2	044	076
3	045	077
4	O46	078
5	047	079
6	048	O80
7	O49	O81
8	O50	O82
9	O51	O83
10	O52	O84
11	O53	O85
12	do not	assign

X5

ΛĐ		
Pin No.	Assignment 1st PL 400	2nd PL 400
1	186	1214
2	185	1213
3	184	1212
4	183	I211
5	182	1210
6	l81	1209
7	180	1208
8	179	1207
9	178	1206
10	177	1205
11	176	1204
12	175	1203

х3

<u> </u>		
Pin No.	Assignment 1st PL 400	2nd PL 400
1	O54	O86
2	O55	087
3	O56	O88
4	O57	O89
5	O58	O90
- 6	O59	091
7	O60	092
8	O61	O93
9	O62	094
10	Control Ready	for
	Operation	
11	do not assign	
12	+24V cannot be off via EMERG	

X6

A0		
Pin No.	Assignment	
	1st PL 400	2nd PL 400
1	198	1226
2	197	1225
3	196	1224
4	195	1223
5	194	1222
6	193	1221
7	192	1220
8	l91	l219
9	190	l218
10.	189	l217
11	I88	l216
12	187	1215

^{* +24}V must always be connected, even the outputs are not used.





Kundendienst Issue: 01.09.1995
Page 23

X7

Pin No.	Assignment	
	1st PL 400	2nd PL 400
1	1110	1238
2	1109	1237
3	1108	1236
4	l107	1235
5	I106	1234
6	I105	1233
7	I104	1232
8	1103	1231
9	l102	1230
10	I101	1229
11	1100	1228
12	199	1227

X10 Connection to LE or to 1st PL

Pin No.	Assignment
1, 2, 3	OV
4	serial IN 2
5, 6, 17, 18	do not assign
7	-RESET
8	-WRITE EXTERN
9	WRITE EXTERN
10	-A5
11	-A3
12	-A1
13	shield
14, 15	+12V
16	Board ID (PK)
19	serial IN 1
20	EMERG.STOP
21	-serial OUT
22	serial OUT
23	-A4
24	-A2
25	-A0

X 8

Pin No.	Assignment 1st PL 400	2nd PL 400
1	1122	1250
2	l121	1249
3	l120	1248
4	1119	1247
5	I118	1246
6	1117	1245
7	l116	1244
8	l115	1243
9	l1114	1242
10	1113	1241
11	l112	1240
12	l111	1239


X11 Connection of the 2nd PL

Pin No.	Assignment
1, 2, 3	ov
4, 5, 6	do not assign
14 to 18	do not assign
7	-RESET
8	-WRITE EXTERN
9	WRITE EXTERN
10	Ι-Δ5
11	-A3
12	-AI
13	shield
19	serial IN 2
20	EMERG.STOP
21	-serial OUT
22	serial OUT
23	-A4
24	-∆2
25	-A0

X9

7.5		
Pin No.	Assignment 1st PL 400	2nd PL 400
1	do not assign	
2	do not assign	
3	do not assign	
4	l125	1253
5	l124	1252
6	1123	1251

5.2.3 Connector Designation : PLC Analog Board PA 110



Issue: 01.09.1995
Kundendienst Page 23.2

5.2.4 Pin Layout: PLC Analog Board PA 110

X1 Connection to LE or PL

Pin No.	Assignment
1, 2, 3	ov
4	serial IN 2
5, 6, 17, 18	do not assign
7	-RESET
8	-WRITE EXTERN
9	WRITE EXTERN
10	-A5
11	-A3
12	-A1
	shield
14.15	+ 12V
16	board identification
19	serial IN 1
20	EMERG.STOP
21	-serial OUT
22	serial OUT
23	-A4
24	-A2
25	-A0

X2, X3, X4, X5 Analog Inputs ± 10V

Pin No.	Assignment	
1	power input (± 10V)	
3	shield	

X6 Power Supply

Pin No.	Assignment	
1	± 21\/	

X7, X8, X9, X10 Inputs of the Pt 100 Thermistor


Pin No.	Assig	nment	
1	l+	constant current for Pt	100
2	U+	measuring input	
3	U-	measuring input	
4	1-	constant current for Pt	100
5	shield		


INC 407/415 Issue: 01.09.1995

Page 24

5.3 Connectors on the Keyboard Units

5.3.1 Connector Designation: TE 400





5.3.2 Pin Layout: TE 400

X1 Connection of the Soft Keys of the VDU (BC)

Flange socket with female insert (9-pin)

Pin No.	Assignment
1	SL0
2	SL1
3	SL2
4	SL3
5	do not assign
6	RL15
7	RL14
- 8	RL13
9	RL12


X2 Connection to the Logic Unit (LE)


Flange socket with female insert (37-pin)

Pin No.	Assignment
1	RLO
2	RL1
3	RL2
4	RL3
5	RL4
6	RL5
7	RL6
8	RL7
9	RL8
10	RL9

11	RL10
12	RL11
13	RL12
14	RL13
15	RL14
16	RL15
17	RL16
18	RL17
19	RL18
20	SL0
21	SL1
22	SL2
23	SL3
24	SL4
25	SL5
26	SL6
27	SL7
28	RL19
29	RL20
30	do not assign
31	RL21
32	RL22
33	RL23
34	spindle override (wiper)
35	feed override (wiper)
36	+ 5V
37	0V -

5.3.3 Connector Designation: TE 410 (only customized version)





5.3.4 Pin Layout: TE 410

X1 Connection of the Soft Keys of the VDU (BC)

Flange socket with female insert (9-pin)

Pin No.	Assignment
1	SL0
2	SL1
3	SL2
4	SL3
5	do not assign
6	RL15
7	RL14
8	RL13
9	RL12

X2 Connection to the Logic Unit (LE)

Flange socket with female insert (37-pin)

Pin No.	Assignment
1	RLO
. 2	RL1
3	RL2
4	RL3
5	RL4
6	RL5
7	RL6
8	RL7
9	RL8
10	RL9

11	RL10
12	RL11
13	RL12
14	RL13
15	RL14
16	RL15
17	RL16
18	RL17
19	RL18
20	SL0
21	SL1
22	SL2
23	SL3
24	SL4
25	SL5
26	SL6
27	SL7
28	RL19
29	RL20
30	do not assign
31	RL21
32	RL22
- 33	RL23
34	spindle override (wiper)
35	
36	
37	ov .
35 36	feed override (wiper) + 5V

Issue: 01.09.1995 Page 26

X3 Connection to the Logic Unit (LE)

Flange socket with female insert (37-pin)

Pin No.	Assignment
1	l128 key non-functional
2	I129 coolant ON/OFF
3	I130 spindle OFF
4	I131 NC OFF
5	1132 NC ON
6_	I133 directional key X- (X+)
7	I134 directional key Y- (Z-)
8_	1135 directional key Z- (Y-)
9	I136 directional key Z+ (Y+)
10	1137 directional key Y+ (Z+)
11	1138 directional key X+ (X-)
12	1139 directional key VI+
13	I140 directional key VI-
14	I141 rapid traverse
15	I142 spindle ON
16	do not assign
17	do not assign
18	do not assign
19	I146 directional key V+
20	I147 directional key V-
21	I148 spindle scanning mode
22	do not assign
23	do not assign
24	do not assign
25	do not assign
26	do not assign
27	do not assign
28	do not assign
29	do not assign
30	do not assign
31	do not assign
32	do not assign
33	do not assign
34	do not assign
35	do not assign
36	+ 24V PLC
37	+ 24V PLC


() = version 02/04



5.4 Connectors on the Visual Display Units



5.4.1 Connector Designation: BC 110



5.4.2 Pin Layout: BC 110

XI Connection to the Logic Unit

Flange socket with female insert (15-pin)

Pin No.	Signal_
7	R analog
9	V SYNC
10	H SYNC
11	0 V
14	G analog
15	B analog

X3 Line Connection

Euro connector

X2 Connection of the Soft Keys to the Keyboard Unit

Flange socket with female insert (9-pin)

Pin No.	Signal
1	SL0
2	SL1
3	SL2
4	SL3
6	RL15
7	RL14
8	RL13
9	RL12

X4 DC Connection for Ventilator

Terminal block


Pin No.	Signal
1	+ 24v
2	o v

issue: 01.09.1995

Page 28

5.4.3 Connector Designation: BC 1 10 B





5.4.4 Pin Layout: BC 1 10 B

XI Connection to the Logic Unit see section 5.4.2

X2 Connection of the Soft Keys to the

Keyboard Unit see section 5.4.2

X3 Line Connection

Terminal block (3-pin) Assignment according to label

X4 Voltage Output for External Units

Terminal block (Z-pin)

Pin	Signal
+	6 V *
	ov

^{*} max. load 0.9 A

Issue: 01.09.1995



Page 29 Kundendienst

6. Board Description

Processor Board

Interface:

LE 407

Encoder inputs 3D Touch probe system Data interface RS 232C Data interface RS 422 Handwheel HR 130/330

Monitoring:

Encoder inputs xis positions ³rogram memory)ata processing Emergency-Stop

Storage:

Operating program (NC software) ³LC programs Machine parameters Compensation value lists IC programs (user programs)

LE 415

Processor Board

Interface:

Data interface RS 232C Data interface RS 422 Handwheel HR 130/330

Monitoring:

Emergency-Stop

Storage:

Operating program (NC software) PLC programs Machine parameters Compensation value tables NC programs (user programs)

CLP Board

Interface:

Encoder inputs Ref. pulse inhibit 3D Touch probe system

Monitoring:

Encoder inputs Axis positions Program memory Data processing **Emergency-Stop**

PLC Graphics Board:

Interface:

57 PLC inputs 31PLC outputs **VDU**


Kevboard unit Machine operating panel

PLCI/O board

Monitoring:

Temperature Voltages Buffer battery





lssue: Ø1 .09.1995 Page 32

8. Power Supply


8.1 External Power Supply Requirements

The voltages must correspond to the following definitions:

Unit		Power Supply	Voltage Range DC Average Value	Max. Current Consumption	Power Consumption
LE	NC	24 V (VDE 0551)	lower limit 20.4	LE 415: 1.5 A LE 407: 1.3 A	approx. 30 W
	PLC			1.8 A if half of the inputs/outputs are active simultaneously	approx. 6 W if approx. 1/3 of the inputs/ outputs are active simultaneously
PL 400		24 V (VDE 0550)	upper limit 31 V *	21 A if half of the inputs/outputs are active simultaneously	approx. 25 W if approx. 1/3 of the inputs/ outputs are active simultaneously

^{*} Voltages up to 36V - perm sible with t < 100 ms.

8.1 .1 Power Supply




The NC-part of the LE must not be connected to the control voltage of the machine tool. It requires its own external power supply generated separately according to the German Standard VDE 0551:

24 V DC voltage with a permissible AC component (ripple voltage) of 1.5 Vpp (recommended filtering capacitor 10 000 μ F/ 40 V-).

8.1.2 PLC Power Supply

The PLC-part (PLC inputs and outputs) of the LE and the PL 400 is operated with a control voltage of 24V (of the machine tool), generated according to VDE 0550 (German Standard).

Superimposed AC voltage components arising from a non-controlled three-phase bridge connection with a ripple factor of 5% (see German Standard DIN 40110/10.75, section 1.2) are permissible. Thus, the highest absolute value for the upper voltage limit is 32.6V; the smallest absolute value for the lower voltage limit is 18.5V.



The 0 V line of the PLC power supply must be connected to the central signal ground of the machine tool (ground line $0 \ge 6 \text{ mm}^2$).




D-83292 Traunreut · @ (08669) 31-0


Page 33

8.2 Power Supply of the Visual Display Units

Power Supply BC 110



Power Supply BC 1 10B



XI: Connection of the logic unit

X2: Connection of the keyboard unit (for soft keys)

X3: line connection

BC 110B			
110 V ~	220 V ~		220 V ~
85 to 132 V ~	170 to 264 V ~	2 V ~	170 to 264 V ~
T 2.0 A	T 2.0 A		F 3.15 A
49 to 61 Hz		Hz	
Power consum	ption 60 W		

X4: Connection of DC voltage **BC 110**

Designation	Assignment
1	+ 24 V
2	ΩV

X4: Voltage output for external units ** BC 110B

Designation	Assignment
+	ค\/*
	0 V

^{*} max. load 0.9 A

^{* *} auxiliary voltage for keyboard driver, if long cables are used

issue: 01.09.1995

Page 34

8.3 Power Supply of the NC Part

The power supply line for the NC is connected to the terminals of X31.

The different voltages for the LE are transformed from the voltage fed (+24V) in the POWER SUPPLY assembly. (see block diagram, sec. 8.3.1)

The input and output voltages are displayed by LEDs. The states of the individual voltages are only displayed approximately by the LEDs. The exact values must be measured, and the measured values must correspond to the following table:

output	Unom [V]	Umin [V]	UMAX [V]	INOM [V]
+ 5 V	+ 5.2	+ 5.18	+ 5.22	2.5
+ 12 V	+ 12	+ 11.4	+ 12.6	0.15
+ 15 V	+ 15	+ 14.4	+ 15.6	0.3
-15v	-15	14.4	15.6	0.15
U BATT	+ 4.5	+ 3.7		approx. 20 µA
+ 12 V BE 1)	+ 12.3	+ 12	+ 12.6	1.5
+ 5 V * 1 ²⁾	+ 5	+ 4.75	+ 5.25	0.3

^{1) + 12} V BE is not required for TNC 407/415

^{2) + 5} V * 1 is a potential-free voltage.




NOTE:


Always switch off the main switch before engaging or disengaging any connectors, The power supply unit does not function during free run (basic load is required).

Issue: 01.09.1995

Page 35

8.3.1 NC Power Supply for LE 407/415







With the current version the connector X2 is no longer required. The strands are directly soldered to the power supply board.

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995

Kundendienst Page 36

8.4 Checking the Power Supply (Power Supply Unit)

Two low-voltage fuses are located on the power supply assembly. The fuse F 2.5A protects the output voltage of +24V BE $^{1)}$, and the fuse F 4.0A protects the remaining voltages (see block diagram, section 8.3.1). If an error occurs in the power supply (all voltages are missing), first check the +24V at the supply line and then the low-voltage fuses.

By means of the test load unit, the power supply can be checked fast and easily. For this purpose the connectors to the power supply boards must be disconnected from the power supply and connected to the test load unit.

The different values can be measured at the sockets of the test load unit with a multimeter. The values and their tolerances can be seen from the table in section 8.3. If the measured values deviate distinctly from the values in the table, the power supply assembly is defective.

If no test load unit is available, the voltages can be measured at the measuring points on the processor board, the CLP board or the PLC graphics board. (Measuring points: see section 8.5)

1) The voltage of +24V BE is not required for the TNC 407/415, as the VDU has its own power supply,




NOTE:

Always switch off the main switch before engaging or disengaging any connectors The power supply unit does not function during free-run (basic load is required).




8.4.1 Measurement Setup with the Test Load Unit




Issue: 01.09.1995 Page 38

8.5 Measuring Points on the Boards

8.5.1 Processor Board TNC 415




8.5.2 CLP Board TNC 415



issue: Ø1.09.1995

Page39

8.5.3 Processor Board TNC 407



Issue: 01.09.1995

Kundendienst Page 40

8.6 Power Supply of the PLC-Part

The power supply line for the internal PLC is connected to the terminal block X44 (1=+24V can be switched off, 2=+24V cannot be switched off, 3=0V). The OV line as well as the +24V (can be switched off) line may also be connected via connector X41 or X42 (see PLC Connection Schematic, section 8.6.2).


The PLC supply voltages are protected by means of low-voltage fuses on the PLC graphics board

24V can be switched off low-voltage fuse F2.5 A 24V cannot be switched off low-voltage fuse F1 A


The power supply line for the PLC I/O board PL 400 is connected to the terminal blocks XI2 (0V), XI3 (+24V can be switched off) and the terminal strip X3/pin 12 (+24V cannot be switched off). See PLC Connection Schematic, section 8.6.2.

There is no fuse on the PLC I/O board (electronic power limiter)

8.5.1 Measuring Points on the PLC Graphics Board



8.6.2 Connection Schematic of the PLC Power Supply



The PLC outputs 00 to 023 are supplied via X44/pin 1 (24V can be switched off) and can be reset by an external emergency stop.

The PLC outputs 024 to 030 are supplied via X44/pin 2 (24V cannot be switched off) and **cannot** be reset by an external emergency stop.

However, all PLC outputs can be reset by an internal emergency stop (e.g. GROSS POSITIONING ERROR <AXIS> XY).

(The voltage at X44/pin 2 must be connected, as it is used for the internal power supply of the PLC board and the graphics board.)

Issue: 01.09.1995

Page 42

8.7 Buffer Battery

Exchange Buffer Battery

The buffer battery is the voltage source for the program memory, if the machine tool is switched off.


If the error message

EXCHANGE BUFFER BATTERY

appears, the batteries must be exchanged within one week.

The buffer batteries are located behind a screw fitting in the power supply of the LE 407/LE 415. To exchange, open the LE by undoing both snaps

In order to protect the program memory of the TNC 407, a capacitor (located on the processor board) is used in addition to the batteries. Thus, the line voltage may be switched off during battery exchange, Without the batteries the capacitor is capable of maintaining the memory contents for about one day. The TNC contains an additional accumulator so that without the batteries the memory contents remains stored for approx. two weeks.



3 AA-size batteries, leak-proof IEC designation "LR6"




NOTE:

The capacitor and the accumulator are only being charged when the TNC is switched on (charging time of the accumulator: approx. 24 hi.

Processor Board TNC 407

Processor Board TNC 415






Page 43

9. Keyboard Unit TE 400/4 10


9.1 Overview

TE 400




ld.No. 250 517 01

TE 410 (customized)




Id.No. 258 645 . . (.. = version)






Version 03




Version 03

(with protective frame)



Version 04

(with protective frame)



Issue: 01.09.1995



Kundendienst Page 44

9.2 Checking the Keyboard Unit

Example:

The key contacts can be measured with an ohmmeter at the flange socket X2 of the keyboard unit The measuring adaptor can also be used, if available (see section 18.31.

If e.g. is pressed at the TNC operating panel, $< 100 \,\mathrm{m}\Omega$ can be measured between pin 17 and pin 20 of the flange socket X2 at the TNC operating panel with the measuring adaptor (connections 17 and 20).

9.2.1 TNC Operating Panel (Key Matrix)

Key	Flange Socket X2 of Keyboard Unit		
	PIN 17		
	17	PIN 20	
#	17	21	
\$	18	20	
9/0	18	21	
\wedge	19	20	
&	19	21	
*	28	20	
	28	21	
	29	20	
	29	21	
$\overline{+}$	31	20	
	31	21	
	32	20	
11	17	22	

Key	Flange Socket X2 of Keyboard Unit		
	_ PIN	PIN	
Q	17	23	
W	18	22	
E	18	23	
R	19	22	
	19	23	
(Y)	28	22	
U	28	23	
	29	22	
0	29	23	
P	31	22	
Z	31	23	
RF	32	22	
CTEL	17	24	
A	17	25	

Key	Flange Socket X2 of Keyboard Unit		
	P!N	PIN	
S	18	24	
D	18	25	
F	19	24	
G	19	25	
H	28	24	
J	28	25	
K	29	24	
	29	25	
•	31	24	
	31	25	
	32	24	
SPACE	17	26	
\mathbb{Z}	17	27	
X	18	26	



DR.JOHANNES HEIDENHAIN GmbH

Issue: 01.09.1995 Page 45 Kundendienst

Key	Flange Socket X2 of Keyboard Unit		
	PIN	PIN 27	
C	18		
V	19	26	
B	19	27	
(N)	28	26	
M	28	27	
5	29	26	
	29	27	
?	31	26	
	31	27	
SPACE	32	26	
PGM NAME	8	24	
CL. PGM	7	24	
PGM CALL	6	24	
EXT	5	24	
	6	22	
MOD	2	27	

Key	X2 of K	Socket eyboard nit
	PIN	PIN
	1	26
	2	20
→	3	27
♦	5	26
(A)	1	27
	2	26
a	3	26
Ð	4	26
		·
	9	20
	9	21
	9	22
CHE GALLO	9	23
(مرا	8	23
CR_s	7	23
RND.	7	22
(T)	8	22
en en	6	23
% €	5	23

Key	Flange Socket X2 of Keyboard Unit		
	PIN	PIN	
TOUCH PROBE	4	20	
CYCL DEF	8	21	
CYCL CALL	7	21	
LBL SET	6	21	
LBL	5	21	
STOP	5 5	22	
TOOL DEF	88	20	
TOOL	7	20	
R ^L	66	20	
R	55	20	
,			
X	4	24	
7	3	24	
8	2	24	
9	1	24	
Y	4	23	

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995

Kundendienst Page 46

Key	Flange Socket X2 of Keyboard Unit		
	PIN	PIN	
Z	4	23	
1	3	22	
2	2	22	
3	1	22	
[V]	4	21	
0	2	21	
•	3	21	
† /_	1	21	

Key	Flange Socket X2 of Keyboard Unit		
	PIN	PIN	
V	9	24	
	9	25	
	3	25	
Q	3	20	
CE	5	25	
DEL	4	25	
P	4	27	
I	Б	27	

Key Flange_Socket X2 of Keyboard				
	PIN	nit PIN_		
NO ENT	2	25		
ТИЗ	1	25		
END	1	20		

f	8	25
•	6	25
СОТО	7	25
•	8	26
· ·	6	26

Checking the Potentiometers of the TNC Operating Panel

If an ohmmeter is connected to the pins, the following resistances can be measured (use a measuring adaptor, if available):

Potentiometer	Flange Socket X2 of		Measured Value	
	Keyboard Unit			
	PIN	PIN	Position	Position
			0	150
Feed Override Pot	36	35	9.7 k	4.7 k
	37	35	4.7 k	9.7 k
Spindle Override Pot	36	34	9.7 k	4.7 k
	37	34	4.7 k	9.7 k

If a measuring adaptor is available, connect this adaptor between the logic unit and the keyboard unit. Now the wiper voltages of the potentiometers can be measured at the above pins (values: approx. 0 to 4.95 V).

Issue: Ø1.Ø9.1995



Kundendienst Page 47

9.2.2 Machine Operating Panel

Key of Version		X2 of K	Socket eyboard
		∣ Uı	nit
01/03	02/04	PIN	PIN
IV+	IV+	12	36, 37
Z′- ↑	Y -1	8	36, 37
Y+ 7	Z+,	10	36, 37
V+)	(V+)	19	36, 37
X'+	X:	11	36, 37
(N)	ha	14	36, 37
[X′·]	X′+ →	6	36, 37
¥- ∠	Z- K	7	36, 37
Z +	Y +	9	36, 37
[IV-]	IV-	13	36, 37
V-)	V-	20	36, 37

Key	Flange Socket X2 of Keyboard Unit		
	PIN	PIN	
	3	36, 37	
	15	36, 37	
(<u></u>	21	36, 37	
74	1	36, 37	
H	2	36, 37	
NC 0	4	36, 37	
NC I	5	36, 37	

9.2.3 Screen Soft Keys

Key	X1 of K	Socket eyboard nit
	PIN	PIN
	8	1
	9	1
	6	2
SK1	7	2

Key	X1 of K	Socket eyboard nit
	PIN	PIN
SK2	8	2
SK3	9	2
SK4	6	3
SK5	7	3

Key	Flange Socket X1 of Keyboard Unit		
	PIN	PIN	
SK6	8	3	
SK7	9	3	
SK8	6	4	
	7	4	

Issue: 01.09.1995 Kundendienst


Page 48

10. Visual Display Unit BC 11 O/I 10B

10.1 Overview

BC 110 ld. No. 254 740 01


BC 110B Id.No. 260 520 01



Checking the Visual Display Unit 10.2.

ld.No. 260 520 01 **BC 110 B**

If the screen remains dark when the machine is switched on , first check the power supply (line voltage) of the VDU. If the voltage supply is functioning properly, a square highlighted field can be generated on the screen of the VDU (which must be switched on) by pressing the external test button on the back side of the unit.



If the VDU generates this highlighted field, the PLC graphics board in the logic unit is probably defective. If however, the VDU remains dark after the test button was pressed, the VDU is defective and must be exchanged.

Page 48.1


Issue: 01.09.1995

BC 1 10 B ld.No. 260 520 01

If the screen remains dark when the machine is switched on, first check the power supply (line voltage) of the VDU. The control signals of the VDU can only be checked by means of an oscilloscope.

The following diagrams were drawn while the VDU was connected. The colour signals R-analog, G-analog and B-analog may be shaped differently (depending on machine parameters and the current screen display). Pin layout see sections 5.1.6 and 5.4.

Diagrams



SERVICE MANUAL TNC 407/415


Issue: 01.09.1995

Kundendienst Page 48.2

B-Analog pin 15*

0.2V/DIV F

* If the colour signals are measured directly at the output of the logic unit, the amplitudes are approx. The twice as large.



5 ms/DIV

Issue: 01.09.1995

Kundendienst Page 49

11. Encoders

11.1 Error Messages

ENCODER <Axis> DEFECTIVE XY

Y = A: Signal amplitude too low

B: Frequency exceeded

C: Wrong reference mark spacing

x = CPU number 1 = Main processor

2 = Geometry processor 3 = CLP processor

11.2 Error Causes

Glass scale contaminated or defective Scanning head contaminated or defective Cable damaged

- Encoder input of the logic unit (LE) defective

11.3 Checking the Encoders

In order to determine whether the encoder or the encoder input of the logic unit is defective, the encoders can be switched at the logic unit For this purpose, the corresponding machine parameters must be altered as well.

Function		MP	Input	t Value
Allocation of the axes to the encoder inputs	X Y Z IV V	110.0 110.1 110.2 110.3 110.4	0 = 1 = 2 = 3 = 4 = 5 =	XI x2 x3 x4 x5 X6*

^{*} X6 may only be used for a machine tool axis, if no spindle orientation is required.

Proceeding if an error message is displayed

e.g. ENCODER X DEFECTIVE 3B

- Switch off main switch.

Switch encoder X-axis with e.g. encoder Y-axis at the logic unit. Switch on main switch.

If the error message POWER INTERRUPTED is generated, call the machine parameters with the code number 95148 and switch the entry values of the machine parameters 110.0 and 110.1.

Exit the machine parameters and switch on the machine as usual.

If the same error message POWER INTERRUPTED is generated again, the error is located in the encoder or in the extension cable. If the error message now says "Y" instead of "X", the encoder input of the logic unit is defective.

Kundendienst Page 50

Issue: 01.09.1995

11.3.1 Electrical Check of Encoders

In order go give a precise statement on the electrical function of an encoder, it must be measured with a phase angle measuring unit (PWM), an oscilloscope and an impedance tester. (see operating instructions Encoder Diagnostic Kit)


If no phase angle measuring unit is available, the electrical state of the cable, the lamp and the photocells of an encoder can be checked with an ohmmeter. The following resistances must be measured at the connector of the encoder:

Encoder connector housing against machine housing (external shield) R < 1 Ω Encoder connector housing against pin 9 (internal shield against external shield) R = ∞ - Encoder connector housing against pins 1 to 8 (external shield against signal lines) R = ∞ Pin 9 against pins 1 to 8 (internal shield signal lines) R = ∞

Pin 1 against pin 2	0"		
Pin 2 against pin 1	0"	(switch poles of ohmmeter)	
Pin 5 against pin 6	90"		
- Pin 6 against pin 5	90"	(switch poles of ohmmeter)	The measured values should
Pin 7 against pin 8	ref. pulse *		be approximately equal.
Pin 8 against pin 7	ref. pulse *	(switch poles of ohmmeter)	
- Pin 3 against pin 4 **	(approx. 5 - 30 Ω)		

^{*}If encoders with selectable reference marks are used, different resistance values are measured (or no resistance), depending on the type of activation.

Basic Circuit Diagram with Sinusoidal Signals



Encoders with square-wave output signals can only be tested with a phase angle measuring unit (PWM)

^{**}The encoder check (pin 3 against pin 4) can only be carried out, if the encoder light unit is a lamp. With encoders with an amplifier section, the light unit cannot be checked at all. With encoders with infrared diodes a resistance in the conducting direction can be measured between pin 3 (+) and pin 4 (-).

Page 51



HEIDENHAIN

DR JOHANNES HEIDENHAIN GmbH
D-i3292 Traunreut @ (0 86 69) 31-0

12. Handwheel HR 130/330

12.1 Overview


HR 130 HR 130.001

Id.No. 254 040 --Id.No. 249 371 -- HR 330


ld.No. 251 534 --

Cable Adaptor for HR 330

ld.No. 249 889 -



12.2 Checking the Handwheel HR 130/330



t = 4 ms (TNC 415) t = 12 ms (TNC 407) The serial handwheels HR 130 and HR 330 can only be tested with an oscilloscope. The controls signals(X23/pin 6 = DTR.pin 8 = RxD)must correspond to the diagram at the left.

The supply voltage for the handwheel is fed via the logic unit (X23 / pin 2 = OV, pin 4 = + 12V).

Paae **51.2**

12.3 Error Messages

HANDWHEEL?

Data transfer (cable) has been interrupted.

HANDWHEEL DEFECTIVE

The light unit in the electronic handwheel is not emitting enough light, with the result that the signals in the handwheel are too small. An error signal is sent over the serial interface of the handwheel.

HANDWHEEL NOT READY X

X = A: No manual handwheel connected

B: Identification code of the manual handwheel does not match MP7640

CY: Contamination, Y = axis identification (only for multi-axis handwheel)

D: Error during receipt of data

E: Incorrect BCC check sum received

F: Manual handwheel outputs "Wrong identification received"

G: Manual handwheel outputs 'Incorrect BBC check sum received"

H: Manual handwheel outputs "Transmission error"

Manual handwheel outputs "Wrong number of initialising parameter received"

J: Manual handwheel outputs "Wrong value of initialising parameter received"



HEIDENHAIN

DR._JOHANNES . HEIDENHAIN GmbH

D-83292 Traunreut · 1 (08669) 31-0


Page 52

13. 3D Touch Probe Systems


13.1 Overview

13.1.1 Touch Probe Systems with External APE

TS 111, Id. No. 237 400 -- with connecting cable




TS 511, Id. No. 237 402 — with infra-red transmission




APE 110, Id.No. 230 465 — for TS 111 **APE 510,** Id.No. 227 590 — for TS 511

APE 511, Id.No. 237 586 — for TS 511 and additional connection for a 2nd SE 510


SE 510, ld.No. 230 473 -






13.1.2 Touch Probe Systems with Integrated APE

TS **120**, ld.No. 243 614 -



Cable Adaptor for TS 120, Id.No. 244 891 -



Kundendienst Page 53

13.2 Error Messages

TOUCH POINT INACCESSIBLE

After the start of a probing function, the scanning point was not reached within the measuring range defined in the machine parameter MP6130.

EXCHANGE TOUCH PROBE BATTERY

The battery voltage of the touch probe system with infrared transmission is below the minimum value.

STYLUS ALREADY IN CONTACT

- The stylus was already deflected when the probing function was started.

PROBE SYSTEM NOT READY

The infrared transmission between the "Touch Probe" and the "Transmitter/Receiver Unit" is faulty (e.g. caused by contamination) or interrupted. The two windows of the touch probe system must be oriented to the transmitter/receiver unit. The battery is dead.

13.2.2 Error Messages during Digitizing of 3D-Contours

WRONG AXIS PROGRAMMED

The touch probe axis in the scanning cycle RANGE is not identical to the calibrated touch probe axis.

FAULTY RANGE DATA

- A MIN coordinate value in the scanning cycle RANGE is equal to or larger than the corresponding MAX coordinate value.
- One or more coordinates are beyond the limit switch range of the scanning cycle RANGE.
 A scanning cycle RANGE was already defined when the scanning cycles MEANDER or CONTOUR LINES were called.

MIRRORING NOT PERMITTED

ROTATION NOT PERMITTED

SCALING FACTOR NOT PERMITTED

Mirroring, rotation or scaling factor were active when the scanning cycles RANGE, MEANDER or CONTOUR LINES were called.

01.09.1995 Page **53.1**

RANGE EXCEEDED

The range has been exceeded during scanning, i.e. a part of the 3D-contour is outside the range.

CYCL-PARAMETER INCORRECT

The programmed travel or the distance between lines or points is negative or larger than 56 535 mm (only possible via Q-parameter programming)

TOUCH POINT INACCESSIBLE

The stylus was deflected before the range was reached during approach.

- In the cycle CONTOUR LINES, the stylus was not deflected within the probing range.

STYLUS ALREADY IN CONTACT

The stylus is not at rest, although it is not touching the contour,

PLANE WRONGLY DEFINED

One of the coordinates of the starting point in the cycle CONTOUR LINES is identical with the touch probe axis.

START POSITION INCORRECT

- The starting point coordinate that is identical to the starting probe axis, is beyond the range

AXIS DOUBLE PROGRAMMED

The same axis has been programmed for both starting point coordinates in the cycle CONTOUR LINES.

TIME LIMIT EXCEEDED

In the scanning cycle CONTOUR LINES the first point of the scanned line was not reached within the programmed time limit.

SERVICE MANUAL TNC 407/415

Issue: 01.09.19958

Kundendienst Page 54

14. Data Interfaces

14.1 Operating Modes

For data transfer the TNC 407/415 can be switched to the following 5 interface operating modes:



For connection of the HEIDENHAIN Magnetic Tape Unit **ME 101/102 or** other peripheral units (e.g. printer); data transfer in standard data format; data format (7 data bits, 1 stop bit, even parity) and Baud rate (2400 bd) adapted to the ME.



For connection of the HEIDENHAIN Floppy Disk Unit **FE 401** or other peripheral units (e.g. personal computer with HEIDENHAIN data transfer software). Data are transferred with a special protocol (blockwise transfer) for data security. Data format 17 data bits, 1 stop bit, even parity) and the transfer protocol are adapted to the FE 401. In the interface mode FE 2 the file names must be noted down for output of machine parameters, compensation value lists and PLC-programs, as the directory of the external data medium cannot be displayed by the TNC and the file name is needed again for data input.



If the floppy disk unit FE 401 is used as an external data medium, no letters are permitted in program names.

When using the FE 401 the Baud rate at the control must be set to 9600



For connection of the HEIDENHAIN Floppy Disk Unit **FE 4018** (or **FE 401,** software version 230 626 03 and later) or other peripheral units. Data are transferred with a special protocol (blockwise transfer) for data security. Data format (7 data bits, 1 stop bit, even parity) and the transfer protocol are adapted to the FE 401/B. The disk directory is automatically displayed by the TNC (ESC sequence).

All characters are permitted for program names.

The Baud rate set at the TNC must always match that of the FE 410/B.

Possible Baud rates are 2400, 4800, 9600, 19 200 and 38 400.



To adapt the transfer of data to external units in standard data format and for blockwise transfer. The interfaces for data transfer are adapted via machine parameters.

Any Baud rate may be selected.



Peripheral units for the EXT operating mode are:
Tape punching units and punched tape readers
Printers or matrix printers for graphic printouts
Mass storage media or programming stations for "Blockwise Transfer"
Programming stations and personal computers for external programming



The Baud rate set at the TNC must always match that of the peripheral unit. Possible Baud rates: 1 10 to 38 400.

Issue: 01.09.' 9958

Page 55

14.2 Interface Configuration and Allocation of the Operating Modes

addition to the main operating modes the TNC features auxiliary modes or MOD-functions which permit additional displays and settings.

After pressing MOD in the operating modes EDIT PROGRAM and TEST RUN the following functions can be selected via soft key:

RS 232 USER RS 422 PARA- SETUP METER	ND)
--------------------------------------	----	---

The MOD function for the settings of the data interfaces is selected with the soft key RS 232 /R 422 SETUP and displayed on the screen:

ELS (EB	PROGRAMM-EI	NSPEICHER	N/EDITI	EREN
SCHNIT	ISTELLE RS23	2 SCHNITT	STELLE	RS422
BETRIE	BSART: FE	BETRIES	SART: F	E 1
BAUD-RI	ATE .	BAUD-RA	ITE	
FE :	9688	FE :	9688	
EXT1 :	9688	EXT1:	9600	
EXT2:	9608	EXT2 :	9600	
ZUWEIS	nne:			
EINSPE	ICHERN RS232	PRINT	:	
PROGRA	MMLAUF RS232	PRINT-	EST : R	5232
PROGRA	MHTEST RS232	?		
0			Ī	END

Note:

With the machine parameter MP5000 interfaces can be disabled. If the entry value is 0, no interface is disabled.

On the right half of the screen the interface RS 232C (V.24) is configured, on the left half the interface RS 422C (V.II). On the left side (lower part of the screen) the operating modes PROGRAMMING AND EDITING, PROGRAM RUN/FULL SEQUENCE and TEST RUN can be allocated to either RS 232 or RS 422. (If the MOD function RS 232 /R 422 SETUP is called in the PLC editor or the machine parameter editor, the editor can be allocated to either RS 232 or RS 422.)

On the right side (lower part of the screen) the user can determine via PRINT and PRINT TEST whether outputs with FN 15 and digitized positions are to be output via one of the interfaces or into a file in the memory of the control:

RS 232 means:

Data are output via the data interface RS 232.

RS 422 means:

Data are output via the data interface RS 422.

- FILE means:

Data are filed in the TNC.

With the arrow keys



the desired settings







(operating mode, Baud rate and interface allocation) may be selected and set according to your requirements by pressing


Exit the MOD function RS 232/RS 422 SETUP by pressing the soft key END

Issue: 01.09.19958

Page 56

14.3 Connecting Cables and Adaptors for the RS 232C Interface

14.3.1 Wiring Diagram and Adaptor of the RS 232C Interface




The data lines and the control lines of the cable between the LE 407/415 and the RS 232C adaptor block (Id.No. 239 760 ..) are transposed. The pin layout at the connector X21 of the LE 407/415 corresponds that of a data circuit terminating equipment (DCE). Due to the transposed data lines and control lines in the cable between the LE 407/415 and the RS 232C adaptor the allocation at the RS 232C adaptor corresponds to a data terminal equipment (DTE). Thus, the external units may be connected to the RS 232C adaptor via the standard HEIDENHAIN data transfer cable (ld.No. 242 869 01).



The RS 232C data interface has different pin assignments at the logic unit X21 and at the RS 232C adaptor block.

| Issue: 01.09.19958 | Kundendienst | Page 57

14.3.2 Wiring Diagram and Adaptor of the RS 422 Data Interface



Advantage of the R\$ 422 data interface:

If a Baud rate of **38 400** has been selected with the RS 422 interface, data transfer over a cable length of 1 km is possible.



The pin assignment of the RS 422 is the same at the logic unit X22 and at the adaptor block RS 422

Issue: 01.09.19958 Page 58

Machine Parameters for the Data Interfaces 14.4

The detailed functions of the machine parameters are explained in the TNC Manual for Machine Tool Manufacturers and in the information on the data interface RS232C/V.24.

In the operating modes ME, FE1 and FE2, the interface parameters are fixed. In the operating modes **EXT1** and **EXT2**, the interface parameters may be determined via machine parameters

All machine parameters for the data interfaces are user parameters, i.e. they can be selected with the code number 123.

14.4.1 Machine Parameters for the Standard Interface (e.g. for ME 101, printer)

MP for EXT1	MP for EXT2	Entry Values	Function
5020.0	5020.1	168	7 data bits, transfer stop by DC3, parity bit (even parity), 1 stop bit
5030.0	5030.1	0	Standard data interface
5201 .0	5201 .1	3	Control character for end of program = ETX



The data format and the type of transfer stop must be set at the printer according to the values of MP5020.0 and MP5020.1.

14.4.2 Machine Parameters for Blockwise Transfer (e.g. for FE 401/B, personal computer with HEIDENHAIN data transfer software)

MP for EXT1	MP for EXT2	Entry Values	Function
5020.0	5020.1	168	7 data bits, transfer stop by DC3, parity bit (even
			parity), 1 stop bit
5030.0	5030.1	12)	Blockwise Transfer
5200.0	5201.1	2 ²⁾	Control character for program start = STX
5201 .O	5201 .1	3 ²⁾	Control character for end of program = ETX
5202.0	5202.1	72 ²⁾	1. ASCII character for data input = H ¹⁾ (e.g. H =
			NC program in HEIDENHAIN plain language)
5203.0	5203.1	69 ²⁾	2. ASCII character for data input = E
5204.0	5204.1	72 ²⁾	1. ASCII character for data output = H^{1} (e.g. H = NC
			program in HEIDENHAIN plain language)
5205.0	5205.1	65"	2. ASCII character for data output = A
5206.0	5206.1	12)	ASCII character for start of command block = SOH
5207.0	5207.1	23 ²⁾	ASCII character for end of command block = ETB
5208.0	5208.1	6 ²⁾	ASCII character for positive acknowledgement = ACK
5209.0	5209.1	212'	ASCII character for negative acknowledgement = NAK
5210.0	5210.1	42)	ASCII character for end of transfer = EOT

- 1) ASCII characters are only valid for the transfer of NC programs.
- 2) If these machine parameters are programmed with 0, the standard values apply.

14.5. Error Messages

14.5.1 Error Messages at the TNC in the ME-Mode

WRONG OPERATING MODE

- The wrong operating mode no operating mode was selected on the external data medium

WRONG PROGRAM DATA

Wrong program data have been detected during data transfer. The control attempted three times to read the data from the magnetic tape before interrupting the process.

DATA MEDIUM MISSING

No cassette has been inserted into the drive.

DATA MEDIUM EMPTY

No programs are stored on the data medium (cassette).

DATA MEDIUM WRITE-PROTECTED

The write-enable plug on the cassette is missing

PROGRAM INCOMPLETE

Data transfer was interrupted before the program was transferred completely.

EXT. INPUT/OUTPUT NOT READY

The DSR-signal is missing at the TNC. ME not connected

Defective or wrong transfer cable
 Wrong interface assignment

ME: TAPE END

The cassette is full. To continue data transfer, turn over or exchange the cassette.

Page 60

14.5.2 Error Messages at the ME

In the ME the electronics is tested, and the external operating conditions are checked. If an error is detected, the lamps of the operating mode display start blinking. In the following table the error types are listed:

0 LED off

* LED blinking

Indicator Lamp	Error Message
000 * 0000	Faulty data during transfer
00 * 0	No cassette inserted
00 **	Write-enable plug in cassette missing
O*OO 0 0 0 0	Wrong operating mode selected
O*O* 0000	Data of magnetic tape faulty
O**O 0000	Magnetic tape blank
*000 0000	
00 0000	
*0*0 0000	Errors in ME electronics
*0** 0000	
**00 0000	
**O* 0000	
*** 0 0 0 0	End of tape
O*** 0000	Peripheral unit not connected
***O 0000	Data transfer between TNC and ME/peripheral unit was interrupted with

14.5.3 Error Messages at the FE in the ME-Mode

In the ME-mode, errors are displayed by blinking indicator lamps (LEDs).

0 LED off

Kundendienst

• LED on

★ LED blinking

Indicator Lamp	Error Massage	
000● 0 * 00	Disk missing or error in the ME electronics	
000* 0*00	Disk cannot be formatted, as it is currently being used	
*00● *000	Disk missing or not formatted	
00 *000	Disk cannot be copied, as a read/write process is active	
• O*@ 0 0 0 0	External unit not ready or not connected	
*○●● 0000	Disk missing or not formatted	
* 00● 00●0	Disk missing or not formatted or no program available	
○● 0000	Program cannot be output, as a transfer is active via the TNC interface	
* OO*	Program cannot be output, as a transfer is active via the PRT interface	
○○*●	External unit not ready or not formatted	
00●● * 000	Disk missing or not formatted	
000● * 0●0	Disk missing or not formatted	
00●* *000	Program cannot be output, as a transfer is active via the TNC interface	
000 * *0●0	Program cannot be output, as a transfer is active via the PRT interface	
0●0● 00*0	External unit not ready or not connected	
O*O● OO●O	Disk missing or error in the ME electronics	
O*O* OO⊕O	Table of contents cannot be output, as a transfer is active via the PRT interface	
000 * 00●0	No interface coupling possible, as a transfer is active via the TNC interface	
○○● * 0 0 0 0	No interface coupling possible, as a transfer is active via the PRT interface	
OO * ● 0000	External unit not ready or not connected	

By pressing

the error messages can be cleared.

01.09.1995 Paae 62

14.5.4 Error Messages at the TNC in the FE-Mode

In this operating mode, the floppy disk unit outputs errors in the following format:

(SOH) ERR: (SP) (SP) (SP) [XXX] (ETB) (BCC)

XXX = error number

The following errors can be displayed on the screen:

Input/output errors:

ERR: 001 = wrong command code
ERR: 002 = illegal program name
ERR: 003 = faulty data transfer
ERR: 004 = program incomplete
ERR: 005 = receiving buffer overflow
ERR: 006 = function currently disabled
ERR: 007 = data-buffer overflow

Errors during program write or read:

ERR: 010 = program not on disk ERR: 011 = program erase-protected ERR: 012 = program is being written to ERR: 013 = program directory is full

ERR: 014 = disk is full ERR: 015 = text not found

ERR: 016 = program name already exists

ERR: 017 = disk access active

ERR: 018 = program currently being read

Disk / Drive / Controller Errors:

ERR: 100 = disk not initialized

ERR: 101 = sector number too large 1)

ERR: **102** = drive not ready $^{2)}$

ERR: 103 = disk is write-protected ERR: 104 = faulty data on disk ¹⁾

ERR: 105 = sector cannot be found 1)

ERR: 106 = check sum incorrect 1)

ERR: 107 = disk controller defective 3)

ERR: 108 = DMA defective 3)

ERR: 109 = disk exchanged during program loading

- These error messages indicate that the disk is defective; in most cases, they can only be eliminated by formatting the disk anew.
- 2) If this error message comes up while the disk is inserted, the drive is defective.
- 3) Hardware error



Page **62.1**

14.5.5 Error Messages during Data Transfer

TRANSFERRED VALUE ERRONEOUS X

JOHANNES HEIDENHAIN GmbH

3292 Traunreut · 🕾 (0 86 69) 31-0

x = A	faulty character frame
-------	------------------------

- В character overflow
- С character frame or character overflow
- D parity error
- character frame or parity error Ε
- character overflow or parity error
- G character frame or parity error
- H receiving-buffer overflow
- K
 - Incorrect ESC sequence (only in ME-mode)

TRANSFERRED DATA INCORRECT X

- x = Acharacter frame faulty
 - parity error
 - Μ control has received the character for "negative acknowledgement" (NAK) more than 3 times
 - control has sent the character for "negative acknowledgement" (NAK) more Ν than 3 times

BAUD RATE NOT POSSIBLE

If both data interfaces are activated simultaneously (RS 232 / RS 422), the baud rates of both interfaces must be the same.

INTERFACE ALREADY ASSIGNED

A data interface cannot be used for two operating modes simultaneously (e.g. DNC-mode and programming at the same time is not possible with one data interface).

EXT. IN-/OUTPUT NOT READY

DSR signal at the TNC missing Defective or wrong transfer cable Wrong interface assignment

PROGRAM INCOMPLETE

Data transfer was interrupted before the program was completely loaded

Issue: 01.09.1995 Page 63

15. External Data Transfer

15.1 Data Transfer Menu

In the operating mode EDITING files can be read in and from the TNC. Press at the VDU to activate this operating mode.



To activate the data transfer menu, press

in the operating mode EDITING.

PROGRAPPLALF INTZFOLSE	PRO	GRAHH	EDI	TIERE	N			
	-L							P
79116	. Н	1478		79319	9	. н	622	
79152	. H			800		Н	362	
79153	. н			COPYFK			Н 11	18
79182	. н			FKNI	ERE	. 1	H 1110	I
79211	. н	2598		LOCH		.H	116	
79228	. H	1898		NIERE		.H	892	
79221	. н	878		TNC35	55FK	(. H	944	
79222	. н	1718		700		- 1	342	
79223	. Н	148		PALE.	TTI	:	Р 6	92 \$
79224	. н	918		NULL		. D	482	
79225	Н	258			ERF	₹.₽	2	•
79226	: H	1710		15		. Α	644	Ε
79227	. H	836		WAS		.A	1084	
34 DRIETCEN) 225	792 8YTE FR	E1 .		-			·
PAGE	PAGE	TRANSFER	TRANSFER	TRANSFER			ENAME	•
n l	J.	100 -20	ති ති	තැත	SHOW		R-M	END
Û	₩			TNC - EXT	DIRECT	OKY		

The memory contents of the TNC is displayed on the left side of the screen, the memory contents of the external unit (if there is any) on the right side. (Only in the data interface mode FE1 is the memory contents of the external unit displayed automatically. With all other data interface modes the memory contents of the external unit can be loaded by means of a soft key.) The arrow keys of the TNC operating panel serve to select a program for data transfer,

The data transfer commands are displayed in the soft-key row.

Soft-key commands in the FE1 mode:


PAGE	PAGE	TRANSFER	TRANSFER	TRANSFER	SHOW ALL	RENAME	
1	1	TNC -> EXT	TNC → EXT	TNC → EXT		ABC XYZ	END
Up- wards page by page	Down- wards page by page	Transfer sleeted program f r o m t o	Transfer all programs from to	Transfer programs from to after confirmation		Rename selected program (only TNC)	Exit EXT function

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995


Page 64

Soft-key commands in the modes FE2, ME, EXT1, EXT2:



Interrupting the Data Transfer

Once data transfer has been started, it can be interrupted by pressing



If the data transfer is interrupted, the error message **PROGRAM INCOMPLETE** is generated.

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 65

15.2 Overview of All Files in RAM

File	File Extension	_	Selection via Code Number
NC programs HEIDENHAIN language	.H	Х	
NC programs ISO	,j	X	
Tool files	.T	X	
Pallet tables	.P	X	
Datum tables	.D	X	
Text files	.A	X	
Machine parameters	.MP		X
Compensation value list	.KOR		Х
PLC program	.PLC		X
Error messages 1. language	.ER1		X
Error messages English	.ERE		X
Dialogs 1. language	.DI1		X
Dialogs English	.DIE		X
Text files	.A		×

Additional information on the files and programs is provided by letters in the status field:


- E: The file/program has been selected in the PROGRAMMING mode.
- S: The file/program has been selected and activated in the TEST RUN mode.
- M: The file/program has been selected and activated in either PROGRAM RUN/ FULL SEQUENCE or in PROGRAM RUN/SINGLE BLOCK.
- P: The file/program is protected against erasing and editing.
- IN: The file/program was programmed in Inch.
- W:The file/program was not completely transferred to the external memory and thus is no longer available.

15.3 External Data Output

Preparations:

Connect the external data medium (ME, FE or other peripheral unit, e.g. personal computer with HEIDENHAIN data transfer software) to the TNC.

Prepare the external data medium for data transfer:



Select the operating mode, the Baud rate and the interface assignment (see sections 14.1 and 14.2) at the TNC.



The ME (Magnetic Tape Unit) is not very suitable as an external data medium, as only one file can be stored on one side of a cassette.

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 66

15.3.1 Output of Files with the Extensions .H, .I, .T*, .D, .P, .A to an External Data Medium

(Note down the file name of the ASCII file xxx.A in the interface mode FE2, as the TNC cannot display the directory of the external data medium.)


The TNC features several file types to facilitate searching and selecting files.

The different file types are distinguished by their names and their extensions.

The following six different file types can be selected via soft keys:

HEIDENHAIN plain language programs

SO programs	file name> .H
Tool files	file name> .T*
Datum tables	file name> .D
Pallet tables	file name> .P
Text files (ASCII files)	file name> .A




^{*} The tool file TOOL.T is automatically generated by the TNC and selected for machining a workpiece. This file cannot be edited, read out or downloaded.

Issue: 01.09.1995

Kundendienst Page 66.1

To output the file TOOL.T it needs to be copied into another tool table: it can be stored on the external data medium under the new file name

Copying TOOL.T to XXX.T



Output of the new file XXX.T: see section 15.3.1



Issue: 01.09.1995Page 67

15.3.2 Machine Parameter Output to an External Data Medium

(Note down the file name of the ASCII file xxx.A in the interface mode **FE2, as** the TNC cannot display the directory of the external data medium.)

Press Key	Function
	Switch TNC to operating mode EDITING (key on VDU)
MOD	Prepare TNC for input of code number
9 5 1 4 8 ENT	Enter code number, acknowledge with ENT
EXT	Activate data transfer menu
	Soft key >TRANSFER TNC → EXT< to transfer data
	Soft key >END< to end data transfer menu
END	TNC is in the operating mode EDITING

15.3.4 Output of the Compensation Value List for Multipoint Axis Error Compensation

(Note down the file name of the ASCII file xxx.A in the interface mode FE2, as the TNC cannot display the directory of the external data medium.)

Press Key	Function
	Switch TNC to operating mode EDITING
	(key on VDU)
MOD	Prepare TNC for input of code number
1 0 5 2 9 6 ENT	Enter code number, acknowledge with ENT
EXT	Activate data transfer menu
	Soft key >TRANSFER TNC →EXT< to transfer data
	Soft key >END< to end data transfer menu
END:	TNC is in the operating mode EDITING

Issue: 01.09.1995

Kundendienst Page 68

153.5 Output of PLC Program, Error Messages and Dialogs

The PLC comprises a file manager for all file types. The following file types are possible:

	File	Extension
File Contents	EPROM Files	RAM Files
PLC Program	.PCE	.PLC
Error Messages, first language	.EE1*	.ER1*
Error Messages, English	.EEE*	.ERE*
Dialogs of OEM cycles, first language	.DE1*	.DI1*
Dialogs of OEM cycles, English	.DEE*	.DIE*
ASCII files		.A*

* Notes:

The error messages, dialogs and ASCII files are output as ASCII files with the file extension .A. For this reason, the files must have different names when they are to be read out so that they are not overwritten on the external data medium. (If necessary, rename files using the soft key >RENAME<.)

Note down file name and extension


During data input the file extension .A must be replaced with the original extension.



Issue: 01.09.1995

Kundendienst Page 69

In general only the files in the RAM must be stored on an external data medium. (Note down the file name of the ASCII file xxx,A in the interface mode **FE2. as** the TNC cannot display the directory of the external data medium.)





Several programs with the extension .PLC may be stored in the RAM. The selected program is marked by an "S" in the status window. Note down the program name so that you can re-select it after the downloading process.

Issue: 01.09.1995




Kundendienst Page 70

15.4 Downloading External Data

Preparations:

Connect the external data medium (ME, FE or other peripheral unit) to the TNC. Prepare the external data medium for data transfer:



 Select the operating mode, the Baud rate and the interface assignment (see 14.1 and 14.2) at the TNC.

15.4.1 Downloading Files with the Extensions .H, .I, .T**, .D, .P, .A*


ress Key	Function
	Switch TNC to operating mode EDITING (key on VDU)
EXT	Activate data transfer menu
	Go to the directory of the external data medium
interface mode FE1	
——	Soft key >SHOW ALL< to display all file types
otherwise otherwise	Use arrow key at the VDU to switch the soft-ke row to the file type display
	Soft key >SHOW.x< to select requested file type
	Use arrow key at the VDU to switch the soft-key row back to the data transfer menu
	Soft key >SHOW ALL< or >SHOW EXT DIRECTORY< to display the directory of the ext data medium at the TNC
	If necessary: select file with arrow key
	Soft key >TRANSFER< for data transfer
	Download further files, if required
	Soft key >END< to end the data transfer menu
END	TNC is in the operating mode EDITING

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 70.1

- * In the interface modes FEZ, EXT1 and EXT2 the name of the ASCII file must be entered manually, as it cannot be displayed by the TNC.
- ** The file TOOL.T always contains the tool table that is read by the TNC. TOOL.T cannot be edited, read out or downloaded. In the TNC several files xxx.T may be stored. The tool table (xxx.T) the TNC is supposed to read must be copied into TOOL.T. I.e. after downloading the files xxx.T, the current tool table still needs to be copied into TOOL.T (see section 15.3.1).

Copying the file xxx.T into TOOL.T



D-652.92 Hadrified (⋅ 🗷 (0.80 0.9) 31-0 Issue: 01.09.1995

Page 71

15.4.2 Machine Parameter Input

Press Key	Function
	Switch TNC to operating mode EDITING (key on VDU)
MOD	Prepare TNC for parameter input
9 5 1 4 8 ENT	Enter code number. acknowledge with ENT
EXŢ	Activate data transfer menu
interface mode	Press arrow key to enter the directory of the external data medium
	If necessary: select desired MP file by pressing the arrow keys
otherwise O	Enter name of MP file (ASCII or numerical keys)
	Soft key >TRANSFER TNC ←EXT< for data input
	Soft key >END< to end data transfer menu
END	TNC is in the operating mode EDITING

Issue: 01.09.1995

Kundendienst Page 72

If the error message OPERATING PARAMETERS ERASED is displayed, reenter the machine parameters as follows:

Function Press Key Clear error message **OPERATING PARAMETERS ERASED** Activate data transfer menu interface mode FE1 If necessary: select desired machine parameter file by pressing the arrow keys Enter name of the MP file otherwise (ASCII or numerical keys) Soft key >TRANSFERTNC←EXT< to download data Soft key >END< to end data transfer menu Exit machine parameter mode Clear error message OPERATING PARAMETERS ERASED

Note:


With new software versions, new machine parameters may be available. If these machine parameters are not comprised in the machine parameter list when downloading, they are set to the value 0. The correct input values for these machine parameters must be entered subsequently.

Page 73

Kundendienst

D-83292 fraunreut · @ (0.86.69) 31-0 Issue: 01.09.1995

15.4.3 Machine Parameter Input for Multipoint Axis Error Compensation






Issue: 01.09.1995 Page 73.1

15.4.4 Downloading the PLC Program: Error Messages and Dialogs


The error messages and the dialogs are read in as ASCII files. They need then to be reconverted into the original file types (see section 15.3.5)



SERVICE MANUAL TNC 407/415 Issue: 01.09.1995

Page 73.2

Kundendienst Page 73.2



Page **74**

Issue: 01.09.1995

16. Analog Outputs

16.1 Specifications

6 outputs:	1, 2, 3, 4, 5, and S	Machine Parameters fo	r the Analog Outputs
		Analog Output	MP Entry Value
Load capacity:	R_i mint 5 $k\Omega$	X	120.0 0 = output 1
	C _i max ≤ 2 nF	Υ	120.1 1 = output 2
		Z	120.2 2 = output 3
Voltage range:	$U_a max = \pm 10V \pm 100 mV$	IV	120.3 β = output 4
	$U_a \min = 0V \pm 3 \text{ mV}$	V	120.4 5 = output 5
	TNC 407	TNC 415	
Resolution	14 bits = 16 384 steps	16 bits = 65 536 steps	
Smallest step	$\frac{10V}{16384} = 0.610mV$	$\frac{10V}{65536} = 0.153mV$	

16.2 Checking the Analog Outputs

Proportionally to the traversing speed, the control generates an analog voltage of **OV** (axis standstill) to **9V** (rapid traverse). The easiest way to determine this voltage is to connect the test adaptor directly to the logic unit or to the connecting terminals of the servo-amplifier and to measure with a multimeter.

If however, the axis does not move due to a defect, and you want to test whether the error is inside or outside the control, the following steps are recommended:

Switch off the main switch of the machine tool.

Connect the test adaptor to the connector X8 (nom. value output) of the LE and connect a multimeter to the test adaptor sockets for the defective axis If no test adaptor is available, connect a multimeter directly to the nominal value output of the servo-amplifier.

Switch on the main switch and the control voltage.

Switch the position display to LAG (servo lag) (see sec. 16.3).

Check or adjust the following machine parameters. (If you alter the machine parameters, note down the original values and enter them again after finishing the test.)

MP	Entry Value	Function	Original Value
1720	100 [mm]	Servo-lag monitoring EMERGENCY STOP	
1140	9.99 IVI	Movement monitoring	

Traverse the reference points that need to be traversed before those of the defective axis.

Turn the override potentiometer of the keyboard unit completely to the left and start reference point traverse for the defective axis.

Check the axis enable for the defective axis at the servo amplifier.

Check the screen display


- * (control ready for operation) must be switched on, the "F" of the feed display must be lit normally (if the display is inverse, the feed enable is missing), and the symbol for "Axis not in the Position Loop" (e.g. $\rightarrow \downarrow \leftarrow$) should not follow the position display.
- Turn the override potentiometer slowly to the right and turn it back left before the servo lag display reaches the limit of the position monitoring (MP1720).

Issue: 01.09.1995

Page 75

When the override potentiometer is turned to the right, the control outputs an analog voltage which is increased proportionally to the servo lag up to 10V max. The control is operating correctly if a voltage of $10V \pm 0.1V$ can be measured at the test adaptor with the multimeter. If no voltage can be measured, switch off the main switch, disconnect the nominal value line from the servo amplifier and test for short-circuit. If the nominal value line is in order, connect the connector X8 to the LE again (leave the nominal value line disconnected), switch on the main switch and repeat the measurement with reference mark traverse. If an analog voltage can be measured now, the control is operating correctly. If no voltage can be measured, the analog output of the LE is probably defective.

15.2.1 Checking the Analog Outputs: Measurement Setup



X8 Nominal Value Output 1, 2, 3, 4, 5, \$

Flange socket with female insert (15-pin)

Pin No.	Signal Designation
1	analog output 1
3	analog output 2
5	analog output 3
7	analog output 4
4	analog output 5
8	analog output S-axis
9	0V analog output 1

Pin No.	Signal Designation
11	0V analog output 2
13	0V analog output 3
14	0V analog output 4
6	0V analog output 5
15	0V analog output S-axis
housing	external shield = housing
2, 10, 12	do not assign

Issue: 01.09.1995 Page **76**

16.3 Switching Over the Position Display

Press Key	Function
	Switch TNC to operating mode MACHINE
MOD	Prepare TNC to be switched over to position display
ENT	Press ENT to switch to desired position display (DIST, ACTL, REF. LAG, NOML)
	Press soft key >END< to switch the TNC to the operating mode EDITING

16.4 Feed Adjustment

Check/adjust the machine parameters. (Note down the original values before changing.)

MP	Entry Value	Function	Original Value
1390	0	Feed precontrol ON in the automatic operating modes	
7290	0	Display step = 1 µm	

Switch the position display to LAG (display of servo lag).

Enter the following test program:

e.g. 1 LBL 1 $$2\times100$$ RO F29999 M (select a larger traverse range if possible) 3×0 R F M 4 CALL LBL 1 REP 10

Run the test program in the operating mode PROGRAM RUN/FULL SEQUENCE.

Adjust the feed at the servo amplifier (tachometer) until the servo lag display is approx. zero for positioning in both directions.

Repeat adjustment for all axes.

Reset the machine parameters and the position display to the original values.

Issue: 01.09.1995

Page 77

16.5 Offset Adjustment

16.5.1 Offset Adjustment with Code Number

The offset adjustment with code number only compensates the current offset. Subsequent offset modifications are not compensated.

Press Key	Function
	Switch TNC to operating mode EDITING
MOD	Prepare TNC for input of code number
7 5 3 6 8 ENT	Enter code number for offset adjustment and acknowledge with ENT


The offset values are displayed individually for each axis in converter increments

(TNC 407:

1 converter increment = 0.61 mV,

TNC 415:

1 converter increment = 0.153 mV)



16.52 Automatic Cyclic Offset Adjustment

In the machine parameter MP1220, the cycle time is determined [unit s] after which an offset is compensated by one converter increment. To switch off the automatic offset adjustment, enter the value 0 in the machine parameter MP1220.



NOTE:

If an offset voltage of 100 mV is reached with automatic offset adjustment, the control switches itself off, generating the error message "GROSS POSITIONING ERROR <Axis> < CPU Number> E".

Issue: 01.09.1995

Kundendienst Page 78

16.5.3 Offset Adjustment at the Servo-Amplifier

Check/adjust the following machine parameters. (Note down the original values before changing.)

MP	Entry Value	Function	Original Value
1080.0	Ø		
1080.1	Ø		
1080.2	Ø		
1080.3	0	Integral factor	
1220	0	Cycle time for automatic offset adjustment	
1390	0	Feed precontrol ON in the automatic operating modes	
1510.0	> = 1		
1510.1	> = 1		
1510.2	> = 1		
1510.3	> = 1	KV factor for feed precontrol	
7290	0	Display step = 1 pm	

Switch position display to LAG (display of servo lag) (see sec. 16.3).

Clear the offset memory with the code number 75368 (see sec. 16.5.1).

Adjust the offset at the servo-amplifier until the values of the individual axes are zero or oscillate symmetrically about zero.

- Reset the machine parameter values and the position display to their original values.

INC 407/415 Issue: 01.09.1995

Page 79

17. PLC Inputs and Outputs

17.1 Specifications

17.1.1 PLC Inputs at the Logic Unit

10 to 131 at X42 1128 to 1152 at X46

"0"-Signal

 $U_e = -20 \text{ V to } 3.2 \text{ V}$

 $l_e = 1.0 \text{ mA}$ with $U_e = 3.2 \text{ V}$

"I"-Signal

 $U_e = 13 \text{ v to } 30.2 \text{ v}$

 $l_e = 3.8 \text{ mA}$ to 8.9 mA

Pin layout:

see section 5.1.7

17.12 PLC Outputs at the Logic Unit

00 to 07 at X46

00 to 030 and "Control Ready for Operation" at X41

"1"-Signal

Uamin = UB - 3 V

la NOM = 0.1 A

Pin layout:

see section 5.1.7

17.1.3 PLC Inputs at the PL 400

164 to 1126

at x4 to x9

"0"-Signal

 $U_e = -20 \text{ V to } 4 \text{ V}$

 $l_e = 1.6 \text{ mA}$ with $l_e = 4 \text{ V}$

"1"-Signal

 $U_e = 16.5 \text{ V to } 30 \text{ V}$

 $l_e = 6.2 \text{ mA}$ to 12.6 mA

17.1.4 PLC Outputs at the PL 400

032 to 062 and "Control Ready for Operation" at X1 to X3

"I"-Signal

Uamin = UB - 3 V

la NOM = 1.2 A

Pin layout:

see section 5.2.2

Page 80

Issue: 01.09.1995

17.2 **Checking the PLC Inputs and Outputs**

Two test units are available to check the inputs and outputs of the PLC:

PLC Test Unit

for X41, X42 and X46

PL Test Adaptor

for the PL board

With the PLC Test Unit all inputs and outputs of a connector are displayed simultaneously and all voltages can be measured. If you use the PL Test Adaptor, only the inputs/outputs of one terminal strip of the PL board are displayed. In this case the voltages can be measured directly at the terminals.

17.2.1 PLC Inputs

Check the PLC inputs as follows:

Connect the test unit between LE and PLC or between LE and PL. Set the TNC as follows:

Press key	Function
	Switch TNC to operating mode EDITING (key on VDU)
MOD	Prepare TNC for code number input
8 0 7 6 6 7 ENT	Enter code number, acknowledge with ENT
	Soft key >TABLE< to display the tables
	Soft key >INPUT< to display the input table

Now the logic states of the inputs are displayed on the screen. The states of the screen display must correspond to those of the test unit. If there is a difference, measure the voltage level (see section 17.1) of this input at the test unit. If the input voltage is correct, the input board is probably defective (10 to 131 and 1128 to 1152 of PLC and graphics board, 164 to 11'26 of PLC I/O board).

Soft key >END< to exit table display
Soft key >END< to switch TNC back to operating mode EDITING



NOTE:

Always switch off the main switch before engaging or disengaging any connector.



Issue: Ø1.Ø9.1995

Page 81



17.2.2 PLC Outputs

Kundendienst

Check the PLC outputs as follows:

Connect the test unit between LE and PLC or between LE and PL. Set the TNC as follows:

Press key	Function
MOD	Switch TNC to operating mode EDITING (key on VDU) Prepare TNC for code number input
8 0 7 6 6 7 ENT	Enter code number, acknowledge with ENT
	Soft key >TABLE< to display the tables
	Soft key >OUTPUT< to display the output table

Now the logic states of the outputs are displayed on the screen. The states of the screen display must correspond to those of the test unit. If there is a difference, test the connecting cable for short circuit and measure the output current at interface (max. 100 mÅ for LE outputs, max. 1.2 Å for PL outputs). If the output current is not exceeded and the connecting cable is in order, the output board is probably defective (00 to 030 of processor board, 032 to 062 of I/O board PL 400).

Soft key >END< to exit table display
Soft key >END< to switch TNC back to operating mode EDITING




NOTE:

Always switch off the main switch before engaging or disengaging any connector.

Issue: Ø1.Ø9.1995 Kundendienst

Page 82

17.2.3 Measurement Setup for PLC Inputs and Outputs





issue: Ø1.Ø9.1995 **Kundendienst**

17.3 Further Diagnosis Possibilities in the PLC Mode

The TRACE function provides the possibility of controlling the logic states of the markers, the inputs and outputs, of the timer and the counter. It also serves to check the contents of bytes. words and double words.


Call the TRACE function from the PLC main menu with the soft key TRACE.

An instruction list (AWL) of the compiled program (process program) is displayed. In addition, the contents of the operand and of the accumulator is displayed in HEX code or decimal code. All active commands of the instruction list are marked by *. Use the cursor keys or the GOT0 function to display the requested program part.

The following soft-key row is displayed:

|--|

Explanation of the soft keys:



Issue: 01.09.1995 Page **82.2**

Kundendienst Page 82.2

17.3.2 Logic Diagram

Function:

The logic states of up to 16 operands (M, I, 0, T, C) can be displayed graphically on the screen at the same time. 1024 PLC scans can be traced.

Press Key	Function
	Soft key >SELECT M/I/O/T/C<

A table is displayed from which the desired operands can be selected. The control requests the positions of the table in a dialog. Wrong inputs can be cleared by pressing DEL. It is possible to enter a trigger condition for each operand. 512 states are traced before and after a trigger event. The following trigger conditions are possible:

"1" → trace if the operand is a logical "1" (trigger on positive edge)

"0" → trace if the operand is a logical "0" (trigger on negative edge)

→ no trigger
If no trigger condition is entered for any of the operands,
the operand states are traced continuously and the last

the operand states are traced continuously and the last 1024 states are stored.

e.g. \emptyset | 15 | 1 \rightarrow trigger on positive edge 1 06 2 \rightarrow trigger on negative edge 2 M7 \rightarrow no trigger

Soft key >START TRACE<
Switch TNC to the operating mode MACHINE (key on VDU)

The trace function is started with START TRACE; END TRACE or a trigger event end the tracing

PCTR blinking: trigger condition has not occurred yet

PCTR on: trigger condition has occurred; write access to buffer memory

PCTR off: buffer memory is full. logic diagram can be called.

Switch to TRACE mode
Soft key >LOGIC DIAGRAM< to call logic diagram

Issue: 01.09.1995

Page 83

Kundendienst

17.4 Output Control Ready for Operation and Acknowledgement for Test Control Ready for Operation

Important functions are monitored by the TNC 407/415 by way of a self-diagnosis system (electronic assemblies such as the micro-processor, the ROM, read/write memory, positioning systems, encoders etc.)

If an error is detected, a blinking error message is displayed in plain language in the dialog line. As soon as this error is displayed, the output "Control Ready for Operation" becomes inactive.

The output "Control Ready for Operation" is available via the connectors X41/X43 of the LE and on the terminal X3 /pin 10 of the I/O board PL 400. If the error cause has been eliminated, this state can be cancelled by

switching off the main switch or pressing



The output "Control Ready for Operation" is to switch off the control voltage of $\pm 24V$ in the machine tool interface. Since this is an important safety function, the switch-off function of the output "Control Ready for Operation" is tested via the input "Acknowledgement Control Ready for Operation" every time the control is switched on.

The TNC 407 features a monitoring function that is tested when the machine tool is switched on. The TNC 415 comprises 3 monitoring systems (main processor, geometry processor and CLP processor) that are also tested when the machine tool is switched on.

If the +24V at the input "Acknowledgement Control Ready for Operation" are missing during the test routine when the control is switched on, the error message "RELAY EXT. DC VOLTAGE MISSING" is generated. If however, the acknowledgement is switched off too late (or not switched off at all) after switch-off of the output, the blinking error message "EMERGENCY STOP DEFECTIVE" is displayed. This error message is also generated, if the power supply of the PLC part is missing (power supply of the PLC part: see section 8.6).

If the control detects an error during the switch-on test routine, a bridge can be inserted between the outputs "Control Ready for Operation" and "Acknowledge Control Ready for Operation" (disconnect the wires) in order to determine whether the defect is due to the control or to the interface. If the error is still present after inserting the bridge and with correct power supply of the PLC part, the defect is located in the logic unit. If however, the error does not occur any longer after the bridge has been inserted, the interface is defective.




Note


Do not forget to remove the bridge and to install the standard operating state after the test

Issue: 01.09.1995 Page 84

Wiring of the EMERGENCY STOP Interface (Basic Circuit Diagram)



17.4.2 EMERGENCY STOP Flow Diagram: TNC 407




Time	Remarks	Error Message
1		POWER INTERRUPTED
2	Waiting for control voltage	RELAY EXT. DC VOLTAGE MISSING
3	After switching off the output "Control Ready for Operation", the "Acknowledgement Control Ready for Operation" must be switched off within 146 ms; otherwise a blinking error message is generated.	EMERGENOYS OP DEFENIVE
4	If the acknowledgement is switched off during operation, the error message is displayed.	EMERGENCY STOP

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995

Page 85

17.4.3 Flow Diagram: TNC 415



Time	Remarks	Error Message
1		POWER INTERRUPTED
2	Waiting for control voltage	RELAY EXT. DC VOLTAGE MISSING
3	After switching off the output "Control Ready for Operation", the "Acknowledgement Control Ready for Operation" must be switched off within 146 ms; otherwise a blinking error message is generated.	YX = 1(= Communication processor 1)= Geometry processor 1. = CLP processor
4	If the acknowledgement is switched off during operation, the error message is displayed.	EMERGENCY STOP

Page 86




18. Test Units

18.1 Test Load Unit for the Power Supply Assembly


Used:

to test the power supply assembly




18.2 Test Unit for the PLC Inputs and Outputs

PL Test Unit, Id.No. 247 359 01 to test the PLC inputs and outputs at the PL



PLC Test Unit, Id.No. 247 361 01 to test the PLC inputs and outputs at the LE




Page **87**

18.3 Measuring Adaptor - Id.No. 255 480 01


Used: to test the keyboard unit (see section 9.3)

as a universal test unit for D-sub connectors (9-pin to 37-pin)




The measuring adaptor can be used to test the inputs and outputs of D-sub connectors (9-pin to 37-pin). On the following page the adaptor cables required for each connector size are described.


The measuring adaptor can also be used instead of the PLC test unit described on page 86 (without display)




Adaptor Cable,9pin Id.No. 255 481 01



Adaptor Cable, 15pin Id.No. 255 482 01



Adaptor Cable, 25pin Id.No. 255 483 01




Adaptor Cable, 37pin Id.No. 255 484 01

18.4 Encoder Diagnostic Set, Id.No. 254 599 02

<u>Used:</u>

- to test the electrical functions of an encoder (further information please see from the operating instructions of the Diagnostic Set)



Issue: 01.09.1995 Page89

19. Exchange Instructions

19.1 General Remarks

19.1.1 Equipment Required

external data medium, e.g. FE 401/B or personal computer with connecting cable

1 tool set (screwdriver, socket wrench etc.)

1 MOS protection device (only required for exchanging boards or EPROMs)

19.12 MOS Protection


If the processor board, the PLC and graphics board, the CLP boards or EPROMs are to be exchanged, a MOS protection is definitely required, as otherwise MOS components on the boards or EPROMs may be destroyed.



Note:

Avoid any unprotected handling or contact of the boards or EPROMs with statically charged objects (packaging material, storage etc.).

MOS Protection



19.1.3 Software Compatibility

Exchange units (complete logic unit) are generally supplied with the latest software version. Exchange boards however, are always supplied without software and without software protection module. For this reason, the EPROMs and the software enable module of the defective board must be inserted into the exchange board at site (see sec. 19.9). Before sending us exchange boards for repair, always remove the EPROMs and the software enable module.

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995 Page 90

Kundendienst Page 9

19.1.4 Backing up RAM Data

Before the complete logic unit or the processor board is exchanged all files in the RAM must be backed up on at- external data medium.

The machine parameters and the part programs are always processed from the RAM and must be stored on an external data medium.

In the machine parameter MP7224 individual file types can be enabled:

- e.g. tool tables, datum tables, pallet tables, ASCII files.
- If all files or individual files are enabled, they need to be stored on an external data medium.
- If the value of the machine parameter MP4010 is 1, the PLC program parts are processed from the RAM and must be backed up.
- If the machine parameter MP730 is not 0, the multipoint axis error compensation is active for one or several axes. In this case, the compensation value list must be backed up as well.

Note:

For reasons of safety, the machine parameters, the compensation value list (if active) and the PLC program (if MP4010=1) should always be backed up on an external data medium. The procedure for data backup is described in section 15.3. Data backup is not required, if the data are already stored on an external data medium.

Kundendienst

Issue: Ø1.Ø9.1995 Page 91

19.1.5 Determining Data for the Auxiliary Operating Modes:

If the processor board assembly or the complete logic unit are to be exchanged, or if a software exchange is to be carried out, the preset values and the current entry values of the auxiliary operating modes should be determined, so that they can be re-entered after the exchange.

Switch off and on the main switch of the machine tool

TNC Dialog Display	Press Key	Remarks
MEMORY TEST	CE	
POWER INTERRUPTED		
RELAY EXT. DC VOLTAGE MISSING		Switch on control voltage
MANUAL OPERATING MODE TRAVERSE REF. POINT .AXIS .AXIS .AXIS	мор	Do not yet traverse the reference points!
POSITION DISPLAY (upper row) 0 0 0 0 0 ACTL REF LAG NOML DIST		Note down the current setting for the position display the switch to ACTL by pressing
POSITION DISPLAY (lowerrow) 0 0 0 0 0 ACTL REF LAG NOML DIST		ENT
The lower position display can be switched on with the soft key >STATUS ON< (only with split screen).		
CHANGE MM/INCH 0 0 MM INCH		√lark unit with a cross
PROGRAM ENTRY 0 0 HEIDENHAIN ISO		√lark type of program
LIMIT X- LIMIT Y- LIMIT Y+	Soft key AXIS LIMIT<	Note down the limit values Do not forget the algebraic sign!) f MP7490 = 1, three different limits may be active. In this case note down all 3 values.



SERVICE MANUAL TNC 407/415 Issue: 01.09.1995

Page 91 .1 Kundendienst

TNC Dialog Display	Press Key	Remarks
LIMIT Z- LIMIT Z+ LIMIT IV- LIMIT IV+ LIMIT V- LIMIT V+	Soft key >END<	Note down the limit values (Do not forget the algebraic sign!)
ACTL X ACTL Y ACTL Z		Note down the preset values (Do not forget the algebraic sign!)
ACTL IV ACTL V	MOD	(key on VDU)
Software Number: VC PLC	Soft key RS232/RS422 SETUP<	Note down the NC and PLC software numbers
OPERATING MODE VIE FE1 FEZ EXT1 EXT2 3 0 0 0 0		Vlark the operating mode of the RS232 interface
3AUD RATE -E BAUD EXT1 BAUD EXT2 BAUD		Note down the Baud rates of the RS232 interface

SERVICE MANUAL TNC 407/415

Issue: 01.09.1995

Kundendienst Page 92

TNC Dialog Display	Press Key Remarks
OPERATING MODE ME FE1 FEZ EXT1 EXT2 0 0 0 0 0	Mark the operating mode of the RS422 interface
BAUD RATE FE BAUD EXT1 BAUD EXT2 BAUD	Note down the Baud rates of the RS422 interface
ALLOCATION PROGRAMMING 0 RS 323 0 RS422 TEST RUN 0 RS 3'23 0 RS422 PROGRAM RUN 0 RS 323 0 RS422	Mark the allocation of the interfaces to the operating modes Soft key >END<

19.1.6 Labelling the Connecting Cables

If the connecting cables are labelled incompletely or not at all, they have to be marked such that the correct plug connections can be re-established after the exchange of the logic unit or of another assembly. (Pin layout: see section 5)



WARNING:

Switching the connecting cables may destroy the unit

Kundendienst

Issue: 01 .09.1995 Page 93

19.2 Exchanging the Logic Unit


192.1 Data Backup and Labelling of the Cables

(see section 19.1)

19.2.2 Dismounting the Logic Unit

a) Switch off the main switch


b) Loosen all plug connectors and clamped joints at the logic unit (pin layout: see section 5)



Issue: 01.09.1995

Kundendienst Page 94

c) Loosen the 4 mounting screws on the logic unit



d) Remove the old logic unit and insert the new one.

19.23 Mounting of the Logic Unit

The logic unit is mounted in the reverse order that is was dismounted:

- a) Insert the logic unit and secure it.
- b) Engage connectors.

Observe that no connectors are switched!

- c) Switch on the main switch.
- d) Read in the machine tool data that have been backed up before the exchange (machine parameters, PLC program, NC programs and tables).
- e) Enter preset values and supplementary operating modes from the table in section 19.1.5 **(before** ref. mark traverse).
- f) Offset adjustment with code number (see section 16.5).

Exchange is now finished

Kundendienst


Issue: 01.09.1995 Page 95

19.3 Exchanging the TNC 415 Processor Board


19.3.1 MOS-Protection, Software, Data Backup and Labelling of the Cables (see section 19.1)

19.3.2 Dismounting the Processor Board

- a) Switch off the main switch at the machine tool.
- b) Loosen the connectors at the processor board (X21, X22, X231. (Pin layout: see section 5)
- c) Undo the lock and open the logic unit.




d) Disengage internal connectors



Issue: 01.09.1995

Kundendienst Page 96

e) Loosen/remove the fixing screws



f) Lift out the processor board; exchange the **EPROMs**, if required (see section 19.9). Insert the new board.

19.3.3 Mounting the Processor Board

The processor board is mounted in the reverse order that is was dismounted

- a) Insert and secure the processor board.
- b) Engage the connectors.

Observe that no connectors are switched!

- c) Close the logic unit and close the lock.
- d) Switch on the main switch.
- e) Read in the machine tool data that have been backed up before the exchange (machine parameters, PLC program, NC programs and tables).
- f) Enter preset values and supplementary operating modes from the tables in section 19.1.5 **(before** ref. mark traverse).
- g) Offset adjustment with code number (see section 16.5).

Exchange is now finished



NOTE:

Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.



Page 97


Exchanging the TNC 415 CLP Board 19.4

19.4.1 MOS-Protection, Software, Data Backup and Labelling of the Cables (see section 19.1)


19.4.2 Dismounting the CLP Board

D-83292 Traunreut - 🕾 (0.86.69) 31-0

- a) Switch off the main switch at the machine tool.
- b) Loosen the connectors at the CLP board (X1- X6, X8, X10, X12). (Pin layout: see section 5.1
- c) Undo the lock and open the logic unit




d) Disengage internal connectors



Issue: 01.09.1995

Kundendienst Page 98

e) Loosen/remove the fixing screws



f) Lift out the CLP board: exchange the EPROMs, if required (see section 19.9). Insert the new board.

19.4.3 Mounting the CLP Board

The CL'? board is mounted in the reverse order that is was dismounted.

- a) Insert and secure the CLP board,
- b) Engage the connectors.

Observe that no connectors are switched!

- c) Close the logic unit and close the lock.
- d) Switch on the main switch.
- e) Offset adjustment with code number (see section 16.5)

Exchange is now finished



NOTE:

Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

Page 99


Exchanging the PLC and Graphics Board of TNC407/415 19.5


MOS-Protection and Labelling of the Cables 19.5.1 (see section 19.1)

19.5.2 **Dismounting the PLC and Graphics Board**

- a) Switch off the main switch at the machine tool.
- b) Loosen the connectors at the PLC and graphics board (X41 X47) (Pin layout: see section 5)
- c) LE 407: Undo lock and open logic unit LE 415: Remove knurled screws

Kundendienst






HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

D-83292 Traunreut © (08669) 31-0

e) Loosen/remove the fixing screws



f) Lift out the PLC and graphics board. Insert the new board.

19.5.3 Mounting the PLC and Graphics Board

The PLC and graphics board is mounted in the reverse order that is was dismounted,

- a) Insert and secure the CLP board.
- b) Engage the connectors.

Observe that no connectors are switched!

- c) Close the logic unit and close the lock.
- d) Switch on the main switch.
- e) Offset adjustment with code number (see section 16.5).

Exchange is now finished.



NOTE:

Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

Kundendienst


Issue: 01.09.1995 Page 101


19.6 Exchanging the TNC 407 Processor Board

19.6.1 MO&Protection, Software, Data Backup and Labelling of the Cables (see section 19.1)

19.6.2 Dismounting the Processor Board


- a) Switch off the main switch at the machine tool.
- b) Loosen the connectors at the processor board (X1 to X6, X12 x21 to X23). (Pin layout: see section 51
- c) Undo the lock and open the logic unit.





Kundendienst Page 102

e) Loosen/remove the fixing screws



f) Lift out the processor board; exchange the EPROMs, if required (see section 19.9) Insert the new board.

19.6.3 Mounting the Processor Board

The processor board is mounted in the reverse order that is was dismounted.

- a) Insert and secure the processor board
- b) Engage the connectors.

Observe that no connectors are switched!

- c) Close the logic unit and close the lock.
- d) Switch on the main switch.
- e) Read in the machine tool data that have been backed up before the exchange (machine parameters, PLC program, NC programs and tables).
- f) Enter preset values and supplementary operating modes from the tables in section 19.1.5 **(before** ref. mark traverse).
- g) Offset adjustment with code number (see section 16.5).

Exchange is now finished




NOTE:

Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.


Issue: 01.09.1995 Page 103 Kundendienst

Exchanging the Power Supply Assembly of TNC 407/415 19.7

- **a)** Switch off the main switch at the machine tool.
- b) Undo the locks and open the logic unit.



d) Disengage internal connectors




1.17多年3

Issue: Ø1.Ø9.1995

Kundendienst Page 104

d) Loosen the mounting screws

Slide out the power supply unit to the right and insert the new power supply unit



e) Fasten the mounting screws, engage internal connectors

Observe that no connectors are switched!

f) Close the logic unit, switch on the main switch.




NOTE:


Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

19.8 Exchanging the PLC I/O Board PL 400

b) Loosen the plug connections and the screw terminals at the PLC I/O board




c) Loosen the screws from the cover of the PLC I/O board, remove cover and disconnect the connecting cable to the PLC board from the PLC I/O board.



Issue: Ø1.Ø9.1995

Kundendienst Page 106

d) Loosen the screws and remove the PLC I/O board



- e) The new PLC I/O board is mounted in reverse order:
 - Mount the PLC I/O board to the logic unit.
 - -Connect the PLC I/O board to the processor board.

Engage the connectors.

-Switch on the main switch.

Exchange is now finished,



NOTE:

Send and store the boards only in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.



Kundendienst

Issue: **01** .09.1995 Page **107**

19.9 Exchanging EPROMs

19.9.1 MOS Protection

For the exchange of EPROMs MOS-protection is indispensable, as otherwise the EPROMs could be destroyed by static charge. Moreover, all data should be backed up (see section 15.1).


Observe the mark on the EPROMs (do not turn them by 180"); be sure not to damage any components during the exchange. Use an appropriate tool. After the software exchange, the logic unit must be marked with the new NC-software number (see section 14.1). The offset adjustment with code number should be performed as well (see section 16.5).

e.g. IC drawing punch and insertion tool







19.9.1 EPROM Designation




Processor Board TNC 415



CLP Board TNC 415



Processor Board TNC 407



Kundendienst

Issue: 01.09.1995 Page 108

20. Machine Parameters

The following list contains the machine parameters for all software versions. However, as some machine parameters are not valid for certain controls or have been introduced /eliminated with a certain software version, columns with symbols for differentiation have been added after the parameter numbers.

Explanation of the Symbols

- With this control, the machine parameter is valid for all software versions.
- The machine parameter has been introduced with a certain software version (e.g. 04 means introduction with software version 04).
- 104The machine parameter has been eliminated starting with a certain software version (e.g. 04 means elimination as of software version 04), or it has been replaced by another parameter.

This machine parameter is not available on this control.

* The machine parameter is accessible via the code number 1'23.

Explanation of the Columns

407 AS	Old software	243 07.
415AS	Old software	243 05., 259 91.
407 NS	New software	243 02.
415 NS	New software	259 96 259 97

Structure

The machine parameters are subdivided into groups.

Due to the structure of the parameter numbers, the list can be expanded easily.

0 999 Encoders and machine tool axes: allocation, evaluation, compensation

1000	Positioning
1400	Operation with feed precontrol
1700	Operation with servo lag
3000	Spindle control
4000	Integrated PLC
5000	Adaptation of the data interface
6000	Measurement with 3D-touch probe system
7100	Tapping
7200	Display and programming
7320	Colour allocation for colour screens
7330	User parameters
7400	Processing and program run

7600

Hardware



Issue: Ø1.Ø9.1995 Kundendienst

Page109

MACHINE PARAMETER LIST

(Excerpt from the Repair Handbook 1.0 **TNC 4071415, section 10.2)**

Code Numbers

123	MACHINE PARAMETER EDITING FOR END USERS (marked by *)
75368	OFFSET ADJUSTMENT
79513	DISPLAY OF VOLTAGE AND TEMPERATURE
86357	REMOVE EDIT/ERASE PROTECTION
95148	MP MODE
105296	COMPENSATION VALUE LIST
531210	RESETTING M 1000 TO M 2000 AND BYTES 0 - 127
620159	DOWNLOADING RUN-IN PROGRAM VIA INTERFACE
807667	PLC MODE
688379	INTERNAL OSCILLOSCOPE

Machine Parameters

The following list contains the machine parameters of all software versions. Since, however, certain machine parameters are only valid for a certain software version or from a certain version on, the list contains columns with symbols for differentiation.

Explanation of the Symbols:

- This machine parameter or entry value is valid for all software versions of this control model.
- = This machine parameter has been introduced with a certain software version (e.g. 04 means that the MP has been introduced with the software version 04).
- 104 = This machine parameter is inactive.
- = This machine parameter is not available with this control model.

Explanation of the Columns:

```
A = TNC 407 with NC software 243 07* - (without digitizing)
B = TNC 415 with NC software 243 05* - and 259 91* - (without digitizing)
C = TNC 407 with NC software 243 02* - (with digitizing)
D = TNC 415 with NC software 259 96* - and 259 97* - (with digitizing)
E = TNC 407 with NC software 243 03* --(equivalent to TNC 415B/425 software)
F = TNC 415 with NC software 280 58* - (special software)
AE-6 = entry values for HEIDENHAIN test unit
```

RH
1.0 TNC 407/415 Machine Parameters Overview 16.01.95 10.1

User Parameters

By means of the MOD function "User Parameters" several machine parameters can be accessed easily (e.g. adaptation of the data interface). This user parameters accessible via MOD function are defined by the machine tool manufacturer through machine parameters.

Entry Values

Possible entry values are:

- The numbers 0 and 1 to select functions, signs, counting directions etc.
- Numerical values for feed rates, displacements etc.
- Decimal values that can be calculated by combining several functions (bit-coded).
- Bit patterns (marked by %), as of TNC407 with NC software 243 03* e.g. MP 10: %00111
- X, Y, Z with encoder (1) i.e. IV, V without encoder (0)
- Hexadecimal values (marked by \$), as of TNC407 with NC software 234 03* e.g. MP 7353.0: \$ 0F818A0

Structure

The machine parameters are subdivided into groups.

The machine parameter number are structured such that the list can be expanded easily.

0-999	Encoders and machine axes: allocation, evaluation, compensation
1000	Positioning
1400	Operation with feed forward control
1700	Operation with servo lag
3000	Spindle
4000	Integral PLC
5000	Adaptation of the data interface
6000	3D-touch probe (general parameters)
6210	Digitizing with 3D-touch probe
6500	Tool calibration with TT 110
7100	Tapping
7200	Display and Programming
7320	Colors, general display and FK graphics
7330	USER parameters
7350	Colors, general display and FK graphics
7400	Machining and program run
7600	Hardware

1.0 TNC 407/415 **Machine Parameters Overview** 16.01.95

Function		No.	MP Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Axes with encoder		10		•	•	•	•	•	•	0 = no encoder	
	Χ		0							+1 = X axis with encoder	% 11111
	Υ		1							+2 = Y axis with encoder	(31)
	Ζ		2							+4 = Z axis with encoder	
	IV		3							+8 = IV. axis with encoder	
	V		4							+16 = V. axis with encoder	
Encoder monitoring		30		•	•	•	•	•	•	0 = no axis monitored	
Absolute position with distance-coded	X		0							+1 = X axis monitored	% 111111
reference marks	Υ		1							+2 = Y axis monitored	(63)
	Ζ		2							+4 = Z axis monitored	
	IV		3							+8 = IV. axis monitored	
	V		4							+16 = V. axis monitored	
	S		5							+32 = S axis monitored	
Signal amplitude	<u> </u>	31		•	•	•	•	•	•	0 = no axis monitored	
	X		0							+1 = X axis monitored	% 111111
	Υ		1							+2 = Y axis monitored	(63)
	Ζ		2							+4 = Z axis monitored	
	IV		3							+8 = IV. axis monitored	
	V		4							+16 = V. axis monitored	
	S		5							+32 = S axis monitored	
Edge separation		32		•	•	•	•	•	•	0 = no axis monitored	
-	X		0							+1 = X axis monitored	% 111111
	Υ		1							+2 = Y axis monitored	(63)
	Z		2							+4 = Z axis monitored	
	IV		3							+8 = IV. axis monitored	
	V		4							+16 = V. axis monitored	
	S		5							+32 = S axis monitored	

1.0 TNC 407/415 MP 10 - MP 32 16.01.95 10.2 1 **Machine Parameters**

Function	No.	MP Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Screen display X Y Z IV V S	40	0 1 2 3 4 5	* * * * *	* * *	* * *	* * *	* * *	* * *	0 = no display +1 = X axis displayed +2 = Y axis displayed +4 = Z axis displayed +8 = IV. axis displayed +16 = V. axis displayed +32 = position of controlled spindle (not with M03/M04)	% 111111 (63)
Controlled axes X Y Z IV	50	0 1 2 3 4	•	•	•	•	•	•	0 = no axis controlled +1 = X axis controlled +2 = Y axis controlled +4 = Z axis controlled +8 = IV. axis controlled +16 = V. axis controlled	% 11111 (31)
Auxiliary axes for the PLC X Y Z IV	60		-	-	-	-	05	•	0 = no auxiliary axis +1 = X axis is auxiliary axis +2 = Y axis is auxiliary axis +4 = Z axis is auxiliary axis +8 = IV. axis is auxiliary axis +16 = V. axis is auxiliary axis	% 00000 (0)
Allocation of the encoder inputs to the machine axes X Y Z IV	110. 110. 110. 110. 110.	1 2 3	* * *	*	* * *				0 to 5 0 = X1 1 = X2 2 = X3 3 = X4 4 = X5 5 = X6 ¹⁾	0 1 2 3 4

¹⁾ X6 may only be used for a machine axes, if no regulated spindle (GS) is required.

1.0 TNC 407/415 **Machine Parameters** MP 40 - MP 110.4 16.01.95 10.2 2

Function		М	P	Α	В	С	D	Е	F	Input	AE-6
		No.	Bit								Entry Value
Allocation of the nominal value										0 to 5	
outputs to the machine axes	X	120.0		•	•	•	•	•	•	0 = output 1	0
	Υ	120.1		•	•	•	•	•	•	1 = output 2	1
	Z	120.2		•	•	•	•	•	•	2 = output 3	2
	IV	120.3		•	•	•	•	•	•	3 = output 4	2 3
	V	120.4		•	•	•	•	•	•	4 = output 5	4
	S	120.5		•	*	•	•	•	•	$5 = \text{output S}^{1)}$	
Counting direction of the encoder		210		•	٠	٠	•	•	٠	0 = positive	
signals	X		0							+1 = X axis negative	% 00000
•	Υ		1							+2 = Y axis negative	(0)
	Ζ		2							+4 = Z axis negative	
	IV		3							+8 = IV. axis negative	
	V		4							+16 = V. axis negative	
	S										
Signal period										0.1 to 1000 [µm]	
(Displacement per grating period.	X	330.0		•	•	•	•	•	•	·	20
Consider the screw pitch when using a	Υ	330.1		•	•	•	•	•	•		20
rotary encoder)	Z	330.2		•	•	•	•	•	•		20
With square-wave input signals the	IV	330.3		•	•	•	•	•	•		20
displacement per square-wave period must	V	330.4		•	•	•	•	•	•		20
be indicated (consider external	S										
interpolation).											

¹⁾ S-analogue may only be used for a machine axes, if no analogue output of the spindle speed is required.

RH
1.0 TNC 407/415 Machine Parameters MP 40 - MP 110.4 16.01.95 10.2 3

Function		MP	A	В	С	D	E	F	Input	AE-6
		No. Bit								Entry Value
EXE interpolation factor at									0, 1, 5	
encoder input	X	340.0	-	-	03	-	•	•	0 = no EXE	0
	Υ	340.1	-	-	03	-	•	•	1 = 1-fold EXE	0
	Z	340.2	-	_	03	-	•	•	5 = 5-fold EXE	0
	IV	340.3	-	_	03	-	•	•		0
	V	340.4	-	-	03	-	•	•		0
Axis designation										
•	VI	410.3	•	•	•	•	•	•	0 = A $1 = B$ $2 = C$	4
	V	410.4	•	•	•	•	•	•	3 = U $4 = V$ $5 = W$	5
Hirth coupling										
Activation	VI	420.3	•		•	•	•	•	0 = inactive	0
	V	420.4	•	•	•	•	•	•	1 = active	0
Defined steps										
·	VI	430.3	•		•	•	•	•	0 to 30.0000 [°]	1
	V	430.4	•	•	•	•	•	•		1

RH
1.0 TNC 407/415 Machine Parameters MP 340.0 - MP 430.4 16.01.95 10.2 4

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Axis compensations:										
Backlash compensation	Χ	710.0	•	•	•	•	•	•	-1.0000 to +1.0000 [mm]	0
	Υ	710.1	•	•	•	•	•	•		0
	Z	710.2	•	•	•	•	•	•		0
	IV	710.3	•	•	•	•	•	•		0
	V	710.4	•	•	•	•	•	•		0
Compensation of reversal spikes										
with circular movements	X	711.0	-	_	•	•	•	•	0 to 1 [mm]	0
magnitude of reversal spike	Υ	711.1	-	-	•	•	•	•		0
agag.	Z	711.2	_	_	•	•	•	•		0
	IV	711.3	_	_	•	•	•	•		0
	V	711.4	_	_	•	•	•	•		0
feed rate to compensate										
the reversal spike	X	712.0	_	_	•	•	•	•	0 to 1 [mm per CLP cycle time]	0
the reversal opins	Υ	712.1	_	_	•	•	•	•	, , , , , , , , , , , , , , , , , , , ,	0
	Z	712.2	_	_	•	•	•	•		0
	ĪV	712.3	_	_	•	•	•	•		0
	V	712.4	_	_	•	•	•	•		0
magnitude of reversal spike		1								
(only effective with M05)	Χ	715.0	_	_	_	_	08	•	0 to 1 [mm]	0
(ethly effective with wide,	Υ	715.1	_	_	_	_	08	•		0
	Z	715.2	_	_	_	_	80	•		0
	ĪV	715.3	_	_	_	_	80	•		0
	V	715.4	_	_	_	_	08	•		0
• feed rate to compensate the reversal										
spike (only effective with M05)	Χ	716.0	_	_	_	_	08	•	0 to 1 [mm per CLP cycle time]	0
spine (em) encoure with moor	Υ	716.1	_	_	_	_	08	•	- ,	0
	Z	716.2	_	_	_	_	80	•		0
	ĪV	716.3	_	_	_	_	80	•		0
	V	716.4	_	_	_	_	80	•		Ŏ

RH 1.0 TNC 407/415 Machine Parameters MP 710.0 - MP 716.4 16.01.95 10.2 5

Function		Mo.	P Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Factor for multipoint axis error		1101									
compensation	X	720.0		•	•	•	•	•	•	-1.0000 to +1.0000 [mm]	0
-	Υ	720.1		•	•	•	•	•	•		0
	Z	720.2		•	•	•	•	•	•		0
	IV	720.3		•	•	•	•	•	•		0
	V	720.4		•	•	•	•	•	•		0
Multipoint axis error compensation		730								0 = linear compensation active	
-	Χ		0	•	•	•	•	•	•	+1 = X axis, multipoint compensation active	% 00000
	Υ		1							+2 = Y axis, multipoint compensation active	(0)
	Z		2							+4 = Z axis, multipoint compensation active	
	IV		3							+8 = IV. axis, multipoint compensation active	
	V		4							+16 = V. axis, multipoint compensation active	
Display mode										0 to ± 99 999.9999 [mm] or [°]	
for rotary axes and PLC auxiliary axes	X	810.0		-	-	-	-	•	•	$0 = \text{display} \pm 99999999999999999999999999999999999$	0
	Υ	810.1		-	-	-	-	•	•	(software limit switch active)	0
	Z	810.2		-	-	-	-	•	•	≠ 0 modulo value for display	0
	IV	810.3		-	-	-	-	•	•	(software limit switch inactive)	0
	V	810.4		-	-	-	-	•	*	(22.3	0

RH
1.0 TNC 407/415 Machine Parameters MP 720.0 - MP 810.4 16.01.95 10.2 6

Function		MP	•	Α	В	С	D	Е	F	Input	AE-6
		No.	Bit							-	Entry Value
Gantry axes										0 to 5	
Configuration	Χ	850.0		-	-	-	-	80	•	0 = main axis	
	Υ	850.1		-	-	-	-	80	•	1 = coupled with X axis	0
	Z	850.2		-	-	-	-	80	•	2 = coupled with Y axis	0
	IV	850.3		-	-	-	-	80	•	3 = coupled with Z axis	0
	V	850.4		-	-	-	-	80	•	4 = coupled with IV. axis	0
										5 = coupled with V. axis	0
Monitoring the parallel movement of the										0 to 100.0000 [mm]	
coupled axes	Χ	855.0		-	-	-	-	-	02	0 = monitoring inactive	0
'	Υ	855.1		-	-	-	-	-	02	≠ 0 maximum deviation of master	0
	Z	855.2		-	-	-	-	-	02	and slave axes	0
	IV	855.3		-	-	-	-	-	02		0
	V	855.4		-	_	-	-	_	02		0
Defining the relationship between the axes										0, 1	
g	X	860.0		_	_	_	_	08	•	0 = referenced to position after power-on	0
	Υ	860.1		_	_	_	_	80	•	1 = referenced to REF marks (machine datum)	0
	Z	860.2		_	_	_	_	80	•	January Communication of the C	0
	ĪV	860.3		_	_	_	_	80	•		0
	V	860.4		-	_	-	-	80	•		0

RH
1.0 TNC 407/415 Machine Parameters MP 850.0 - MP 860.4 16.01.95 10.2 7

	MP		A	В	C	D	Е	F	Input	AE-6
	No.	Bit								Entry Value
X+	910.0		•	•	•	•	•	•	linear axis:	+99 999.9999
Y+	910.1		•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [mm]	ıı ı
Z+	910.2		•	•	•	•	•	•		ıı ı
IV+	910.3		•	•	•	•	•	•	rotary axis:	"
V+	910.4		•				•	•	-99 999.9999 to +99 999.9999 [°]	"
X-	920.0							•		-99 999.9999
Y-	920.1									п
Z-	920.2									п
IV-	920.3				-					п
V-										ıı ı
-			•	Ť		Ť	Ť	Ť		
×⊥	911 0		•	•	•	•		•	linear axis:	+99 999.9999
										+33 999.9333
			•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [IIIII]	п
			•	•	•	•	•	•	rotory ovio:	п
			•	•	•	•	•	•		п
			•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [] 	-99 999.9999
			•	•	•	•	•	•		-99 999.9999
			•	•	•	•	•	•		
			•	•	•	•	•	•		
			•	•	•	•	•	•		
V-	921.4		•	•	•	•	•	•		
			•	•	•	•	•	•	linear axis:	+99 999.9999
									-99 999.9999 to +99 999.9999 [mm]	"
										"
								•	rotary axis:	"
								•	-99 999.9999 to +99 999.9999 [°]	"
										-99 999.9999
										П
			•			•	•	•		"
IV-	922.3		•	•	•	•	•	•		II
V-	922.4		•	•	•	•	•	•		II
	Y+ Z+ IV+ V+ X- Y- Z- IV- V- X+ Y+ Z+ IV+ V+ X- Y- Z- IV- V- V- X+ Y+ Z- IV- V- IV- I	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z- 912.2 IV- 912.3 V- 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y- 912.1 Z- 912.2 IV- 912.3 V- 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y- 921.4 X+ 912.0 Y- 921.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 V- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.1 Z- 922.1 Z- 922.1 Z- 922.2 IV- 922.3 Y- 922.1 Z- 922.2 <t< td=""><td>X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3</td><td>X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3 IV- 922.3</td><td>X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 921.1 Z- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3</td><td>X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3</td><td> No. Bit </td></t<>	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3 IV- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 921.1 Z- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3	X+ 910.0 Y+ 910.1 Z+ 910.2 IV+ 910.3 V+ 910.4 X- 920.0 Y- 920.1 Z- 920.2 IV- 920.3 V- 920.4 X+ 911.0 Y+ 911.1 Z+ 911.2 IV+ 911.3 V+ 911.4 X- 921.0 Y- 921.1 Z- 921.2 IV- 921.3 V- 921.4 X+ 912.0 Y+ 912.1 Z+ 912.2 IV+ 912.3 V+ 912.4 X- 922.0 Y- 922.1 Z- 922.2 IV- 922.3 IV- 922.3	No. Bit

1.0 TNC 407/415 **Machine Parameters** MP 910.0 - MP 922.4 10.2 8 08.05.95

Function		MP		Α	В	С	D	Е	F	Input	AE-6
		No. B	it							-	Entry Value
Datum for positioning blocks with											
M92	Χ	950.0		•	•	•	•	•	•	linear axis:	0
(referenced to the machine datum)	Υ	950.1		•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [mm]	0
	Ζ	950.2		•	•	•	•	•	•		0
	IV	950.3		•	•	•	•	•	•	rotary axis:	0
	V	950.4		•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [°]	0
	•			•	•	*	•		•		
Target position for simulated tool											
change for TOOL CALL during block	X	951.0		_	_	09	09	08	•	linear axis:	0
scan	Υ	951.1		_	_	09	09	08	•	-99 999.9999 to +99 999.9999 [mm]	0
	Z	951.2		_	_	09	09	80	•	,	0
	ĪV	951.3		_	_	09	09	80	Ť	rotary axis:	0
	V	951.4		_	_	09	09	08	Ť	-99 999.9999 to +99 999.9999 [°]	0
	•	001.1							•		
Shifting the machine datum											
(referenced to the REF mark of the	Χ	960.0		_	_	•	•	•	•	linear axis:	0
encoder)	Υ	960.1		_	_	•	•	•		-99 999.9999 to +99 999.9999 [mm]	0
	7	960.2		_	_	·	·	•	•		0
	IV	960.3		_	_	·	•		•	rotary axis:	0
	V	960.4		_	_				•	-99 999.9999 to +99 999.9999 [°]	0
	v	300.4		_	_	•	•	•	•	00 000.0000 to +00 000.0000 []	

Machine Parameters MP 950.0 - MP 960.4 16.01.95 10.2 9

Function		MP No. Bi	t A	В	С	D	E	F	Input	AE-6 Entry Value
Rapid traverse	X Y Z IV V	1010.0 1010.1 1010.2 1010.3 1010.4	•	•	* * * *	* * * *	* * * *	* * * *	linear axis: 10 to 30 000 [mm/min] rotary axis: 10 to 30 000 [°/min]	10000 10000 10000 10000 10000
Manual feed	X Y Z IV V	1020.0 1020.1 1020.2 1020.3 1020.4	•	•	* * * *	* * *	* * * *	* * * *	linear axis: 10 to 30 000 [mm/min] rotary axis: 10 to 30 000 [°/min]	10000 10000 10000 10000 10000
Positioning window	X Y Z IV V	1030.0 1030.1 1030.2 1030.3 1030.4	•	•	* * *	* *	* * *	* * *	linear axis: 0.0001 to 2.0000 [mm] rotary axis: 0.0001 to 2.0000 [°]	0.05 0.05 0.05 0.05 0.05
Polarity of the nominal voltage was positive traverse direction	vith X Y Z IV V	1040 0 1 2 3 4	•	•	•	•	•	•	0 = positive +1 = X axis negative +2 = Y axis negative +4 = Z axis negative +8 = IV. axis negative +16 = V. axis negative	% 00000
Analogue voltage for rapid travel	x X Y Z IV V	1050.0 1050.1 1050.2 1050.3 1050.4	•	•	* * *	• •	* * *	* * *	4.5 to 9 [V]	9 9 9 9

1.0 TNC 407/415 Machine Parameters MP 1010.0 - MP 1050.4 16.01.95 10.2 10

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Acceleration		•	•	•	•	•	•	0.001 to 3.0 [m/s ²]	1
Y	1060.1	•	•	•	•	•	•		1
Z	1060.2	•	•	•	•	•	•		1
IV.		•	•	•	•	•	•		1
V	1060.4	•	•	•	•	•	•		1
Radial acceleration	1070	•	•	•	•	•	•	0.0001 to 3.0 [m/s ²]	1.5
Integral factor									
X	1080.0	•	•	•	•	•	•	0 to 65 535	0
Y	1080.1	•	•	•	•	•	•		0
Z	1080.2	•	•	•	•	•	•		0
IV.		•	•	•	•	•	•		0
V	1080.4	•	•	•	•	•	•		0
Standstill monitoring	1110	•	•					0.001 to 30 [mm]	0.1
X	1110.0	_	_	_	_	_	_	0.0001 to 30 [mm]	0.1
Y	1110.1	-	-	•	•	•	•		0.1
Z	1110.2	-	-	•	•	•	•		0.1
1\	1110.3	-	-	•	•	•	•		0.1
V	1110.4	-	-	•	•	•	•		0.1
Movement monitoring	1140				l ·		1		1
X	1140.0	*	•					0.03 to 10 [V]	1
Y	1140.1	_	-	_	-	-	-	0.00 to 10 [v]	1
Z	1140.2	-	_	•	•	•		Note:	1
				•	•	*	•	entry value 10 → monitoring inactive	1
V	1140.4		_	•	•	•	•	l entry value 10 → monitoring mactive	1
·				*	*	•	•	005.505.[.]	1
Time out to switch off the residual nominal voltage when the error message "Positioning Error"	1150	•	•	•	•	•	•	0 to 65 535 [s]	0
is generated									
Automatic cyclic offset adjustment	1220	•	•	*	*	*	*	0 to 65 535 [s]	1
								0 = no automatic adjustment	

1.0 TNC 407/415 **Machine Parameters** MP 1060.0 - MP 1220 16.01.95 10.2 11

Function		MP No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Reference mark evaluation		1320		•	•	•	•	•	•	0 = positive	
Traverse direction for passing over the	Χ		0							+1 = X axis negative	% 00000
reference marks	Υ		1							+2 = Y axis negative	(O)
	Ζ		2							+4 = Z axis negative	
	IV		3							+8 = IV. axis negative	
	V		4							+16 = V. axis negative	
eed rate for passing over the reference											
marks	X	1330.0		•	•	•	•	•	•	linear axis:	10 000
	Υ	1330.1		•	•	•	•	•	•	10 to 30 000 [mm/min]	10 000
	Z	1330.2		•	•	•	•	•	•		10 000
	IV	1330.3		•	•	•	•	•	•	rotary axis:	10 000
	V	1330.4		•	•	•	•	•	•	10 to 30 000 [°/min]	10 000
Feed rate for leaving the reference end											
position	Χ	1331.0		•	•	•	•	•	•	linear axis:	200
(only if MP1350 = 2)	Υ	1331.1		•	•	•	•	•	•	10 to 500 [mm/min]	200
,,	Z	1331.2		•	•	•	•	•	•		200
	IV	1331.3		•	•	•	•	•		rotary axis:	200
	V	1331.4		•	•	•	•	•	•	10 to 500 [°/min]	200
Axis sequence for reference mark traverse										0 = no ref. mark traverse	
1. axis		1340.0		•	•	•	•	•	•	1 = X	1
2. axis		1340.1		•	•	•	•	•	•	2 = Y	2
3. axis		1340.2		•	•	•	•	•		3 = Z	3
4. axis		1340.3		•	•	•	•	•	•	4 = IV	4
5. axis		1340.4		•	•	•	•	•	•	5 = V	5
Selecting the functional procedure for										0 = position encoder with distance-coded	
passing over the reference marks	Χ	1350.0		•	•	•	•	•		reference marks (1. mode)	1
passing over the reference marks	Y	1350.1		•	•	•	•	•		1 = position encoder without distance-coded	1
	Ż	1350.2		•	•	•	•	•		reference marks	1
	ΙV	1350.3		•	•	•	•	•		2 = special function (linear measurement	1
	V	1350.4			•	•	•	•		with rotary encoder)	1
	•			•	•	•	•	•	•	3 = position encoder with distance-coded	,
										reference marks (2. mode)	

1.0 TNC 407/415 Machine Parameters MP 1320 - MP 1350.4 16.01.95 10.2 12

Function		No.	MP Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Feed forward control or trailing mode in the operating modes "Positioning with MDI" "Program Run / Single Block" "Program Run / Full Sequence"		1390		•	•	•	•	•	•	0 = feed forward control 1 = trailing mode	0
Feed forward control in all operating modes	X Y Z IV V	1391	0 1 2 3 4	-	-	-	-	-	02	bit not set: control in the operating modes "Positioning with MDI", "Program Run / Single Block" and "Program Run / Full Sequence" according to MP1390 bit set: feed forward control in all operating modes	% 00000

Operation with Feed Forward Control

Function		MP	1	Y E	В	С	D	Е	F	Input	AE-6
		No. Bi	t								Entry Value
Position monitoring during											
operation with feed forward cont	peration with feed forward control			• •	•					0.001 to 30 [mm]	
erasable (POSITIONING ERROR)	X	1410.0		- -	-	-	-	-	-	0.0001 to 30 [mm]	3
	Υ	1410.1		- -	-	•	•	•	•		3
	Z	1410.2		- -	-	•	•	•	•		3
	IV	1410.3		- -	-	•	•	•	•		3
	V	1410.4		- -	-	•	•	•	•		3
EMERGENCY STOP											
(GROSS POSITIONING ERROR)		1420		• •	•					0.001 to 30 [mm]	
	X	1420.0		- -	-	-	-	-	-	0.0001 to 30 [mm]	4
	Υ	1420.1		- -	-	•	•	•	•		4
	Z	1420.2		- -	-	•	•	•	•		4
	IV	1420.3		- -	-	•	•	•	•		4
	V	1420.4		- -	-	•	•	•	*		4

1.0 TNC 407/415 **Machine Parameters** MP 1390 - MP 1420.4 16.01.95 10.2 13

Cams for "Reference End Position":

The reference marks can either be traversed manually using the axis direction keys or automatically with the start key. It is not necessary to enter a code number for the manual traverse as was the case with preceding TNC models. The traverse direction for automatic traverse of the reference marks is defined in MP1320. In order to reverse the traverse direction at the end of the traverse range, a cam for "reference end position" is required. The trigger signals "ref. end position" are assigned to free PLC inputs. By the PLC software these PLC inputs are connected to the PLC markers M2506 and M2556 to M25599. Depending on the entry value of MP1350 the TNC behaves differently.

Linear Encoder with Distance-Coded Reference Marks (MP 1350.X = 0). Mode 1

If the trigger signal "ref. end position" is set when starting reference mark traverse, the axis moves in the direction opposite to that set in the MP1320. If the trigger signal "ref. end position" is only set during automatic traverse, the TNC ignores this signal. Thus, there must be at least two reference marks within the range of the "reference end position". Ref. mark evaluation takes place either in the range of the "ref. end position" or else beyond this range. In case of an evaluation beyond the software limit switch range, the axis automatically moves to the software limit switch after evaluation.

Linear Encoder without Distance-Coded Reference Marks (MP 1350.X = 1)

The traverse direction is automatically reversed, if the axis traverses the cam for "ref. end position". If the axis is already in the range of the "reference end position" range when starting, it moves immediately in the opposite direction. For this reason the reference mark has to be outside the "ref. end position" range.

Special Operation: Linear Measurement with a Rotary Encoder (MP1350.X = 2)

The axis automatically moves to the cam for "reference end position" at the defined feed rate (MP1330). This axis is started again at a reduced feed rate (MP1331) in the opposite direction; the first reference mark is evaluated after the end of the "reference end position" range has been reached. Then the axis is stopped. If the axis is already in the "reference end position" range when starting, it moves immediately at the reduced feed rate (MP1331) in the direction opposite to that indicated in MP1320.

Linear Encoder with Distance-Coded Reference Marks (MP1350.X = 3), Mode 2

If the trigger signal "reference end position" is set during reference mark traverse, the axis moves opposite to the direction defined in MP1320. The signal "ref. end position" is not ignored by the NC. it is only set during automatic traverse. The traverse direction is reversed immediately. Thus, no reference marks are required in the "ref. end position" range.

Machine Parameters MP 1350.X 16.01.95

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
1. block of Kv factors	Χ	1510.0	•	•	•	•	•	•	0.1 to 20	1
for operation with feed forward	Υ	1510.1	•	•	•	•	•	•		1
control	Ζ	1510.2	•	•	•	•	•	•		1
	IV	1510.3	•	•	•	•	•	•		1
	V	1510.4	•	•	•	•	•	•		1
Stiction compensation	Χ	1511.0	-	-	-	-	•	•	0 to 16 777 215 [μs]	0
Duration of stiction compensation	Υ	1511.1	-	_	-	-	•	•	·	0
(differential part)	Ζ	1511.2	-	-	-	-	•	•		0
·	IV	1511.3	-	-	-	-	•	•		0
	V	1511.4	-	-	-	-	•	•		0
Limitation of stiction compensation	X	1512.0	-	-	-	-	•	•	0 to 16 777 215 [counting steps]	0
(differential part)	Υ	1512.1	_	-	-	_	•	•		0
,	Z	1512.2	_	-	-	_	•	•		0
	IV	1512.3	_	-	-	_	•	•		0
	V	1512.4	-	_	-	-	•	•		0
Feed rate for stiction compensation	X	1513.0	-	-	-	-	•	•	0 to 300 000 [mm/min]	0
(differential part)	Υ	1513.1	_	_	_	_	•	•	, ,	0
,	Ζ	1513.2	_	-	-	_	•	•		0
	IV	1513.3	-	-	-	-	•	•		0
	V	1513.4	-	-	-	-	•	•		0
2. block of Kv factors	Х	1515.0	-	-	-	-	•	•	0.1 to 10	1
for operation with feed forward	Υ	1515.1	-	_	-	-	•	•		1
control	Ζ	1515.2	-	-	-	-	•	•		1
M105: enable	IV	1515.3	-	-	-	-	•	•		1
M106: disable	V	1515.4	-	-	-	-	•	•		1
Approach speed and transient		1520	•	•	•	•	-	-	0.1 to 10 [m/min]	1
behaviour when accelerating									. , .	
Velocity below which the	Χ	1525.0	-	-	-	-	-	02	0.1 to 10.000 [mm/min]	0
positioning window is monitored	Υ	1525.1	_	_	-	_	-	02		0
	Ζ	1525.2	-	-	-	-	-		recommended value: 0.5 mm/min	0
	IV	1525.3	-	-	-	-	-	02	·	0
	V	1525.4	_	_	_	_	_	02		0

1.0 TNC 407/415 Machine Parameters MP 1510.0 - MP 1525.4 16.01.95

10.2 15

RH

Operation with Servo Lag

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Position monitoring during										
operation with servo lag		1710	•	•					0 to 100 [mm]	
cancellable (POSITIONING ERROR)	X	1710.0	-	-	-	-	-	-	0 to 300 [mm]	20
	Υ	1710.1	-	-	•	•	•	•		20
	Z	1710.2	-	-	•	•	•	•		20
	IV	1710.3	_	_	•	•	•	•		20
	V	1710.4	-	-	•	•	•	•		20
EMERGENCY STOP			1							
(GROSS POSITIONING ERROR)		1720	•	•					0 to 100 [mm]	
(2	Χ	1720.0	_	-	_	_	_	_	0 to 300 [mm]	30
	Y	1720.1	_	_	•	•	•	•		30
	Z	1720.2	_	_	•	•	•	•		30
	١٧	1720.3	_	_	•	•	•			30
	V	1720.4	-	-	•	•	•	•		30
1. block of Kv factors										
for the trailing mode	Χ	1810.0	•	•	•	•	•	•	0.1 to 10	1
Tor the truning mode	Y	1810.1	•	•	•	•	•	•	0.1 to 10	
	Ż	1810.2								
	IV	1810.3	•	•	•	•	•	•		
	V	1810.4	•	*	•	•	•	•		'1
	V	1610.4	•	•	•	•	•	*		
2. block of Kv factors for the										
trailing mode	X	1815.0	_	-	-	-	•	•	0.1 to 10	1
M105: enable	Υ	1815.1	_	-	-	-	•	•		1
M106: disable	Z	1815.2	_	_	_	_	•	•		1
	IV	1815.3	_	_	_	_	•	•		1
	V	1815.4	_	_	_	_	•	•		1
								•		

1.0 TNC 407/415 Machine Parameters MP 1710.0 - MP 1815.4 16.01.95 10.2 16

Function	M	ΙP	Α	В	С	D	E	F	Input	AE-6
	No.	Bit								Entry Value
Multiplication factor Kv										
(not effective with M05)	1820		•	•					0.001 to 1.000	
X	1820.0		-	-	-	-	-	-		1
Υ	1820.1		-	-	•	•	•	•		1
Z	1820.2		-	-	•	•	•	•		1
IV	1820.3		-	-	•	•	•	•		1
V	1820.4		-	-	•	•	•	•		1
Kink point										
•	1830		•	•					0 to 100.000 [%]	
X	1830.0		-	-	-	-	-	-		100
Υ	1830.1		-	-	•	•	•	•		100
Z	1830.2		-	-	•	•	•	•		100
IV	1830.3		-	-	•	•	•	•		100
V	1830.4		-	-	•	•	•	•		100

RH
1.0 TNC 407/415 Machine Parameters MP 1820.0 - MP 1830.4 16.01.95 10.2 17

Spindle

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Output of the spindle speed	3010	*	*	*	•	•	•	0 = spindle speed not output	6
coded								1 = only if speed changes 2 = with every TOOL CALL	
analogue								 3 = gear switching signal only if gear range changes 4 = gear switching signal with every TOOL CALL 5 = no gear switching signal 	
regulated spindle for orientation								6 = gear switching signal only if gear range changes 7 = gear switching signal with every TOOL CALL 8 = no gear switching signal	
Output of an analogue voltage at the analogue output of the spindle (only if MP3010 < 3)	3011			-		* *	*	0 = no function 1 = voltage is proportional to the current feed rate 2 = voltage defined via PLC (module 9130) 3 = voltage defined via M-function (M200 - M204)	0
Feed rate that corresponds to an analogue voltage of 10V (only if MP3011 = 1)	3012	-	-	-	-	•	•	0 to 300 000 [mm/min]	0

1.0 TNC 407/415 **Machine Parameters** MP 3010 - MP 3012 08.05.95 10.2 18

Function	MP	Α	В	С	D	Е	F	Input	AE-6
	No. Bit							-	Entry Value
LASER function with M202								10 to 300 000 [mm/min]	-
Characteristic curve kink points	3013.0	-	-	-	-	-	•		0
Speed	3013.1	-	-	-	-	-	•		0
•	3013.2	-	-	-	-	-	•		0
	3013.3	-	-	-	-	-	•		0
	3013.4	-	-	-	-	-	•		0
	3013.5	-	_	-	-	-	•		0
	3013.6	-	_	-	-	-	•		0
	3013.7	-	_	-	-	-	•		0
	3013.8	-	_	-	-	-	•		0
	3013.9	_	_	_	_	_	•		0
	3013.10	_	_	_	_	_	•		0
	3013.11	-	-	-	-	-	•		0
Characteristic curve kink points									
Voltage	3014.0	-	-	-	-	-	•		0
	3014.1	-	-	-	-	-	•		0
	3014.2	-	-	-	-	-	•		0
	3014.3	-	-	-	-	-	•		0
	3014.4	-	-	-	-	-	•		0
	3014.5	-	-	-	-	-	•		0
	3014.6	-	-	-	-	-	•		0
	3014.7	-	_	-	-	-	•		0
	3014.8	_	_	_	_	_	•		0
	3014.9	_	_	-	-	_	•		0
	3014.10	_	_	-	-	-	•		0
	3014.11	-	-	-	-	-	•		0
Limitation of speed code	3032	04	•	*	*	*	*	0 to 99 999	00991
								00991 = no limitation	

1.0 TNC 407/415 Machine Parameters MP 3013 - MP 3020 16.01.95 10.2 19

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Axis standstill, if only a spindle speed is output during a TOOL CALL		3030	٠	٠	٠	٠	٠	٠	0 = axis standstill 1 = no axis standstill	0
Programming the spindle speed S = 0 (if MP3240.1 ≠ 0)		3120	٠	٠	٠	•	•	•	$0 \rightarrow S = 0$ permitted $1 \rightarrow S = 0$ not permitted	0
Polarity of S-analogue voltage		3130	*	•	•	•	•	•	0 = M03: positive voltage M04: negative voltage 1 = M03. negative voltage M04: positive voltage 2 = M03 / M04: positive voltage 3 = M03 / M04: negative voltage	0
Counting direction of the spindle encoder		3140	٠	٠	٠	٠	•	٠	0 = positive 1 = negative	0
S-analogue voltage with nominal									0 to 9.999 [V]	
speed gear range	1	3210.0	•	•	٠	•	•	•		9
gear range	2	3210.1	•	•	•	•	•	•		9
gear range		3210.2	•	•	•	•	•	•		9
gear range		3210.3	•	•	•	•	•	•		9
gear range		3210.4	•	•	•	•	•	•		9
gear range		3210.5	•	•	•	•	•	•		9
gear range		3210.6	•	•	•	•	•	•		9
gear range	8	3210.7	•	•	•	•	•	•		9
Controlled range for S-analogue output									0 to 9.999 [V]	
Max. S-analogue voltage that can be output		3240.0	•	•	-	-	-	-		
Min. S-analogue voltage that can be output		3240.1	-	-	•	•	•	•		0
Jog voltage for gear change (markers for direction of rotation: M2490 / M2491)		3240.2	•	•	•	•	•	•		0.1
Limit with S-override m	nax.	3310.0	•	٠	٠	•	•	•	0 to 150 [%]	150
m	nin.	3310.1	•	•	•	•	•	•		0

1.0 TNC 407/415 Machine Parameters MP 3030 - MP 3310.1 16.01.95 10.2 20

Function			MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Ramp gradient of th	ne spindle:									0 to 1.999 [V/ms]	
• Spindle ON/OFF, M03	3, M04, M05;		3410 3410.0	- •	103 03	- ◆	- ◆	- ◆	- •		0.1
Oriented spindle stop; "Tagging of a selection of the stop of the selection of the se	,		3410.1 3410.2	• 08	03 11	*	*	•	•		0.1 0.1
"Tapping" cycle;			3410.3	_	_	•	•	•	•		0.1
• "Rigid Tapping" cycle			3410.3								0.1
Positioning window	for the spindle		3420	+	+	+	+	*	•	0 to 65 535 [increments]	10
Spindle preset			3430	•	•	•	•	•	•	0 to 360 [°]	0
Kv factor for the sp	indle									0.1 to 10	
(per gear range)	gear range	1	3440.0	•	•	•	•	•	•		1
	gear range	2	3440.1	•	•	•	•	•	•		1
	gear range	3	3440.2	•	•	•	•	•	•		1
	gear range	4	3440.3	•	•	•	•	•	•		1
	gear range	5	3440.4	•	•	•	•	•	•		1
	gear range	6	3440.5	•	•	•	•	•	•		1
	gear range	7	3440.6	•	•	•	•	•	•		1
	gear range	8	3440.7	•	•	•	•	•	•		1

RH
1.0 TNC 407/415 Machine Parameters MP 3410 - MP 3440.7 16.01.95 10.2 21

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Nominal spindle speed									0 to 99 999.999 [rpm]	
gear range	1	3510.0	•	•	•	•	•	•		1000
gear range	2	3510.1	•	•	•	•	•	•		2000
gear range	3	3510.2	•	•	•	•	•	•		3000
gear range	4	3510.3	•	•	•	•	•	•		4000
gear range	5	3510.4	•	•	•	•	•	•		5000
gear range	6	3510.5	•	•	•	•	•	•		6000
gear range	7	3510.6	•	•	•	•	•	•		7000
gear range	8	3510.7	•	•	•	•	•	•		8000
Maximum spindle speed									0 to 99 999 [rpm]	
gear range	1	3515.0	_	_	•	•	•	•		1200
gear range		3515.1	_	_	•	•	•	•		2400
gear range		3515.2	_	_	•	•	•	•		3600
gear range		3515.3	_	_		•				4800
gear range		3515.4	_	_		•				6000
gear range		3515.5	_	_	·	•	•			7200
gear range		3515.6	_	_	·	•				8400
gear range		3515.7	-	-	•	•	•	•		9600
Spindle speed if marker 2501		3520.0	•	•	•	•	•	•	0 to 99 999.999 [rpm]	
is set									direction of rotation always positive	200
Spindle speed for oriented spindle stop		3520.1	•	٠	•	•	•	•	0 to 99 999.999 [rpm]	100

RH
1.0 TNC 407/415 Machine Parameters MP 3510.0 - MP 3520.1 08.05.95 10.2 22

Integral PLC

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
PLC program from RAM or EPRON	Л	4010	•	•	٠	•	٠	•	+0 = EPROM	-
									+1 = RAM	0
Automatic lubrication	Χ	4060.0	•	•	•	•	•	•	0 to 65 535 [65 536 μm]	100
	Υ	4060.1	•	•	•	•	•	•		200
	Z	4060.2	•	•	•	•	•	•		300
	IV	4060.3	•	•	•	•	•	•		400
	V	4060.4	•	•	•	•	•	•		0
Maximum change of the										
temperature compensation per Pl scan in the PLC words W576 - W5		4070	-	_	03	03	•	•	0.0001 to 0.0005 [mm]	0.0001

1.0 TNC 407/415 Machine Parameters MP 4010 - MP 4070 16.01.95 10.2 23

Functio	n	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
PLC:	time for	110.							0 to 65 535 [PLC cycles]	
0.	T 0 - 29	4110.0	•	•	•	•	•	•	0 to 00 000 [1 20 0yoloo]	100
	. 5 25	4110.1	•	•	•	•	•	•		22
		4110.2	•			•	•			50
		4110.3	•	•	•	•	•	•		100
		4110.4	•	•	•	•	•	•		4
		4110.5	•	•	•	•	•	•		5
		4110.6	•	•		•	•	•		6
		4110.7	•	•		•	•	•		7
		4110.8	•	•	•	•	•	•		8
		4110.9	•	•	•	•	•	•		5 6 7 8 9
		4110.10	•	•	•	•	•	•		10
		4110.11	•	•	•	•	•	•		11
		4110.12	•	•	•	•	•	•		12
		4110.13	•	•	•	•	•	•		13
		4110.14				•	•			14
		4110.15	•			•	•	•		15
		4110.16	•	•	•	•	•	•		25
		4110.17		•	•	•	•	•		0
		4110.18	•		•	•	•	•		0
		4110.19	•	•	•	•	•	•		0
		4110.20	•	•	•	•	•	•		0
		4110.21	•	•	•	•	•	•		0
		4110.22			•	•	•	•		0 0 0 0
		4110.23	•	•		•	•	•		0
		4110.24	•	•	•	•	•	•		0
		4110.25	•	•	•	•	•	•		0
		4110.26	•	•	•	•	•	•		0
		4110.27	•	•		•	•	•		0
		4110.28	•			•	•			0
		4110.29	•	•	•	•	•	•		0
			•	•	•	•	•	•		

RH
1.0 TNC 407/415 Machine Parameters MP 4110.1 - MP 4110.29 16.01.95 10.2 24

Functio	n	МР	A	В	С	D	E	F	Input	AE-6
		No. Bit								Entry Value
PLC:	time for								0 to 65 535 [PLC cycles]	
	T 30 - 47	4110.30	•	•	•	•	•	•		0
		4110.31	•	•	•	•	•	•		0
		4110.32	•	•	•	•	•	•		0
		4110.33	•	•	•	•	•	•		0
		4110.34	•	•	•	•	•	•		0
		4110.35	•	•	•	•	•	•		0
		4110.36	•	•	•	•	•	•		0
		4110.37	•	•	•	•	•	•		0
		4110.38	•	•	•	•	•	•		0
		4110.39	•	•	•	•	•	•		0
		4110.40	•	•	•	•	•	•		0
		4110.41	•	•	•	•	•	•		0
		4110.42	•	•	•	•	•	•		0
		4110.43	•	•	•	•	•	•		0
		4110.44	•	•	•	•	•	•		0
		4110.45	•	•	•	•	•	•		0
		4110.46	•	•	•	•	•	•		0
		4110.47	•	•	•	•	•	•		0
PLC:	preset counter values								0 to 65 535 [PLC cycles]	
	counters 0 - 10	4120.0	•	•	•	•	•	•		0
		4120.1	•	•	•	•	•	•		1
		4120.2	•	•	•	•	•	•		2
		4120.3	•	•	•	•	•	•		3
		4120.4	•	•	•	•	•	•		4
		4120.5	•	•	•	•	•	•		5
		4120.6	•	•	•	•	•	•		2 3 4 5 6 7
		4120.7	•	•	•	•	•	•		7
		4120.8	•	•	•	•	•	•		8
		4120.9	•	•	•	•	•	•		9
		4120.10	•	•	•	•	•	•		10
				•						

RH
1.0 TNC 407/415 Machine Parameters MP 4110.30 - MP 4120.10 16.01.95 10.2 25

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
PLC: preset counter values								0 to 65 535 [PLC cycles]	,
counters 11 - 31	4120.11	•	•	•	•	•	•	, -	11
	4120.12	•	•	•	•	•	•		12
	4120.13	•	•	•	•	•	•		13
	4120.14	•	•	•	•	•	•		14
	4120.15	•	•	•	•	•	•		15
	4120.16	•	•	•	•	•	•		16
	4120.17	•	•	•	•	•	•		17
	4120.18	•	•	•	•	•	•		18
	4120.19	•	•	•	•	•	•		19
	4120.20	•	•	•	•	•	•		20
	4120.21	•	•	•	•	•	•		21
	4120.22	•	•	•	•	•	•		22
	4120.23	•	•	•	•		•		23
	4120.24	•	•	•	•		•		24
	4120.25	·	•	•	•		•		25
	4120.26	•	•	•			•		26
	4120.27	·	•				•		27
	4120.28	•	•	•		•	•		28
	4120.29		•	•	•	•	•		29
	4120.30								30
	4120.31	* •	•	•	•	•	•		31
		•	*	•	•	•	•		
Fast PLC input		_	_	•	•	•	•	0 to 254	0
Defining the fast input	4130								
O									
Defining the active level of the fast input	4131	_	-	•	•	•	•	0 = activation with LOW level	0
								1 = activation with HIGH level	

Function		MP	Α	В	С	D	E	F	Input	AE-6
		No. Bit								Entry Value
Setting a number									-99 999.9999 to +99 999.9999 [mm] or [°]	
	D768	4210.0	•	•	•	•	•	•		+10
	D772	4210.1	•	•	•	•	•	•		+1
	D776	4210.2	•	•	•	•	•	•		+2
	D780	4210.3	•	•	•	•	•	•		+3
	D784	4210.4	•	•	•	•	•	•		+4
	D788	4210.5	•	•	•	•	•	•		+5
	D792	4210.6	•	•	•	•	•	•		+6
	D796	4210.7	•	•	•	•	•	•		+7
	D800	4210.8	•	•	•	•	•	•		+8
	D804	4210.9	•	•	•	•	•	•		+9
	D808	4210.10	•	•	•	•	•	•		+10
	D812	4210.11	•	•	•	•	•	•		+11
	D816	4210.12	•	•	•	•	•	•		+12
	D820	4210.13	•	•	•	•	•	•		+13
	D824	4210.14	•	•	•	•	•	•		+14
	D828	4210.15	•	•	•	•	•	•		+15
	D832	4210.16	•	•	•	•	•	•		+16
	D836	4210.17	•	•	•	•	•	•		+17
	D840	4210.18	•	•	•	•	•	•		+18
	D844	4210.19	•	•	•	•	•	•		+19
	D848	4210.20	•	•	•	•	•	•		+20
	D852	4210.21	•	•		•	•	•		+21
	D856	4210.22	•	•	•	•	•	•		+22
	D860	4210.23	•	•			•	•		+23
	D864	4210.24	•	•			•	•		+24
	D868	4210.25	•	•		•	•	•		+25
	D872	4210.26	•	•		•	•	•		+26
	D876	4210.27	•	•			•	•		+27
	D880	4210.28	•	•			•	•		+28
	D884	4210.29	•	•			•	•		+29
	D888	4210.30	•	•			•	•		+30
	D892	4210.31	•	•			•	•		+31
			•	•	•	•	•	•		

RH
1.0 TNC 407/415 Machine Parameters MP 4210.0 - MP 4210.31 16.01.95 10.2 27

Function			MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Setting a number		D896 D900 D904 D908 D912 D916 D920 D924 D928 D932 D936 D940 D944 D948	4210.32 4210.33 4210.34 4210.35 4210.36 4210.37 4210.38 4210.49 4210.40 4210.41 4210.42 4210.43 4210.44 4210.45	•	•	•	•	•	•	-99 999.9999 to +99 999.9999 [mm] or [°]	+0 +0 +0 +0 +0 +0 +0 +0 +0 +0 +0 +0 +0
Machine parameters with multiple functions	W960	D952 D956	4210.46 4210.47 4220.0	•	•	*	*	•	•	10 to 30 000 • setting a value in the PLC	+0 +0
manipie functions	W962 W964 W966 W968	Y Z IV V	4220.1 4220.2 4220.3 4220.4	•	• • •	* * *	•	* * *	• •	setting a value in the FLC or feed rate for reapproching the contour [mm/min] or [°/min]	1800 1800 1800 1800
Setting a number (readable with module 90	32)		4230.0 4230.31		- -	06 06	06 06	* 	• 	-99 999.9999 to +99 999.9999 [mm]	0 0

1.0 TNC 407/415 **Machine Parameters** MP 4210.32 - MP 4230.31 16.01.95 10.2 28

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
PLC: setting a number	4231.0	-	-	06	06	•	•	-99 999.9999 to +99 999.9999 [mm]	0
(readable with module 9032)									
	4231.31	-	-	06	06	•	•		0
PLC: setting a number								-99 999.9999 to +99 999.9999 [mm]	
W976 (M2192 2207	4310.0	•	•	•	•	•	•		20480
W978 (M2208 2223	4310.1	•	•	•	•	•	•		0
W980 (M2224 2239	4310.2	•	•	•	•	•	•		0
W982 (M3200 3215	4310.3	•	•	•	•	•	•		0
W984 (M3216 3231	4310.4	•	•	•	•	•	•		0
W986 (M3232 3247	4310.5	•	•	•	•	•	•		0
W990 (M3248 3263	4310.6	•	•	•	•	•	•		0
Adaptation of the data interface	4410	1)	1)	03	03	-	-	0 = no analogue inputs	
extension (X47)								1 = analogue inputs on 1. PL	
								2 = analogue inputs on 2. PL	
	4410	1)	1)	03	03	٠	•		0
	0							+0 = no analogue inputs activated on 1. extension	
								+1 = analogue inputs on 1. extension (PA 100 or analogue inputs activated on PL 410)	
	1							+0 = no analogue inputs activated on 2. extension	
								+2 = analogue inputs on 2. extension (PA 100 or analogue inputs activated on PL 410)	

¹⁾ MP without function; therefore, do not enter 0.

1.0 TNC 407/415 **Machine Parameters** MP 4231.0 - MP 4410 16.01.95 10.2 29

Adaptation of the Data Interface

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Inhibiting a data interface	5000							0 = no interface inhibited 1 = RS-232 inhibited 2 = RS-422 inhibited	0
Control characters for "Blockwise Transfer" Character for beginning and end of program; the character of end of program is also valid for the standard data interface	5010.0*	105	108	-	-	-	-	0 to 32 382	515
ASCII character for data input	5010.1*	105	108	-	-	-	-	0 to 32 382	0
ASCII character for data output	5010.2*	105	108	-	-	-	-	0 to 32 382	0
ASCII character for beginning and end of command block	5010.3*	105	108	-	-	-	-	0 to 32 382	0
ASCII character for pos. and neg. acknowledgement	5010.4*	105	108	-	-	-	-	0 to 32 382	0
ASCII character for end of data transfer	5010.5*	105	108	-	-	-	-	0 to 32 382	0

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 5000 - MP 5010.5 08.05.95 10.2 30

Function	МР	Α	В	С	D	E	F	Input	AE-6
	No. Bit						-		Entry Value
Data format and transfer stop operating mode EXT operating mode EXT1 operating mode EXT2 operating mode EXT3 (PLC)	5020.0* 5020.1* 5020.2*	105 05 05 -		- •	- •	- •	- •	0 to 255	168 168 168
7 or 8 data bits	0							+0 = 7 data bits, bit 8 = parity +1 = 8 data bits, bit 8 = 0, bit 9 = parity	
Block check character	1							+0 = BCC may be any character +2 = control character not BCC	
Transfer stop by RTS	2							+0 = inactive +4 = active	
Transfer stop by DC3	3							+0 = inactive +8 = active	
Character parity even/odd	4							+0 = even +16 = odd	
Character parity on/off	5							+0 = off +32 = on	
Number of stop bits	6 7							+64 = bit 6 = 1 +128 = bit 7 = 1	
								bit 6 bit 7 0 1 = 1½ stop bits 1 0 = 2 stop bits 0 1 = 1 stop bit 1 1 = 1 stop bit	

^{*} accessible via code number 123

1.0 TNC 407/415 Machine Parameters MP 5020.0 - MP 5020.2 16.01.95 10.2 31

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Operating mode for										•
EXT		5030	105	108	-	-	-	-		
EXT1		5030.0*	05	80	•	•	•	•		1
EXT2		5030.1*	05	80	•	•	•	•	0 = standard data transfer	1
EXT3 (PLC)		5030.2*	-	-	•	•	•	•	1 = blockwise transfer	1
Transfer speed for PLC coupling (EXT3)		5040	-	-	*	•	*	•	0 to 9 0 = 110 Bd	7
Control characters for "Blockwise Transfer" ASCII character for beginning of	(OT) (I									
program	(STX)								0 to 127	
EXT1		5200.0*	05	08	•	•	•	•		0
EXT2		5200.1*	05	08			* *	* •		0
EXT3 (PLC)		5200.2*	-	-	L.	Ť				0
ASCII character for end of									0407	
program	/ET\/\	E004.0*	٥٦	00					0 to 127	
EXT1 EXT2	(ETX)	5201.0* 5201.1*	05	80	*	* *	* *	* *		0
EXT2 (PLC)		5201.1"	05	80			•			0
		3201.2	-	-						U
ASCII character for file type (for data transfer)									0 to 127	
EXT1		5202.0*	05	08	•	•	•	•	0 10 127	0
EXT2		5202.0	05	08			•	•		0
EXT3 (PLC)		5202.1*	05	- 08	•	•	•	•		0
ASCII character for input code		0202.2	ļ <u>-</u>	_					0 to 127	U
EXT1	(E)	5203.0*	05	08	•	•	•	•	0 10 127	0
EXT2	(⊏)	5203.0*	05	08			•	•		0
EXT2 (PLC)		5203.1*	05	Uδ			•	•		0
EATS (PLU)		0203.2"	-	_			<u> </u>			U

^{*} accessible via code number 123

1.0 TNC 407/415 Machine Parameters MP 5030.0 - MP 5203.2 08.05.95 10.2 32

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
ASCII character for file type									0 + 407	
(for data output)		F004.0*	٥٦	00					0 to 127	0
EXT1 EXT2		5204.0* 5204.1*	05	08	* *	* *	*	•		0
EXT2 (PLC)		5204.1*	05	08			•			0 0
		5204.2	-	-			-		0 to 127	0
ASCII character for output code EXT1	/ / / /	5205.0*	05	00	•	•	•		0 10 127	0
EXT2	(A)	5205.0*	05	08 08				•		0
EXT2 (PLC)		5205.1*	05	08	•					0
		5205.2"	-	-	Ť	Ľ	Ļ	ļ Ť		0
ASCII character for beginning of									0 += 107	
command block	(0011)	F000 0*	٥٦	00					0 to 127	
EXT1	(SOH)	5206.0*	05	08	•	•	•	*		0
EXT2		5206.1*	05	08		*	*	•		0
EXT3 (PLC)		5206.2*	-	-	•	Ľ	_	Ľ		0
ASCII character for end of										
command block									0 to 127	
EXT1	(ETB)	5207.0*	05	80	•	•	•	•		0
EXT2		5207.1*	05	80	•	•	•	•		0
EXT3 (PLC)		5207.2*	-	-	•	•	•	*		0
ASCII character for positive										
acknowledgement									0 to 127	
EXT1	(ACK)	5208.0*	05	80	•	•	•	•		0
EXT2		5208.1*	05	80	•	•	•	•		0
EXT3 (PLC)		5208.2*	-	-	•	•	•	*		0
ASCII character for negative										
acknowledgement									0 to 127	
EXT1	(NAK)	5209.0*	05	80	•	•	•	•		0
EXT2		5209.1*	05	80	•	•	•	•		0
EXT3 (PLC)		5209.2*	-		*	*	•	•		0
ASCII character for end of										
transfer									0 to 127	
EXT1	(EOT)	5210.0*	05	80	•	•	•	•		0
EXT2		5210.1*	05	08	•	•	•	•		0
EXT3 (PLC)		5210.2*	-	-	*	•	•	•		0

^{*} accessible via code number 123

3D-Touch Probe (General Parameters)

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Selection of touch trigger probe	6010*	٠	•	•	•	•	•	0 = transmission via cable (TS 120) 1 = infrared transmission (TS 510)	0
Probing feed rate	6120*	•	•	•	•	•	•	10 to 3 000 [mm/min]	80
Maximum measuring range	6130*	•	•	04	04	•	•	0.001 to 99 999.9999 [mm]	1
Safety clearance over measuring point for automatic measurement	6140*	•	•	•	•	•	•	0.001 to 99 999.9999 [mm]	1
Rapid traverse for probe cycle	6150*	•	•	•	•	•	•	10 to 10 000 [mm/min]	2000
M-function for rotating the spindle by 180° to compensate the center misalignment of the stylus	6160*	-	-	-	-	•	•	-1 = oriented spindle stop via NC 0 = function inactive 1 to 88 = number of M-function for oriented spindle stop via PLC	0

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 6010 - MP 6160 08.05.95 10.2 34

Digitizing with 3D-Touch Probe

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Number of oscillations in normal direction	6210	-	-	•	•	•	•	0 to 65.535 [1/sec]	0
Lubrication of touch probe axis displacement for lubrication at the end of a line	6220	-	-	-	-	-	•	0.000 to 999.999 [mm]	0
• time intervals for lubrication	6221	-	-	-	-	-	•	0 to 65 535 [min]	0
Feed rate in normal direction	6230	-	-	•	•	•	٠	0 to 1 000 [mm/min]	0
Maximum deflection of the stylus	6240	_	_	•	•	•	•	0 to 10 [mm]	0
Output of M90 on NC blocks of digitized data	6260	-	-	•	٠	٠	•	0 = no output 1 = output	0
Rounding the decimal places (NC blocks)	6270	-	-	•	•	•	٠	0 = output in 0.001 mm (1 μm) 1 = output in 0.01 mm (10 μm) 2 = output in 0.0001 mm (0.1 μm)	0

1.0 TNC 407/415 Machine Parameters MP 6210 - MP 6270 16.01.95 10.2 35

Tool Calibration with TT 110

Function	MP No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Tool calibration cycles	6500		-	-	-	-	-	•	0 = cycles inhibited 1 = cycles enabled	0
Probing direction for tool calibration	6505		-	-	-	-	-	٠	 0 = pos. probing direction in the angular reference axis (0° axis) 1 = pos. probing direction in the +90° axis 2 = neg. probing direction in the angular reference axis (0° axis) 3 = neg. probing direction in the +90° axis 	0
Calculation of probing feed rate	6507		-	-	-	-	-	٠	 0 = calculation of probing feed with constant tolerance 1 = calculation of probing feed with variable tolerance 2 = constant probing feed 	0
Maximum permissible measuring error when calibrating with a rotating tool	6510		-	-	-	-	-	•	0.002 to 0.999 [mm]	0.005
Probing feed rate when calibrating with a non-rotating tool	6520		-	_	-	_	-	•	10 to 3 000 [mm/min]	10
Distance between lower edge of tool and upper edge of stylus for tool radius calibration	6530		-	-	-	-	-	•	0.001 to 99.9999 [mm]	10
Diameter or edge length of the TT 110 stylus	6531		-	-	-	-	-	•	0.001 to 99 999.9999 [mm]	10

1.0 TNC 407/415 Machine Parameters MP 6500 - MP 6531 16.01.95 10.2 36

Function		MP No. I	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Safety zone around the stylus of TT 110 for prepositioning		6540		-	-	-	-	-	•	0.001 to 99 999.9999 [mm]	10
Rapid traverse in the probing cycle		6550		-	-	-	-	-	•	10 to 10 000 [m/min]	10
M-function for oriented spindle stop for measuring individual cutting edges		6560		-	-	-	-	-	•	-1 = oriented spindle stop via NC 0 = function inactive 1 to 88 = number of M-function for oriented spindle stop via PLC	10
Maximum permissible surface cutting speed at the cutting edges of the tool		6570		-	-	-	-	-	•	1.0000 to 120.0000 [m/min]	100
Center coordinates of the TT 110 stylus referenced to the machine datum	X Y Z	6580.0 6580.1 6580.2		1 1 1	- - -	- - -			* *	- 99 999.9999 to + 99 999.9999 [mm]	0 0 0

Tapping

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Minimum feed override when tapping	7110.0	•	•	•	•	•	•	0 to 150 [%]	95
Maximum feed override when tapping	7110.1	•	•	•	•	•	•	0 to 150 [%]	105
Dwell time for change of direction of spindle rotation in a tapping cycle	7120.0	٠	•	٠	•	٠	٠	0 to 65.535 [s]	0
Spindle deceleration time in a tapping cycle (only effective with BCD output of the spindle speed)	7120.1	•	•	•	•	•	•	0 to 65.535 [s]	0
Spindle slow-down time after reaching the total hole depth	7120.2	•	•	•	•	•	•	0 to 65.535 [s]	0
Tapping without floating tap holder • run-in behaviour of the spindle	7130	-	-	•	•	•	•	0.001 to 10 [°/min]	0.5
 transient response of the spindle during acceleration 	7140	-	-	•	•	•	•	0.01 to 0.999	0.15
Positioning window of the tool axis	7150	-	-	•	•	•	•	0.0001 to 2 [mm]	0.05
Spindle orientation at the beginning of cycle 17 "Rigid Tapping"	7160	-	-	-	-	08	•	0 = spindle orientation is executed 1 = spindle orientation is not executed	1

1.0 TNC 407/415 Machine Parameters MP 7110.0 - MP 7160 16.01.95 10.2 38

Display and Programming

Function		MF No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
		70404								0 = control	
Programming station		7210*		*	•	•	*	•	•	1 = programming station: PLC active 2 = programming station: PLC inact	
POWER INTERRUPTED		7212		_	-	_	-	•	•	0 = press [CE] to confirm the messa	
										1 = message is confirmed automati	•
Block-number increment size		7220*		08	80	•	•	+	•	0 to 250	
(for ISO programming)										0 = no generation	0
Maximum length of file names		7222*		-	-	-	-	•	•	0 = max. 8 characters	
when opening a file										1 = max. 12 characters	
										2 = max. 16 characters	
Disable file types		7224*		05	80	-	-	-	-	0 = no file type disabled	0
(for selection, table of contents and											
external data transfer)											
HEIDENHAIN programs	(.H)		0	05	80	-	-	-	-	+ 1 = disabled	
ISO programs	(.1)		1	05	80	-	-	-	-	+ 2= disabled	
Tool tables	(.T)		2	05	80	-	-	-	-	+ 4= disabled	
Datum tables	(.D)		3	05	80	-	-	-	-	+ 8= disabled	
Pallet tables	(.P)		4	05	08	-	-	-	-	+ 16= disabled	
ASCII (text) files	(.A)		5	05	08	-	-	-	-	+ 32= disabled	
Disable file types (for selection, table of contents and external data transfer)		7224.0*		-	-	•	•	•	•	0 = no file type disabled	% 00000000 (0)
HEIDENHAIN programs	(.H)		0	_	_	•	•	•	•	+ 1 = disabled	
ISO programs	(.11)		1	_		•	·		•	+ 2= disabled	
Tool tables	(.1) (.T)		2	_	_	·	•	•	•	+ 4= disabled	
Datum tables	(.T) (.D)		3	_	_	•	•	•	•	+ 8= disabled	
Pallet tables	(.D)		4	_	_	•	•	•	•	+ 16= disabled	
ASCII (text) files	(.A)		5	_	_	•	•	•	•	+ 32= disabled	
PLC HELP files	(., t, (.HLP)		6	_	-	_	_	08	•	+ 64= disabled	
Measuring point tables	(.PNT)		7	_	-	_	_	08	•	+ 128= disabled	

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 7210 - MP 7224.0 16.01.95 10.2 39

Display and Programming

Function		М	P	Α	В	С	D	E	F	Input	AE-6
		No.	Bit						_		Entry Value
Protecting file types		7224.1*								0 = no file type protected	% 00000000
(for selection, table of contents and											(O)
external data transfer)											
HEIDENHAIN programs	(.H)		0	-	-	•	•	•	•	+ 1 = protected	
ISO programs	(.1)		1	-	-	•	•	•	•	+ 2= protected	
Tool tables	(.T)		2	-	-	•	•	•	•	+ 4= protected	
Datum tables	(.D)		3	-	-	•	•	•	•	+ 8= protected	
Pallet tables	(.P)		4	-	-	•	•	•	•	+ 16= protected	
ASCII (text) files	(.A)		5	-	-	•	•	•	•	+ 32= protected	
PLC HELP files	(.HLP)		6	-	-	-	-	08	•	+ 64= protected	
Measuring point tables	(.PNT)		7	-	-	-	-	80	•	+ 128= protected	
Preset size											
Pallet table	(.P)	7226.0*		05	08	•	•	•	•	0 to 255 = number of reserved entries	10
Datum table	(.D)	7226.1*		05	80	•	•	•	•	(can be expanded via soft key)	10
Size of NC memory for											
DNC mode											
Minimum		7228.0		-	-	-	-	08	•	1 to 1024 [kBytes]	1
Maximum		7228.1		-	-	-	-	08	•	1 to 1024 [kBytes	10
Switching over the dialog		7230*		•	•	•	•	•	•	0 = first dialog language	0
language				`		`				1 = second dialog language (English)	

^{*} accessible via code number 123

1.0 TNC 407/415 Machine Parameters MP 7224.1 - MP 7230 08.05.95 10.2 40

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Inhibiting program entry if	7240*	•	•	•	•	•	٠	0 = inhibited	1
PGM No. = No. of OEM cycle								1 = not inhibited	
Inhibiting HEIDENHAIN cycles	7245.0	•	•	•	•	•	•	0 to 65 535	0
cycle 1	1							bit = $0 \rightarrow \text{cycle not inhibited}$	
cycle 2	2							bit = 1 \rightarrow cycle inhibited	
cycle 3	3								
cycle 4	4								
cycle 5	5								
cycle 6	6								
cycle 7	7								
cycle 8	8								
cycle 9	9								
cycle 10	10								
cycle 11	11								
cycle 12	12								
cycle 13	13								
cycle 14	14								
cycle 15	15								
	7245.1	•	•	•	•	•	٠	0 to 65 535	0
cycle 16	0							bit = $0 \rightarrow \text{cycle not inhibited}$	
cycle 17	1							bit = 1 \rightarrow cycle inhibited	
cycle 18	2							, sit is a significant of the si	
cycle 19	3								
cycle 20	4								
cycle 21	5								
cycle 22	6								
cycle 23	7								
cycle 24	8								
cycle 25	9								
cycle 26	10								
cycle 27	11								
cycle 28	12								
cycle 29	13								
cycle 30	14								
cycle 31	15								

1.0 TNC 407/415 **Machine Parameters** MP 7240 - MP 7245.1 16.01.95 10.2 41

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Disable paraxial positioning blocks with R+/R- compensation	7246	-	-	-	-	٠	٠	0 = enabled 1 = disabled	0
Difference between Q-parameter numbers for "DLG-DEF" block and "DLG-CALL" block in OEM cycle	7250	•	•	•	•	•	•	0 to 50 0 if "DLG-CALL" blocks only	0
Number of global Q-parameters that are transferred from an OEM cycle to the calling program	7251	•	•	•	•	•	•	0 to 100 40 = the Q-parameters Q60 to Q90 are global	0
Central tool table	7260*	•	•	*	•	•	•	0 to 254 0 = no central tool file entry value = number of tools	254
Number of tools with pocket number	7261*	•	•	•	•	•	•	0 to 254	254

^{*} accessible via code number 123

Machine Parameters MP 7246 - MP 7261 16.01.95 10.2 42

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
	e elements in to tool file are displayed and output via e								0 = no display 1 - 99 = position of the element in the tool table	0
NAME	(tool name)	7266.0	_	_	_	_	•	•	smallest value = first position	1
L	(tool length)	7266.1	-	-	-	-	•	•	highest value = last position	2
R	(tool radius 1)	7266.2	-	_	-	-	•	•		3
R2	(tool radius 2)	7266.3	_	-	-	-	•	•		4
DL	(tool length allowance)	7266.4	-	-	-	-	•	•		5
DR	(oversize tool radius 1)	7266.5	-	-	-	-	•	•		6
DR2	(oversize tool radius 2)	7266.6	-	-	-	-	•	•		7
TL	(tool locked)	7266.7	-	-	-	-	•	•		8
RT	(replacement tool)	7266.8	-	-	-	-	•	•		9
TIME1	(max. tool life)	7266.9	-	-	-	-	•	•		10
TIME2	(max. tool life with TOOL CALL)	7266.10	-	-	_	-	•	•		11
CUR. TIME	(current tool life)	7266.11	-	-	_	-	•	•		12
DOC	(commentary on tool)	7266.12	-	-	_	-	•	•		13
CUT	(number of cutting edges)	7266.13	-	-	-	-	_	•		14
LTOL	(tolerance for tool length)	7266.14	-	-	-	-	_	•		15
RTOL	(tolerance for tool radius)	7266.15	-	-	-	-	-	•		16
DIRECT	(cutting direction of tool)	7266.16	-	-	_	-	_	•		17
PLC	(PLC status)	7266.17	-	-	-	-	_	02		18
TT: L-OFFS	(tool offset, length)	7266.18	-	-	-	-	-	04		19
TT: R-OFFS	(tool offset, radius)	7266.19	-	-	-	-	_	04		20
LBREAK	(breakage tolerance, tool length)	7266.20	-	-	-	-	-	04		21
RBREAK	(breakage tolerance, tool radius)	7266.21	-	-	-	-	_	04		22
Selecting th	e elements in the TOOL.P								0 = no display	
file (pocket									1 - 99 = pos. of the element in the tool table	
T	(tool number)	7266.0	-	_	-	_	•	•	smallest value = first position	1
ST	(special tool)	7266.1	-	-	-	-	•	•	highest value = last position	2
F	(fixed pocket)	7266.2	-	_	-	-	•	•		3
L	(locked pocket)	7266.3	-	_	-	-	•	•		4
PLC	(PLC status)	7266.4	_	_	-	_	•	•		5

^{*} accessible via code number 123

1.0 TNC 407/415 Machine Parameters MP 7266.0 - MP 7267.4 08.05.95 10.2 43

Function	MP No. Bi		A	В	С	D	E	F	Input	AE-6 Entry Value
Display of the current feed rate in the TOOL.P file before start in the manual operating modes	7270*		•	•	•	•	•	•	0 = display of feed rate only when pressing an axis direction key (feed from MP1020.X individually for each axis) 1 = display of feed rate also before pressing an axis direction key (smallest value from MP1020.X for all axes)	0
Decimal sign	7280*		•	•	•	•	•	•	0 = decimal comma 1 = decimal point	0
Tool length in ACTL/NOML display	7285*		-	-	•	•	•	•	0 = ignored 1 = taken into account	0
Display step	7290		*	•	-	-	-	-	0 = 0.001 mm 1 = 0.005 mm	1
X	7290.0*		-	-	•	•	-	-	0 = 0.001 mm	0
Υ	7290.1*		-	-	•	•	-	-	1 = 0.005 mm	0
Z	7290.2*		-	-	•	•	-	-	$2 = 0.0001 \text{ mm}^{1)}$	0
IV	7290.3*		-	-	•	•	-	-		0
V	7290.4*		-	-	•	•	-	-		0
X	7290.0*		-	-	-	-	•	•	$0 = 0.1 \text{mm} / 0.1^{\circ}$	6
Υ	7290.1*		-	-	-	-	•	•	$1 = 0.05 \text{mm} / 0.05^{\circ}$	6
Z	7290.2*		-	-	-	-	•	•	$2 = 0.01 \text{ mm} / 0.01^{\circ}$	6
IV	7290.3*		-	-	-	-	•	•	$3 = 0.005 \text{mm} / 0.005^{\circ}$	6
V	7290.4*		-	-	-	-	•	•	4 = 0.001 mm / 0.001°	6
									$5 = 0.0005 \text{mm} / 0.0005^{\circ}$	
									6 = 0.0001 mm / 0.0001°	
Inhibiting datum setting	7295*		-	-	•	•	•	•	0 = entry not inhibited	0
(axis keys and soft keys) X)							+1 = X axis inhibited	
Y	1								+2 = Y axis inhibited	
Z	2								+4 = Z axis inhibited	
IV V	3								+8 = IV. axis inhibited	
-	7200	+					00	<u> </u>	+16 = V. axis inhibited	
Datum setting via axis keys	7296		-	-	-	-	80	•	0 = datum setting via axis keys and soft key 1 = datum setting with soft key only	0

^{*} accessible via code number 123

1) not with TNC 407

1.0 TNC 407/415 **Machine Parameters** MP 7270 - MP 7296 08.05.95 10.2 44

Function	M		A	В	С	D	E	F	Input	AE-6
Cancel status display and Q-parameters with M02, M30 and END PGM	No. 7300*	Bit	106	109	-	-	-	-	0 = status display and Q-parameters are not cancelled 1 = status display and Q-parameters are cancelled	O 0
Cancel status display and Q-parameters	7300								cancened	
cancel status display with M02, M30 and END PGM		0	06	09	•	•	-	-	+0 = status display is not cancelled +1 = status display is cancelled	
cancel Q-parameters when program is selected		1	06	09	•	•	-	-	+0 = Q-parameters are cancelled +2 = Q-parameters are not cancelled	
 Selective erasing of status data (S) TOOL data (T) Q-parameter values (Q) with M02, M30, END PGM 	7300	0 1 2	-	-	-	-	•	•	O to 7 end of program program selection 0 = S Q T 1 = 2 = S Q T - Q - 3 = - Q - - Q - 4 = S Q T T 5 = T T 6 = S Q T - Q T 7 = - Q T - Q T	0
Graphics display • view in three planes	7310*	0	•	•	•	•	•	•	+0 = German standard +1 = American standard	0
 rotating the coordinate system in the working plane 		1	•	•	•	•	•	•	+0 = no rotation +2 = coordinate system rotated by +90°	
BLK form after datum shift		2	-	-	-	-	•	•	+0 = BLK form is not shifted +4 = BLK form is shifted	
• show cursor position in "view in 3 planes"		3	-	-	-	-	•	•	+0 = cursor is not displayed +8 = cursor is displayed	

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 7300 - MP 7310 16.01.95

Function	М	_	Α	В	С	D	E	F	Input	AE-6
	No.	Bit								Entry Value
Graphic simulation of a process without										
TOOL CALL and without infeed movement in the										
operating modes "Program Run" and "Test Run"										
Tool radius	7315*		-	-	-	-	•	•	0 to 99 999 [mm]	0
Tool penetration depth	7316*		-	-	-	-	•	•	0 to 99 999 [mm]	0
(from upper edge of blank)										
M-function to start the simulation	7317.0*		-	-	-	-	•	•	0 to 88	0
M-function to interrupt the simulation	7317.1*		-	-	-	-	•	•	0 to 88	0

^{*} accessible via code number 123

Machine Parameters MP 7315 - MP 7317.1 08.05.95 10.2 46

Colours, General Display and FK-Graphics

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Background colour for soft keys, operating modes, dialog display,	NO. BIL								Entry Value
simulation, parallel graphics	7320.0	•	•	-	-	-	-	0 to 4095	0
Background of block display	7320.1	•	•	-	-	-	-	0 to 4095	538
Background of status factor	7320.2	•	•	-	-	-	-	0 to 4095	800
Background of FK-graphics	7320.3	•	•	-	-	-	-	0 to 4095	0
FK-graphics: resolved contour	7320.4	*	•	-	-	-	-	0 to 4095	4095
FK-graphics: subprograms	7320.5	•	•	-	-	-	-	0 to 4095	240
FK-graphics: alternative solutions	7320.6	•	*	-	-	-	-	0 to 4095	240
FK-graphics: non-resolved contour	7320.7	•	•	-	-	-	-	0 to 4095	3840
Window frames	7320.8	•	•	-	-	-	-	0 to 4095	3202
Operating mode display	7320.9	•	•	-	-	-	-	0 to 4095	3458
General block display	7320.10	•	•	-	-	-	-	0 to 4095	3731
Status display	7320.11	•	•	-	-	-	-	0 to 4095	4003
Axis display	7320.12	•	•	-	-	-	-	0 to 4095	4020
Display of current block	7320.13	•	•	-	-	-	-	0 to 4095	4055

1.0 TNC 407/415 Machine Parameters MP 7320.0 - MP 7320.13 16.01.95 10.2 47

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Dialog display, colour of soft key									-
symbols	7320.14	•	•	-	-	-	-	0 to 4095	4074
Error messages	7320.15	•	•	-	-	-	-	0 to 4095	4095
Colours for "3D-View"								0 to 4095	
upper edges	7321.0	•	•	-	-	-	-		2254
front surface	7321.1	•	•	-	-	-	-		872
symbols	7321.2	•	•	-	-	-	-		4095
right edges	7321.3	•	•	-	-	-	-		1162
Colours for "View in 3 Planes"								0 to 4095	
horizontal projection	7322.0	•	•	-	-	-	-		2254
vertical and side view	7322.1	•	•	-	-	-	-		2254
symbols and coordinate system	7322.2	•	•	-	-	-	-		872
cursor	7322.3	•	•	-	-	-	-		300
Colours for the status window								0 to 4095	
status elements	7323.0	05	08	-	-	-	-		4095
recognition texts	7323.1	05	80	-	-	-	-		240
separating line	7323.2	05	80	-	-	-	-		3840
no function	7323.3	05	08	-	-	-	-		0

1.0 TNC 407/415 **Machine Parameters** MP 7320.14 - MP 7323.3 16.01.95 10.2 48

User Parameters

Function		MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
USER parameters Determination of the user parameters	0 1 2 3 4 5	7330.0 7330.1 7330.2 7330.3 7330.4 7330.5 7330.6	* * * * * * * * * * * * * * * * * * *	•	* * * * * * * * * * * * * * * * * * *	•	* * *	* * *	0 to 9999.99 number of desired machine parameter NOTE: Always enter 2 decimal places: i.e. 110.10 (not: 110.1)	0 0 0 0 0 0
	7 8 9 10 11 12 13 14	7330.7 7330.8 7330.9 7330.10 7330.11 7330.12 7330.13 7330.14 7330.15	• • • • •	•	•	•	• • • •	•		0 0 0 0 0 0 0
Allocation of the dialogs to the user parameters	0 1 2 3 4 5 6 7 8	7340.0 7340.1 7340.2 7340.3 7340.4 7340.5 7340.6 7340.7 7340.8 7340.9	* * * * * * * * * * * * * * * * * * *	•	* * * * * * * * * * * * * * * * * * *	• • • • •	* * * * * * * * * * * * * * * * * * *	* * * * * * * * * * * * * * * * * * *	0 to 4095 0 = first line of the respective file	0 0 0 0 0 0 0 0

1.0 TNC 407/415 Machine Parameters MP 7330.0 - MP 7340.9 16.01.95 10.2 49

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
10	7340.10								0
		•	•	•	•	•	•		0
11	7340.11	•	•	•	•	•	•		0
12	7340.12	•	•	•	•	•	•		0
13	7340.13	•	•	•	•	•	•		0
14	7340.14	•	•	•	•	•	•		0
15	7340.15	•	•	•	•	•	•		0

Colours for General Display and FK-Graphics

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Window frames	7350	-	-	•	•	•	•	\$0000000 to \$03F3F3F	\$030200C
Error messages	7351	-	-	•	•	٠	٠	\$0000000 to \$03F3F3F	\$03F3F3F
Operating mode "Machine" background text of operating mode dialogs	7352.0 7352.1 7352.2		- - -	•	•	• •	• •	\$0000000 to \$03F3F3F	\$0000000 \$0342008 \$03F3828
Operating mode "Programming" background text of operating mode dialogs	7353.0 7353.1 7353.2			•	•	•	•	\$0000000 to \$03F3F3F	\$000000 \$0342008 \$03F3828

1.0 TNC 407/415 **Machine Parameters** MP 7340.10 - MP 7353.2 16.01.95 10.2 50

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Text display "Machine"	ito. Dit							\$0000000 to \$03F3F3F	Linery variation
background	7354.0	_	-	•	•	•	•	400000000000000000000000000000000000000	\$0080400
general program text	7354.1	_	_	•	•	•	•		\$038240C
current block	7354.2	_	_	•	•	•	•		\$038341C
background of current window	7354.3	-	-	•	•	•	104		\$00C0800
background of inactive window	7354.4	-	-	_	_	_	04		\$0040800
Text display "Programming"								\$0000000 to \$03F3F3F	
background	7355.0	-	-	•	•	•	•		\$0080400
general program text	7355.1	-	-	•	•	•	•		\$038240C
current block	7355.2	-	-	•	•	•	•		\$038341C
background of current window	7355.3	-	-	•	•	•	104		\$00C0800
background of inactive window	7355.4	-	-	-	-	-	04		\$0080400
Status and PLC window								\$0000000 to \$03F3F3F	
background	7355.0	-	-	•	•	•	•		\$00C0800
axis positions in status display	7355.1	-	-	•	•	•	•		\$03F2C18
status display (except axis pos.)	7355.2	-	-	•	•	•	•		\$03F280C
Soft keys "Machine"								\$0000000 to \$03F3F3F	
background	7357.0	-	-	•	•	•	•		\$000000
symbols	7357.1	-	-	•	•	•	•		\$03F3828
Soft keys "Programming"								\$0000000 to \$03F3F3F	
background	7358.0	-	-	•	•	•	•		\$000000
symbols	7358.1	-	-	*	•	•	*		\$03F3828
Graphics: 3D view								\$0000000 to \$03F3F3F	
background	7360.0	-	-	•	•	•	•		\$000000
surface	7360.1	-	-	•	•	•	•		\$0203038
front surface	7360.2	-	-	•	•	•	•		\$00C1820
text fields in the graphics window	7360.3	-	-	•	•	•	•		\$03F3F3F
lateral surface	7360.4	-	-	•	•	•	•		\$0102028

1.0 TNC 407/415 Machine Parameters MP 7354 - MP 7360.4 08.05.95 10.2 51

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Graphics: View in 3 planes								\$0000000 to \$03F3F3F	·
(and Oscilloscope)									
background	7361.0	-	-	•	•	•	•		\$000000
horizontal projection (grid)	7361.1	-	-	•	•	•	•		\$0203038
vertical and horizontal view (non-selected channel)	7361.2	-	-	*	*	•	•		\$0203038
coordinate system and texts in graphics display (cursor, data, detail)	7361.3	-	-	•	•	•	•		\$03F3F3F
cursor (selected channel)	7361.4	-	-	•	•	•	•		\$03F0000
Additional status display in graphics								\$0000000 to \$03F3F3F	
window									
background colour of status display	7362.0	-	-	•	•	-	-		
elements of status display	7362.1	-	-	•	•	-	-		
headlines of status display	7362.2	-	-	•	•	-	-		
separating lines	7362.3	-	-	•	•	-	-		
background of graphics window	7362.0	-	-	-	-	•	•	\$0000000 to \$03F3F3F	
background of status display	7362.1	-	-	-	-	•	•		\$0080400
symbols in status display	7362.2	-	-	-	-	•	•		\$00C0800
values in status display	7362.3	-	-	-	-	•	•		\$038240C
									\$03F2C18
FK graphics								\$0000000 to \$03F3F3F	
background colour	7363.0	-	-	•	•	•	•		\$000000
resolved contours	7363.1	-	-	•	•	•	•		\$03F3F3F
subprograms and zoom frame	7363.2	-	-	•	•	•	•		\$0003F00
alternative solutions	7363.3	-	-	•	•	٠	•		\$0003F00
non-resolved contours	7363.4	-	-	•	•	•	•		\$03F0000

1.0 TNC 407/415 **Machine Parameters** MP 7361 - MP 7363.4 16.01.95 10.2 52

Machining and Program Run

Function	MF No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Cycle "Scaling Factor" active in 2 or	7410*		•	•	•	•	*	+	0 = 3 axes	0
3 axes									1 = in the operating plane	
Tool data in TOUCH PROBE block	7411*		•	•	•	•	+	•	0 = the current tool data are overwritten with	0
									the calibrated touch probe data	
									1 = the current tool data are retained	
Cycle for milling pockets with	7420*		•	•	•	•	*	•	0 to 15	%0000
free-programmed contour										(O)
slot-milling direction		0							0 = ccw for milling pockets	
									cw for milling islands	
									1 = cw for milling pockets	
									ccw for milling islands	
 sequence for clearing out and slot 		1							0 = first slot-milling, then clear out pocket	
milling									2 = first clear out pocket, then slot-milling	
 merge programmed contours 		2							0 = contours are only merged, if the	
									tool center paths intersect	
									4 = contours are merged, if the	
									programmed contours overlap	
 "clearing out" and "slot milling" to 		3							0 = "clearing out" and "slot milling" in one	
pocket depth or individually for each									operation over all pecks	
peck									8 = for each peck "slot milling" is run	
									before "clearing out" (depending on bit 1)	

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 7410 - MP 7420 08.05.95 10.2 53

Function		MP No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Overlapping factor for pocket milling		7430*		•	•	•	+	•	•	0.1 to 1.414	1
Tolerance range for circle end point (linear contour)	t	7431*		-	-	•	•	•	•	0.0001 to 0.016 [mm]	0.01
Output of M-functions		7440*									
Programmed stop with M06			0	•	•	•	•	•	•	+0 = program halt with M06 +1 = no program halt with M06	%01011 (11)
Output of M98, modal cycle call			1	•	•	•	•	•	•	+0 = no cycle call, normal code transfer of M89 at beginning of block +2 = modal cycle call at end of block	
Axis standstill when an M-function is output Exception: axis standstill always occurs with M-functions that result in a programmed stop (e.g. M00, M02) or with a STOP or a CYCL CALL block	ut		2	•	•	•	•	•	•	+0 = program halt until acknowledgement of M-function +4 = no program halt, TNC does not wait for acknowledgement	
Select Kv factors with M105/M106			3	-	-	-	-	•	•	+0 = function not active +8 = function active	
Reduced feed rate in the tool axis with M103			4	-	-	-	-	•	•	+0 = function not active +16 = function active	
Position for tool exchange (from MP951.X) during block scan	X Y Z IV V	7450	0 1 2 3 4	-	-	09	09	08	•	0 = position ignored +1 = position of X axis taken into account +2 = position of Y axis taken into account +4 = position of Z axis taken into account +8 = position of IV. axis taken into account +16 = position of V. axis taken into account	%00000 (0)
Constant feed rate in corners		7460*		•	•	*	•	•	•	0 to 179.9999 [°]	10
Display mode and software limit switches for rotary axis		7470*		•	•	•	•	•	•	$0 = 0$ to $\pm 359.999^\circ$ (no software limit switch monitoring) $1 = 0$ to $\pm 99.999.999^\circ$	0

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 7430 - MP 7470 08.05.95 10.2 54

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Datum in datum table	7475	-	-	-	-	•	•	0 = datum point is workpiece datum 1 = datum point is machine datum	0
Output of tool number or pocket number								0 to 6	
with TOOL CALL block	7480.0	*	•	•	•	•	•	0 = no output 1 = output of tool number only when tool number changes (W262)	2
		•	•	•	•	•	•	2 = output of tool number with every TOOL CALL (W262)	
		•	•	•	•	•	•	3 = output of pocket number (W262) and tool number (W264) only when tool number changes	
		-	-	05	04	•	•	4 = output of pocket number (W262) and tool number (W264) with every TOOL CALL	
		-	-	-	-	08	•	5 = output of pocket number (W262) and tool number (W264); pocket table does not change.	
		-	-	-	-	08	•	6 = output of pocket number (W264) with every TOOL CALL; pocket table does not change.	

1.0 TNC 407/415 **Machine Parameters** MP 7475 - MP 7480.0 16.01.95 10.2 55

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
with TOOL DEF blocks (only if MP7260 > 0)	7480.1	•	•	•	•	٠	٠	0 = no output	2
		•	•	•	•	•	•	1 = output of tool number only when tool number changes (W262)	
		•	•	•	•	•	•	2 = output of tool number with every TOOL DEF (W262)	
		•	•	•	•	•	•	3 = output of pocket number (W262) and tool number (W264) only when tool number changes	
		-	-	05	04	•	•	4 = output of pocket number (W262) and too number (W264) with every TOOL DEF	ol
Number of traverse range	7490	05	08	•	•	•	•	0 = 1 range, 3 datum points	0
limitations		05	80	•	•	•	•	1 = 3 ranges, 3 datum points	
		-	-	-	-	08 08	•	2 = 1 range, 1 datum point 3 = 3 ranges, 1 datum point	

^{*} accessible via code number 123

1.0 TNC 407/415 **Machine Parameters** MP 7480.1 - MP 7490 16.01.95 10.2 56

Function	M No.	P Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Description of the swivel head										
geometry										
1. Parameter block										
Selection of the transformed axis	7510									
		0	-	-	-	-	80	•	0 to 63	0
		1							+1 = X-axis	
		2							+2 = Y-axis	
		3							+4 = Z-axis	
		4							+8 = A-axis	
		5							+16 = B-axis	
									+32 = C-axis	
Additional identifier for transformation	7511		-	-	-	-	80	•		0
		0							0 = swivel head	
									1 = tilting table	
		1							0 = incremental dimensions	
									(for swivel head)	
									1 = absolute dimensions, referenced to	
									the machine datum (for tilting table)	
Dimensions for transformation	7512		-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
									0 = swivelling axis	
2. Parameter block	7520		-	-	-	-	08	•	0 to 63	0
	7521		-	-	-	-	08	•	0 to 3	0
	7522		-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
3. Parameter block	7530		-	-	-	-	08	•	0 to 63	0
	7531		-	-	-	-	08	•	0 to 3	0
	7532		-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
4. Parameter block	7540		-	-	-	-	08	•	0 to 63	0
	7541		-	-	-	-	08	•	0 to 3	0
	7542		-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0

1.0 TNC 407/415 Machine Parameters MP 7510 - MP 7542 08.05.95 10.2 56.1

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
C. Danisas dan blask	1-01 -10							0.4- 00	
5. Parameter block	7550	-	-	-	-	80	•	0 to 63	0
	7551	-	-	-	-	80	•	0 to 3	0
	7552	-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
6. Parameter block	7560	-	-	-	-	08	•	0 to 63	0
	7561	-	-	-	-	08	•	0 to 3	0
	7562	-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
7. Parameter block	7570	-	-	-	-	08	•	0 to 63	0
	7571	-	-	-	-	08	•	0 to 3	0
	7572	-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
8. Parameter block	7580	-	-	-	-	08	•	0 to 63	0
	7581	-	-	-	-	08	•	0 to 3	0
	7582	-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0
9. Parameter block	7590	-	-	-	-	08	•	0 to 63	0
	7591	-	-	-	-	08	•	0 to 3	0
	7592	-	-	-	-	08	•	- 99 999.9999 to + 99 999.9999	0

Hardware

Function	No.	Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Feed rate and spindle override	7620									2
Feed rate override if the rapid traverse key is pressed in the operating mode "Program Run"		0	•	•	•	•	-	-	+0 = override inactive +1 = override active	
Override in 2% or 1% increments (if inactive, always 1%)		1	•	•	104	104	-	-	+0 = 2% steps +2 = 1% steps	
Feed rate override if the rapid traverse key and external direction keys are pressed in the "Manual" mode		2	•	•	•	•	-	-	+0 = override inactive +4 = override active	
Override in 0.01% increments with non- linear characteristic curve		3	-	-	02	02	-	-	+0 = override inactive +8 = 0.01% steps	
Feed rate and spindle override Feed rate override function if the rapid traverse key is pressed in the operating mode "Program Run"	7620	0	-	-	-	-	•	•	+0 = feed override inactive +1 = feed override active	%1101
 Feed override function in the MANUAL mode, if the rapid traverse key and external direction keys are pressed in the HANDWHEEL mode if the rapid traverse key and the direction key on the handwheel are pressed. 		2							+0 = feed override inactive +4 = feed override active	
Override, characteristic curve		3							+0 = feed and spindle override in 1% ster +8 = feed and spindle override in 0.01% and non-linear characteristic line	

RH
1.0 TNC 407/415 Machine Parameters MP 7620 16.01.95 10.2 57

Function	MP No. Bit	A	В	С	D	E	F	Input E	AE-6 Entry Value
Configuration of the handwheel	7640*	•	•	103	103	-	-	0 = machine with electronic handwheel 1 = machine without electronic handwheel	0
Configuration of the handwheel	7640*	-	-	03 03 03 -	03 03 03 -	•	* * * *	0 = no handwheel connected 1 = HR 330 (all keys via NC) 10 2 = HR 130, HR 330 (all keys via NC) 20 3 = HR 330 rapid traverse key: PLC I 162 plus key: PLC I 160 minus key: PLC I 161 4 = HR 332; evaluation of keys and LEDs depends on MP7645.0 5 = HRA 110, multi-axis handwheel (3 x HR 150)	0
		-	-	-	-	-	04	6 = HRA 410, evaluation of keys and LEDs depends on MP7645.0	
Entry of interpolation factor	7641	-	-	-	-	•	•	0 = at keyboard 1 = via PLC module 9036	0

^{*} accessible via code number 123

- 1) axis switchover with handwheel
- 2) axis switchover with handwheel or keyboard
- 3) If the HR 410 does not receive any initializing parameters (MP 7645.x) it automatically switches to HR 332 mode (MP 7640 = 4).

Machine Parameters MP 7640 - MP 7641 08.05.95 10.2 58

Function	MP No. Bit		A	В	С	D	E	F	Input	AE-6 Entry Value
Initalizing parameters for the handwheel Allocation of the 3rd handwheel via axis selector switch (MP7640 = 5)	7645.0 C		_	-	-	-	•	•	+0 = position 1 (left stop) → Z axis position 2 → IV. axis position 3 → V. axis +1 = position 1 → X axis position 2 → Y axis position 3 → Z axis position 4 → IV. axis	0
Evaluation of keys and LEDs on HR332 (MP7640 = 4) HR 410 in HR 332 mode (MP 7640 = 4)	2 - 7645.0	7 .		-	-	-	•	•	position 5 → V. axis +2 = position 3 → Z axis position 4 → IV. axis position 5 → V. axis reserved HR 332 0 = keys X, Y, Z, IV and their LEDs are evaluated by NC remaining keys: PLC I 164 to I 170 remaining LEDs: PLC O 100 to O 106 1 = keys: PLC I 160 to I 171 LEDs: PLC O 96 to O 107 HR 410 0 = keys X, Y, Z, IV and their LEDs are	0
HR 410 in HR 410 mode (MP 7640 = 6)	7645.0		-	-	-	-	*	•	evaluated by NC remaining keys: PLC I 164 to I 171 remaining LEDs: PLC O 100 to O 107 1 = keys: PLC I 160 to I 171 LEDs: PLC O 96 to O 107 0 = keys X, Y, Z, IV, V, actl. value transfer and their LEDs are evaluated by NC remaining keys: PLC I 168 to I 175 remaining LEDs: PLC O 100 to O 111 1 = keys: PLC I 168 to I 175 LEDs: PLC O 96 to O 111	0

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Allocation of the 3rd handwheel via machine parameter (MP7640 = 5)	7645.1	-	-	-	-	•	•	0 = simulation of the first position of the selector switch MP 7645.0 = 0 → Z axis MP 7645.0 = 1 → X axis +1 = X axis +2 = Y axis +4 = Z axis +8 = IV. axis +16 = V. axis	0
Select axis selection process (MP7640 = 5)	7645.2	-	_	-	-	•	•	0 = axis selection via axis selector switch according to MP 7645.0 1 = axis selection according to MP 7645.1	
reserved	7645.3 7645.7	-	-	-	-	•	•	no function	0

1.0 TNC 407/415 Machine Parameters MP 7645.1 - MP 7645.7 08.05.95 10.2 59.1

Function	MP No. Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Handwheel, counting direction	7650	•	•	•	•	•	•	0 = positive counting direction 1 = negative counting direction	0
Hysteresis for electronic handwheel	7660	•	•	•	•	•	•	0 to 65 535 [increments]	10
Handwheel, minimum interpolation factor	7670	•	•	•	•	•	104	0 to 10	0
Handwheel interpolation factor								0 to 10	
slow (HR 130/3xx/410)	7670.0	-	-	-	-	-	04		0
medium (HR 410 only)	7670.1	-	-	-	-	-	04		0
fast (HR 410 only)	7670.2	-	-	-	-	-	04		0
HR 410: %-factor of manual feed								0 to 100 [%]	
slow (HR 410 only)	7671.0	-	-	-	-	-	04		50
medium (HR 410 only)	7671.1	-	-	-	-	-	04		75
fast (HR 410 only)	7671.2	-	-	-	-	-	04		100

Function	No.	IP Bit	A	В	С	D	E	F	Input	AE-6 Entry Value
Multifunctional parameters	7680									%0011111 (31)
• memory function for axis direction keys		0	•	•	*	•	*	•	0 = not stored +1 = stored	
• re-approaching the contour		1	•	•	•	•	•	•	0 = inactive +2 = active	
• block scan		2	06	09	•	•	•	•	0 = inactive +8 = active	
• block scan interrupted by STOP or M06		3	09	12	•	•	•	•	0 = interruption active +16 = interruption inactive	
 with block scan in a TAPPING cycle, the dwell time to reverse the direction of rotation is waited to end 		4	19	12	•	•	•	•	0 = dwell time is waited to end +8 = dwell time is not waited to end	
• start of calculation with block scan		5	*	•	*	•	*	•	0 = start at cursor position +32 = start at beginning of program	
 tool length for blocks with surface normal vector 		6	-	-	-	-	-	•	0 = without DR2 from tool table +64 = with DR2 from tool table	
Memory test after power-on	7690		•	•	•	•	•	•	0 to 7	%11 (3)
RAM		0							+0 = test +1 = no test	(0)
EPROM		1							+0 = test +0 = test +2 = no test	

1.0 TNC 407/415 Machine Parameters MP 7680 - MP 7690 10.2 61 08.05.95