

11/06

Kundendienst/Service



Changes/Developments

We are constantly working on technical improvements of our products.

For this reason, details described in this manual may differ slightly from your control. In this case, please order a revised service manual from us.

Duplication

This manual is provided subject to the condition that no part of it shall be duplicated in any form without our prior consent.

Issue 11/2006

valid for the software versions TNC 415B/425: NC Software 259 93* (Standard) TNC 415F/425E: NC Software 259 94* (Export)

TNC 415B/425: NC Software 280 54* (Special Software)

TNC 415F/425E: NC Software 280 56* (Export)

Contents Service Manual TNC 415B/425

How to use this Service Manual	1	
Minor Error Messages		
Major Error Messages and their Causes		
Hardware Components TNC 415B/425	4	
Logic Unit LE 415B/425	5	
Connector Designation and Pin Layout	6	
Block Diagrams	7	
Board Description	8	
Grounding Diagrams TNC 415B/425	9	
Power Supply	10	
Keyboard Unit TE 400/410	11	
Visual Display Unit BC 110/B	12	
Encoders	13	
Electric Handwheels	14	
3D-Touch Probes	15	
Data Interfaces		
Data Input and Output		
Analogue Outputs		
PLC Inputs and Outputs		
Test Units		
Exchange Instructions		
Machine Parameter List	22	

Table of Contents

		Page
1.	How to Use this Service Manual	3
2.	Minor Error Messages	4
2.1	Causes of Minor Error Messages	
3.	Major Error Messages and their Causes	7
4.	Hardware Components TNC 415B/425	16
5.	Logic Unit LE 415B/425	17
5.1	Designation of the Logic Unit LE 415B/F	
5.2	Designation of the Logic Unit LE 425/E	
5.3	Hardware Components of the Logic Unit LE 415B/425	
6.	Connector Designation and Pin Layout	20
6.1	Connectors on the Logic Unit LE 415B/425	20
6.2	Connectors on the PLC I/O Boards	28
6.3	Connectors on the Keyboard Units	39
6.4	Connectors on the Visual Display Units	43
7.	Block Diagrams	45
8.	Board Description	47
9.	Grounding Diagram TNC 415/B	48
10.	Power Supply	51
10.1	External Power Supply Requirements	
10.2	Power Supply of the NC	
10.3	Checking the Power Supply Unit	
10.4	Power Supply of the PLC	
10.5	Buffer Battery	
11.	Keyboard Unit TE 400/410	62
11.1	Overview	
11.2	Checking the Keyboard Unit	64
12.	Visual Display Unit BC 110/B	73
12.1	Overview	
12.2	Checking the Visual Display Unit	73
13.	Encoders	
13.1	Error Messages for Axes with Analogue Speed Controller	76
13.2	Error Messages for Axes with Integral Digital Speed Controller	
13.3	Electrical Inspection of an Encoder	80
14.	Electronic Handwheels	81
14.1	Handwheel HR 130/330	
14.2	Handwheel HR 332	
14.3	Error Messages	83

Page 2 Issue: 20.08.95

		Page
15.	3D-Touch Probes	84
15.1	Overview	
15.2	Error Messages	85
16.	Data Interfaces	87
16.1	Operating Modes of the Data Interfaces	
16.2	Machine Parameters for the Data Interfaces	
16.3	Error Messages	
16.4	Wiring Diagrams of the Data Interfaces	
17.	Data Input and Output	97
17.1	Data Transfer Menu	
17.2	Overview of Files for TNC 415B/425	
17.3	External Data Output	
17.4	Downloading External Data	
18.	Analogue Outputs	120
18.1	Specifications	
18.2	Checking the Analogue Outputs	
18.3	Switching Over the Position Display	
18.4	Adjustment of the Feed Rate	
18.5	Offset Adjustment	
18.6	Oscilloscope Function	
19.	PLC Inputs and Outputs	133
19.1	PLC Inputs	
19.2	PLC Outputs	133
19.3	Checking the PLC Inputs and Outputs	134
19.4	Diagnosis Possibilities in the PLC Mode	137
19.5	Compiling the PLC Program	142
19.6	Output "Control Ready for Operation" and Acknowledgement for Test	
	" Control Ready for Operation "	143
20.	Test Units	
20.1	Test Unit for the PLC Inputs and Outputs	
20.2	Universal Measuring Adapter	
20.3	Encoder Diagnostic Set	147
21.	Exchange Instructions	
21.1	Important Notes	
21.2	Exchanging the Logic Unit	
21.3	Exchanging the Processor Board	
21.4	Exchanging the CLP Board	
21.5	Exchanging the PLC Graphics Board	
21.6	Exchanging the Power Supply Unit	
21.7	Exchanging the PLC I/O Boards	
21.8	Exchanging the EPROMs	169
22.	Machine Parameter List	170

Page 3 Issue: 20.08.95

1. How to Use this Service Manual

The service manual TNC 415B/425 can be used to diagnose, locate and eliminate errors on machine tools controlled by TNC.

In order to correctly judge the problems in an NC-controlled machine tool, fundamental knowledge of the machine tool and its drives as well as their interaction with the control and the measuring systems is required. Incorrect behaviour of the machine tool can also result from improper use of the control, NC-programming errors and incorrect or not properly optimized machine parameters.

For further information in this respect please refer to the

- Documentation of the machine tool manufacturer
- Operating Manual (HEIDENHAIN)
- Technical Manual (HEIDENHAIN).

The Technical Manual is not enclosed with every control. In general, it is only supplied to the machine tool manufacturer and is updated by HEIDENHAIN, Traunreut. Therefore, it is absolutely necessary to contact the machine tool manufacturer, if errors occur that are due to a machine parameter or to the interface of the control. Support will, however, also be provided by the HEIDENHAIN service department and agencies. Telephone numbers, addresses and telex/fax numbers can be found on the back side of the cover page and the back side of the service manual.

Issue: 20.08.95

2. Minor Error Messages

TNC 415B/425 features a comprehensive integral monitoring system to avoid input and operation errors, to locate errors and technical defects of the entire equipment (TNC, measuring systems, machine tool, cables etc.). The monitoring system is a fixed component of the TNC hardware and software; it is always active when the control is switched on. If a technical defect or an operation error is detected, an error message in plain language is displayed on the screen.

To erase **minor error messages**, press



Further error messages are described in the

- Operating Manual TNC 407/415B/425
- Technical Manual TNC 407/415/425
- Documentation by the machine tool manufacturer
- Operating Instructions FE 401 B.

START POSITION INCORRECT TOUCH POINT INACCESSIBLE RANGE EXCEEDED OPERATING PARAMETERS ERASED BAUD RATE NOT POSSIBLE CYCL PARAMETER INCORRECT FAULTY RANGE DATA ROTATION NOT PERMITTED 15	5.2 5.2 5.2 5.2 .1 5.3
START POSITION INCORRECT TOUCH POINT INACCESSIBLE RANGE EXCEEDED OPERATING PARAMETERS ERASED BAUD RATE NOT POSSIBLE CYCL PARAMETER INCORRECT FAULTY RANGE DATA ROTATION NOT PERMITTED 15	5.2 5.2 5.2 .1 5.3 5.2
TOUCH POINT INACCESSIBLE RANGE EXCEEDED OPERATING PARAMETERS ERASED BAUD RATE NOT POSSIBLE CYCL PARAMETER INCORRECT FAULTY RANGE DATA ROTATION NOT PERMITTED	5.2 5.2 .1 5.3 5.2
RANGE EXCEEDED 15 OPERATING PARAMETERS ERASED 2 BAUD RATE NOT POSSIBLE 16 CYCL PARAMETER INCORRECT 15 FAULTY RANGE DATA 15 ROTATION NOT PERMITTED 15	5.2 .1 5.3 5.2 5.2
OPERATING PARAMETERS ERASED BAUD RATE NOT POSSIBLE CYCL PARAMETER INCORRECT FAULTY RANGE DATA ROTATION NOT PERMITTED 15	.1 5.3 5.2
BAUD RATE NOT POSSIBLE CYCL PARAMETER INCORRECT FAULTY RANGE DATA ROTATION NOT PERMITTED 15	5.2 5.2
CYCL PARAMETER INCORRECT 15 FAULTY RANGE DATA 15 ROTATION NOT PERMITTED 15	5.2
FAULTY RANGE DATA 15 ROTATION NOT PERMITTED 15	5.2
ROTATION NOT PERMITTED 15	
	5.2
DATA MEDIUM MISSING 16	
	3.3
	6.3
DATA MEDIUM WRITE-PROTECTED 16	6.3
LIMIT SWITCH <axis> 2</axis>	.1
PLANE WRONGLY DEFINED 15	5.2
	9.6
EXT. IN-/OUTPUT NOT READY 16	6.3
ERR: 001 16	3.3
ERR: 002	3.3
ERR: 003	3.3
ERR: 004 16	6.3
ERR: 005	3.3
ERR: 006 16	6.3
ERR: 007 16	3.3
ERR: 010 16	6.3
ERR: 011 16	6.3
ERR: 012 16	6.3
ERR: 013	6.3
ERR: 014 16	6.3
ERR: 015	6.3
ERR: 016 16	6.3
ERR: 017 16	6.3
ERR: 018 16	6.3
	6.3
ERR: 101 16	6.3

Γ	1
Error Message	Sec.
ERR: 102	16.3
ERR: 103	16.3
ERR: 104	16.3
ERR: 105	16.3
ERR: 106	16.3
ERR: 107	16.3
ERR: 108	16.3
ERR: 109	16.3
PROGRAM DATA ERRONEOUS	16.3
WRONG OPERATING MODE	16.3
WRONG AXIS PROGRAMMED	15.2
HANDWHEEL?	14.3
HANDWHEEL DEFECTIVE	14.3
ME: TAPE END	16.3
SCALING FACTOR NOT PERMITTED	15.2
PLC PROGRAM NOT TRANSLATED	2.1
PLC: ERROR <00 to 99>	2.1
POSITIONING ERROR	2.1
PROGRAM INCOMPLETE	16.3
POWER INTERRUPTED	2.1
INTERFACE ALREADY ASSIGNED	16.3
RELAY EXT. DC VOLTAGE MISSING	19.6
STYLUS ALREADY IN CONTACT	15.2
PROBE SYSTEM NOT READY	15.2
EXCHANGE TOUCH PROBE BATTERY	15.2
TRANSFERRED VALUE ERRONEOUS X	16.3
TRANSFERRED DATA INCORRECT X	16.3
TIME LIMIT EXCEEDED	15.2

Issue: 20.08.95

2.1 Causes of Minor Error Messages

OPERATING PARAMETERS ERASED

- With new and exchange controls, the machine parameters are always erased
- Defective buffer batteries, accumulator or capacitor
- RAM error on the processor board
- Software exchanged

LIMIT SWITCH < AXIS>

- "Manual" Operating Mode

The preset **software limit** switch has been reached during traverse with the axis address keys.

- "Automatic" Operating Mode

The **calculated position** of the current block is beyond the software limit switch range or beyond the additional limit (set with the MOD function <AXIS LIMIT>). The positioning is not performed.

Machine Parameters for the Software Limit Switches

	X+	Х-	Y+	Υ-	Z+	Z-
Default setting	910.0	920.0	910.1	920.1	910.2	920.2
Activation via PLC 1)	911.0	921.0	911.1	921.1	911.2	921.2
Activation via PLC 1)	912.0	922.0	912.1	922.1	912.2	922.2

	IV+	IV-	V+	V-
Default setting	910.3	920.3	910.4	920.4
Activation via PLC 17	911.3	921.3	911.4	921.4
Activation via PLC 1)	912.3	922.3	912.4	922.4

¹⁾ PLC markers M 2816 and M 2817

POWER INTERRUPTED

- After a reset signal of the power supply (e.g. line voltage drops)
- Important machine parameters may have been changed: e.g. MP 210, MP 410.3, MP 730, MP 3240.1, MP 7210, MP 7310

POSITIONING ERROR

- The servo lag monitor set in the machine parameters 1410.X or 1710.X has responded. (Check the run-in behaviour of the axis; readjust, if necessary.)

PLC PROGRAM NOT TRANSLATED

- After editing, the PLC program must be compiled (translated) anew.

Page 6 Issue: 20.08.95

PLC: ERROR 00	marker	2924	
to	to		— set
PLC: ERROR 99	marker	3023	

- Instead of PLC: ERROR 00 to 99 another dialogue may be displayed with customized PLC programs. For further information please contact your machine tool manufacturer.

NOTES

Issue: 20.08.95

3. Major Error Messages and their Causes

The integrated monitoring system distinguishes between minor and gross errors. Gross errors are characterized by a blinking display (e.g. malfunctions of the encoders, of the drives and data processing errors).

If a gross error occurs, the control opens the contact "Control Ready for Operation". This causes an emergency stop of the machine tool.

the error cause has been eliminated.

By switching off the main switch or by pressing , the emergency stop state can be reset, provided that

Display (blinking)	Error Cause
PROCESSOR CHECK ERROR YX	X = 0 CRC sum control data incorrect 1 CRC sum MC-memory incorrect 2 Check sum NC-memory incorrect 3 Test plane incomplete / will not run 4 Crosstalk between data bits in RAM 5 Crosstalk between addresses in RAM 6 Stack overflow 7 CRC sum PLC program ASCII 8 CRC sum PLC program OP-Code 9 CRC sum test section A Software error B Wrong interrupt Differentiation with register V0: 08 bus error 0C address error 10 illegal instruction 14 division by 0 18 error output for CHK command (check range) 20 error output for TRAPV command (trap on overflow) 24 privilege infringement (supervisor command in the user mode) 28 emulator trap 2C emulator trap 30 - 34 - 38 - 3C interrupt vector not initialized 40 interrupt vector not initialized 41 interrupt vector not initialized 42 interrupt vector not initialized 43 interrupt vector not initialized 44 interrupt vector not initialized 45 interrupt vector not initialized 46 interrupt vector not initialized 47 interrupt vector not initialized 48 interrupt vector not initialized 49 interrupt vector not initialized 40 interrupt vector not initialized 41 interrupt vector not initialized 42 interrupt vector not initialized 43 interrupt vector not initialized 44 interrupt vector not initialized 45 - 56 - 50 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 55 - 56 - 57 - 58 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 55 - 56 - 57 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 51 - 51 - 51 - 51 - 52 - 53 - 54 - 55 - 56 - 57 - 58 - 58 - 59 - 59 - 50 - 50 - 51 - 51 - 51 - 51 - 51 - 51 - 51 - 51

Page 8 Issue: 20.08.95

Display (blinking)	Error Cause
PROCESSOR CHECK ERROR YX (continued)	C Time slice overflow D Command stack overflow control loop E Wrong command main processor F Wrong display mode main processor G Wrong boot command H Verify error with boot command "load" I Wrong supplementary command with boot command "test" J Boot logon not successful K EPROM comparison CLP L Wrong command CLP processor M Operating voltage beyond tolerance range N No PLC texts in PLC chip O Axis 4 and/or 5 paraxial with export version P Inhibited software function activated (function without software enable module) C TNC 415 without CLP or geometry CPU R The control attempted to start a PLC positioning (M2704 to M2708), a datum shift (M2716) or to switch the range (M2816 and M2817), although MP7440/bit 2 was set or MP3030 ≤ 1. Y = CPU number 1 = main processor 2 = geometry processor 3 = CLP processor

If the error message **PROCESSOR CHECK ERROR XY** (XY = code; see above) comes up repeatedly, send the **complete logic unit** to HEIDENHAIN for repair. Please indicate the **error message and the code.**

Page 9 Issue: 28.10.00

Display (blinking)	Error Ca	use	
	VV 1 A	NC -tt	
ERROR IN PLC-PROGRAM XX	XX = 1A	NC start	complement missing
	1B	Rapid traverse	complement missing
	1C	Axis address key latch	complement missing
	1D	Feed enable	complement missing
	1E	PLC positioning X 1)	complement missing
	1F	PLC positioning Y 1)	complement missing
	1G	PLC positioning Z 1)	complement missing
	1H	PLC positioning IV 1)	complement missing
	11	Axis address key X+	complement missing
	1J	Axis address key X-	complement missing
	1K	Axis address key Y+	complement missing
	1L	Axis address key Y-	complement missing
	1M	Axis address key Z+	complement missing
	1N	Axis address key Z-	complement missing
	10 1D	Axis address key IV+	complement missing
	1P 1Q	Axis address key IV- More than one of the markers	complement missing
	10	M2485M2487 (M03, M04,	
		M05) are set simultaneously	
	1R	More than one of the	
	111	functions "PLC Positioning"	
		(M2704 to M2708), "Datum	
		Shift" (M2716) or "Q-Para-	
		meter Transfer" are activated	
		simultaneously.	
	2A	Jog increment pos. X+	complement missing
	2B	Jog increment pos. X-	complement missing
	2C	Jog increment pos. Y+	complement missing
	2D	Jog increment pos. Y-	complement missing
	2E	Jog increment pos. Z+	complement missing
	2F	Jog increment pos. Z-	complement missing
	2G	Jog increment pos. IV+	complement missing
	2H	Jog increment pos. IV-	complement missing
	21	Jog increment pos. V+	complement missing
	2K	Jog increment pos. V-	complement missing
	2L		complement missing
	2M	Axis address key V+	complement missing
	2N	Axis address key V-	complement missing
	2P	PLC positioning V	complement missing
	50	Excessive nesting (too many m	nodules nested inside
		one another)	
	51	Stack underflow (an attempt to	acquire data from the
		STACK, although it was empty	
	52	Stack overflow (an attempt to I	oad too many data
		onto the STACK)	
	53	Time-out (the permissible prog	
		exceeded by more than twice.	Check the structure of
		the subprogram)	
	54	CASE arguments are larger tha	n the number of
		entries in the table	
	55	No access to error texts / dialo	gue texts

Page 10 Issue: 20.08.95

Display (blinking)	Erro	r Cau	ise
ERROR IN PLC-PROGRAM X	X =	7 8	Called label not defined No end-program condition found (the program does not contain an EM instruction, or it contains a JP instruction without a LBL instruction following.) Program is too long (RAM overflow) (insufficient memory for the program code to be generated.)
ERROR IN PLC-PROGRAM XX	XX =	10 11 12 13 14 15 16 17 18 19 20 21 22	Assign with parenthesis (an =, S, SN, R, RN or PS instruction has been programmed, although arithmetic parenthesis are open) Excessive nesting of parentheses (more than 16 parentheses are open) Jump within a gating sequence (unconditional jump has been programmed, although the gating sequence was not closed with an Assign) "Close Parenthesis" without "Open Parenthesis" (a "Close Parenthesis" command was programmed, although no parentheses were open) Label within parentheses (a LBL instruction has been programmed, although parentheses are open) Label within a gating sequence (a LBL instruction has been programmed, although the previous gating was not closed with an Assign) Jump within parentheses (a jump instruction has been programmed, although parentheses are open) Parentheses open at the end of a block (an EM instruction has been programmed, although parentheses are open) Label defined twice Logic Assign missing (a Word Assign or gating has been programmed, although the previous Logic-gating was not closed with a Assign) Logic Assign missing (a Word instruction has been programmed, although the previous Logic-gating was not closed with an Assign) Word accumulator not loaded (a Word Assign or gating has been programmed, although the Logic accumulator does not contain a definite value) Logic accumulator not loaded (a Logic has been programmed, although the Logic accumulator does not contain a definite value)

Page 11

Issue: 20.08.95

Display (blinking)	Error Cau	se
ERROR IN PLC-PROGRAM XX (continued)	23	Accumulators not loaded on "Open Parentheses" (an A[, AN[, O[, ON[, XON[command has been programmed, although neither the word nor the logic accumulator has been gated or loaded)
	24	Incorrect type of parentheses result (a different type has been calculated in the parentheses from that which was defined in the "Open Parentheses" command, i.e. logic instead of word or vice versa)
	25	Conditional jump with incorrect logic accumulator (a conditional jump has been programmed, although the logic accumulator does not contain a definite value)
	26	Empty CASE instruction
	27	"END-CASE" missing

NOTES

Issue: 20.08.95

Error Messages GROSS POSITIONING ERROR: Axes with Analogue Speed Controller

Display (blinking)	Error Cause	
GROSS POSITIONING ERROR <axis> YA</axis>		exceeded 0.X) e exceeded 0.X)
GROSS POSITIONING ERROR <axis> YB</axis>	Monitoring of the Anal - The nominal voltage calcureached its limit of ± 10 V (only with feed forward co	ulated by the control has (± 20 V for spindle).
GROSS POSITIONING ERROR <axis> YC</axis>		d in a certain time is less than e nominal value calculated by the d via MP1140.x)
GROSS POSITIONING ERROR <axis> YD</axis>	Standstill Monitoring - The deviation from the no standstill has exceeded th machine parameter MP11	ne value programmed in the
GROSS POSITIONING ERROR <axis> YE</axis>	Monitoring of the Offset - The offset voltage limit of during an automatic offset (see section 18.5)	100mV has been reached
	Y = CPU number	1 = main processor 2 = geometry processor 3 = CLP processor

Error Location

When the error message GROSS POSITIONING ERROR is displayed, the error may be located in any element of the closed loop.

e.g.- Error in control (e.g. CLP board)

- Excessive offset voltage at the servo amplifier
- Incorrect speed adjustment at the servo amplifier
- Monitoring function of servo amplifier has responded (e.g. monitoring of current intensity)
- Electrical defect at the servo amplifier
- Mechanical error (bearing, spindle, guides)
- Excessive mechanical forces on a drive

Issue: 20.08.95

Error Messages GROSS POSITIONING ERROR: Axes with Integrated Digital Speed Controller

Display (blinking)	Error Cause	
GROSS POSITIONING ERROR <axis> YA</axis>	•	rd control: exceeded X) exceeded X)
GROSS POSITIONING ERROR <axis> YB</axis>	Monitoring of the Analogous The nominal voltage calcular reached its limit of ± 10 V ((only with feed forward control of the Analogous Control of	ated by the control has (± 20 V for spindle).
GROSS POSITIONING ERROR <axis> YC</axis>	Movement Monitoring - The difference between th position encoder (LS) and t (ROD) has reached the tole MP1970.x.	hat of the speed encoder
GROSS POSITIONING ERROR <axis> YD</axis>	Standstill Monitoring - The deviation from the non standstill has exceeded the machine parameter MP111	e value programmed in the
GROSS POSITIONING ERROR <axis> YE</axis>	Monitoring of the Offse - The offset voltage limit of during an automatic offset a (see section 18.5)	100mV has been reached
GROSS POSITIONING ERROR <axis> YF</axis>	Monitoring of the Integral Controller - The monitoring limit of the (MP1910.x) has responded	integrated speed controller
	Y = CPU number	1 = main processor 2 = geometry processor 3 = CLP processor

Error Location

When the error message GROSS POSITIONING ERROR is displayed, the error may be located in any element of the closed loop.

- e.g.: Error in control (e.g. CLP board)
 - Excessive offset voltage at the servo amplifier
 - Monitoring function of servo amplifier has responded (e.g. monitoring of current intensity)
 - Electrical defect at the servo amplifier
 - Motor, tachometer, encoder or cabling defective
 - Mechanical error (bearing, spindle, guides)
 - Excessive mechanical forces on a drive



Display (blinking)	Error Cause	
ENCODER <axis> DEFECTIVE YA</axis>	Signal amplitude error	position encoder
ENCODER <axis> ` DEFECTIVE YA</axis>	Signal amplitude error	speed encoder
ENCODER <axis> DEFECTIVE YB</axis>	Signal frequency error	position encoder
ENCODER <axis> ` DEFECTIVE YB</axis>	Signal frequency error	speed encoder
ENCODER <axis> DEFECTIVE YC</axis>	Error with distance-coded scale	position encoder
ENCODER <axis> `DEFECTIVE YC</axis>	Error with distance-coded scale	speed encoder
	2	= main processor = geometry processor = CLP processor
	Error Causes: - Encoder not connected - Cable damaged - Glass scale contaminated or da - Scanning head defective - Encoder monitoring system de Checking the encoders: see sect	fective
WRONG REFERENCE POINT	Wrong reference mark spacing e coded linear encoders (counting measuring system or the logic un	error caused by the
TNC OPERATING TEMP. EXCEEDED	Temperature inside the logic uni	t has exceeded + 70°C
EMERG. STOP DEFECTIVE YX EMERGENCY STOP PLC	YX = 1(1. emergency stop to 1) 2. emergency stop to 1. 3. emergency stop to - Error during the test routine "Co when the machine is switched	est est ontrol ready for operation" I on (see section 19.4)
	This error message is only gener is set without additional marker (

Page 15

Issue: 20.08.95

Display (blinking)	Error Cause	
PLC: Error 00	marker 2924	
to	to	— and marker 2815 set
PLC: Error 99	marker 3023	
CHECK SUM ERROR YX	1B CRC s 1D CRC s	sum main processor EPROM chips 1/2 sum main processor EPROM chips 3/4 sum PLC chip s sum calculation
	YC CRC s YD CRC s YE CRC s YR CRC s	sum main processor EPROM chips 1 to 4 sum geometry processor EPROM chips 5/6 sum PLC chip sum GEM chip 7 sum CLP boot chip s sum calculation
	YB CRC s YC CRC s YD CRC s YE CRC s YR CRC s	sum main processor EPROM chips 1/2 sum main processor EPROM chips 3/4 sum geometry processor EPROM chips 5/6 sum PLC chip sum GEM chip 7 sum CLP boot chip s sum calculation
	Y = CPU r	number
		1 = main processor2 = geometry processor3 = CLP processor

Instead of PLC: ERROR 00 ... 99 another dialogue may be displayed with customized PLC programs. For further information, please contact your machine tool manufacturer.

CRC = Cyclic Redundancy Check (during data transfer)

If the error message CHECK SUM ERROR YX comes up repeatedly, send the **complete logic unit** to HEIDENHAIN for repair. Please indicate the **check sum error**.

Page 16 Issue: 20.08.95

4. Hardware Components TNC 415B/425

TNC	TNO 445 D	TNO 405
Component	TNC 415 B	TNC 425
LOGIC UNIT LE 415 B/F ⁶⁾		
ld.No. 267 223	X	
LOGIC UNIT LE 425/E ⁶⁽⁷⁾		
Id.No. 267 214		X
		<i>'</i>
VISUAL DISPLAY UNIT BC	110/B	
Id.No. 260 520 (BC 110B)	X	X
Id.No. 254 740 (BC 110)	X ⁵⁾	X ⁵⁾
KEYBOARD UNIT TE 400		
Id.No. 250 517	X	X
KEYBOARD UNIT TE 410	customized version)	
Id.No. 258 645	X	X
Id.No. 264 105	X	X
PLC I/O BOARD PA 110 (op	otion) ²⁾	
Id.No. 262 651	X	X
PLC I/O BOARD PL 400 (op:		
ld.No. 255 855	X	X
PLC I/O BOARD PL 405 (op	tion) ⁴⁾	
ld.No. 263 371 21	X	X
	(· \3)	
PLC I/O BOARD PL 410 (op ^o Id.No. 263 371		V
IU.INU. 203 3/ I	X	X

only digital part (64 PLC inputs / 32 PLC outputs)

only analogue part

version 01: 64 PLC inputs / 23 PLC outputs and analogue part version 11: 64 PLC inputs / 23 PLC outputs, no analogue part

only digital part: (32 PLC inputs / 16 PLC outputs)

superseded by BC 110B


⁶⁾ F/E: export versions of the controls (different software; hardware identical)

TNC 425: control with integral digital speed controller (see section 18.2)

Page 17 Issue: 20.08.95


5. LOGIC UNIT LE 415B/425

5.1 Designation of the Logic Unit LE 415B/F



Page 18 Issue: 20.08.95

5.2 Designation of the Logic Unit LE 425/E



Issue: 20.08.95

5.3 Hardware Components of the LOGIC UNIT LE 415B/425

Board Overview LE 415B/F

	TNC 415B/F		
Board	LE 415B/F 267 223	LE 415B/F 267 223 3-	LE 415B/F 267 223 4-
PROCESSOR BO	ARD		
ld.No. 268 553 01	X	Х	X
PLC GRAPHICS I Id.No. 257 954 02 Id.No. 257 954 03*	BOARD ×	х	X
14.110. 237 934 03			^
CLP BOARD			
CLP BOARD Id.No. 275 705 01	X		

Board Overview LE 425/E

			TNC 425/E		
	LE 425/E				
Board	267 214 1-	267 214 2-	267 214 3-	267 214 4-	267 214 5-
PROCESSOR B	OARD				
ld.No. 268 553 01	Х	Х	Х	Х	Х
					•
PLC GRAPHICS	BOARD				
ld.No. 257 954 02	Х	Х	Х	Х	
Id.No. 257 954 03*					Х
CLP BOARD					
ld.No. 265 401 01	X				
ld.No. 268 927 01		Х			
ld.No. 275 711 01			Х		
ld.No. 275 711 02				X	X

^{* +24}V supply voltage of the operating panel (routed via X46) cannot be switched off with EMERG. STOP.


Page 20 Issue: 20.08.95

6. Connector Designation and Pin Layout

6.1 Connectors on the LOGIC UNIT LE 415B/425

6.1.1 Connector Designation LOGIC UNIT LE 415B/425

LE 415B



CLP board

X1 = measuring system 1 (~) X2 = measuring system 2 (~)

X3 = measuring system 3 (~)

X4 = measuring system 4 (~)

X5 = measuring system 5 (~)

X6 = measuring system S ()

X8 = nominal value output 1, 2, 3, 4, 5, S

X12 = triggering touch probe

X14 = measuring touch probe

B = signal ground

PLC graphics board

X41 = PLC output

X42 = PLC input

X43 = visual display unit (BC)

X44 = 24V power supply for PLC

X45 = TNC keyboard unit (TE)

X46 = machine operating panel

X47 = PLC I/O board

Processor board

X21 = RS-232-C data interface


X22 = RS-422 data interface

X23 = electronic handwheel

X31 = 24V- power supply for NC

Issue: 20.08.95

LE 425



0

*

X44 (*)

CLP Board

X1 = encoder 1 (~) X2 = encoder 2 (~) X3 = encoder 3 (~) X4 = encoder 4 (~) X5 = encoder 5 (~) X6 = encoder S (¬¬¬)

X8 = nominal value output 1, 2, 3, 4, 5, S

X12 = touch trigger probe X14 = measuring touch probe X15 = encoder / speed X16 = encoder / speed

X16 = encoder / speed X17 = encoder / speed X18 = encoder / speed

X19 = encoder / speed

X20 = reserved B = signal ground

PLC Graphics Board

X41 = PLCoutput

X42 = PLC input

X43 = visual display unit (BC) X44 = 24 V power supply for PLC X45 = TNC operating panel (TE) X46 = machine operating panel

X47 = PLC I/O interface

Processor Board

X21 = V.24/RS-232-C data interface X22 = V.11/RS-422 data interface X23 = electronic handwheel

X31 = 24V- power supply for NC

Issue: 14.11.06

6.1.2 Pin Layout: POWER SUPPLY LE 415B/425

X31 Power Supply (NC)

terminal strip (pluggable) 2-pin

Pin No.	Assignment
1	+ 24 V
2	OV



6.1.3 Pin Layout: CLP Board LE 415 B

X1,X2,X3,X4,X5 Encoders 1,2,3,4,5 (Position)

sinusoidal input, current interface 7-16µA flange socket with female insert (9-pin, Conei)

Pin No.	Assignment
1	0°+
2	0°-
5	90°+
6	90°-
7	RP+
8	RP-
3	+ 5 (Up)
4	0 V (Uusable comp.)
9	internal shield
housing	external shield = housing

X6 Spindle Encoder (Position)

square-wave encoder (TTL) flange socket with female insert (12-pin, Conei)

Pin No.	Signal Designation
5	Ua1
6	-Ua1
8	Ua2
1	-Ua2
3	Ua0
4	-Ua0
7	-UaS
(2)	+ 5V (sense)
12	+ 5V (Up)
(11)	0 V (sense)
10	0 V (Uusable comp.)
9 (via spring)	shield = housing

X8 Nominal Value Output 1,2,3,4,5,\$

flange socket with female insert (15-pin, D-SUB)

Pin No.	Signal Designation
1	analogue output 1
3	analogue output 2
5	analogue output 3
7	analogue output 4
4	analogue output 5
8	analogue output spindle
9	0V analogue output 1
11	0V analogue output 2
13	0V analogue output 3
14	0V analogue output 4
6	0V analogue output 5
15	0V analogue output spindle
housing	external shield = housing
2,10,12	do not assign

X12 Touch Trigger Probe

flange socket with female insert (15-pin, D-SUB)

Pin No.	Signal Designation
1	internal shield
3	standby
4	start
5	+ 15V
6	+ 5V (Up)
7	-battery warning
8	0 V (Uusable comp.)
9	trigger signal
10	-trigger signal 1)
2, 11 to 15	not assigned

1) stylus at rest = high level



Page 23

Issue: 20.08.95

X14 Measuring Touch Probe

flange socket with female insert (25-pin, D-SUB)

Pin No.	Assignment
17	0° +
4	0° -
16	90° +
3	90° -
14	RP +
2	RP -
15	+ 5V
1	OV
21	0° +
8	0° -
20	90° +
7	90° -
18	RP +
6	RP -
19	+ 5V
5	0 V
25	0°+
12	0°-
24	90°+
11	90°-
22	RP +
10	RP -
23	+ 5V
9	OV
13	shield

6.1.4 Pin Layout: CLP Board LE 425

X1, X2, X3, X4, X5 Encoder 1, 2, 3, 4, 5 (Position)

sinusoidal input current interface 7 - 16µA flange socket with female insert (9-pin, D-SUB)

Pin No.	Assignment
6	0° +
1	0° -
8	90° +
3	90° -
9	RP +
5	RP -
7	+ 5V (UP)
2	0V (UN)
3	internal shield
housing	external shield = housing

X8 Nominal Value Output 1, 2, 3, 4, 5, S see CLP board LE 415 B

X14 Measuring Touch Probe

see CLP board LE 415 B

X6 Spindle Encoder (Position)

square-wave input (TTL) flange socket with female insert (15-pin, D-SUB)

Pin No.	Assignment
1	Ua1
9	-Ua1
3	Ua2
11	-Ua2
14	Ua0
7	-Ua0
13	-UaS
12	+ 5V sense
10	0V sense
4	+ 5V (UP)
2	0V (UN)
5, 6, 8, 15	not assigned
housing	external shield = housing

X12 Touch Trigger Probe

see CLP board LE 415 B

Page 24

Issue: 20.08.95

X15, X16, X17, X18, X19 Encoder 1,2,3,4,5 (Speed)

sinusoidal input, voltage interface 1Vpp flange socket with female insert (15-pin, D-SUB)

Pin No.	Assignment
1	A+
9	A-
3	B+
11	B-
14	R +
7	R -
4	+ 5V (U _P)
2	0V (U _N)
(12)	+ 5V sense
(10)	0V sense
5,6,8,13,15	do not assign
housing	external shield = housing

6.1.5 Pin Layout: PLC Graphics Board LE 415B/425

X44 Power Supply (PLC)

terminal strip (pluggable) 3-pin

Pin No.	Assignment
1	+ 24V_A can be switched off via
	EMERG. STOP
2	+ 24V cannot be switched off
	via EMERG. STOP
3	0V

X41 PLC Output

flange socket with female insert (37-pin, D-SUB)

Pin No.	Assignment
1	00
2	01
3	O2
4	03
5	04
6	O5
7	O6
8	07
9	08
10	O9
11	O10
12	011
13	O12
14	O13
15	O14
16	O15
17	O16
18	O17
19	O18
20	O19

Pin No.	Assignment
21	O20
22	O21
23	O22
24	O23
25	O24 ²⁾
26	O25 ²⁾
27	O26 ²⁾
28	O27 ²⁾
29	O28 ²⁾
30	O29 ²⁾
31	O30 ²⁾
32	do not assign
33	0V (PLC) 1)
34	control ready for operation ²⁾
35,36,37	+24V_A PLC ³⁾
housing	external shield

^{1) 0} V PLC reference potential for testing

X42 PLC Input

²⁾ cannot be switched off with ext. EMERG. STOP

^{3) + 24}V_A PLC power supply for testing (can be switched off)

Page 25 Issue: 20.08.95



Pin No.	Assignment
1	10
2	l1
3	12
4	I3 acknowledgement for test
	"control ready for operation"
5	14
6	15
7	16
8	17
9	18
10	19
11	l10
12	l11
13	l12
14	l13
15	l14
16	l15
17	l16
18	l17
19	l18
20	l19
21	120
22	l21
23	122
24	123
25	124
26	125
27	126
28	127
29	128
30	129
31	130
32	l31
33,34	do not assign
35,36,37	OV PLC ¹⁾
housing	external shield = housing

Pin No.	Assignment
1	RL0
2	RL1
3	RL2
4	RL3
5	RL4
6	RL5
7	RL6
8	RL7
9	RL8
10	RL9
11	RL10
12	RL11
13	RL12
14	RL13
15	RL14
16	RL15 key matrix
17	RL16
18	RL17
19	RL18
20	SL0
21	SL1
22	SL2
23	SL3
24	SL4
25	SL5
26	SL6
27	SL7
28	RL19
29	RL20
30	do not assign
31	RL21
32	RL22 key matrix
33	RL23
34	spindle override (wiper)
35	feed override (wiper)
36	- 5V override potentiometer
37	0V override potentiometer
housing	external shield = housing

¹⁾ external reference potential for PLC supply

X43 Visual Display Unit (BC 110/B) flange socket with female insert (15-pin, D-SUB)

Pin No.	Assignment
1,8,11	GND
2 to 6,12,13	do not assign
7	R signal
9	V SYNC
10	H SYNC
14	G signal
15	B signal

Page 26

Issue: 20.08.95

X46 Machine Operating Panel

flange socket with female insert (37-pin, D-SUB)

Pin No.	Assignment
1	1128
2	1129
3	1130
4	I131
5	1132
6	l133
7	1134
8	l135
9	I136
10	l137
11	I138
12	I139
13	l140
14	l141
15	1142
16	1143
17	1144
18	1145
19	1146
20	1147
21	1148
22	1149
23	1150
24	l151
25	l152
26	O0 1)
27	O1 1)
28	O2 ¹⁾
29	O3 ¹⁾
30	O4 1)
31	O5 ¹⁾
32	O6 ¹⁾
33	O7 ¹⁾
34	0 V (PLC) ²⁾
35	0 V (PLC) ²⁾
36	+ 24V PLC ^{3) 4)}
37	+ 24V PLC ^{3) 4)}

X47 PLC Expansion Interface

12V interface

flange socket with male insert(25-pin, D-SUB)

Pin No.	Assignment
1,2,3	0 V * 1
4	serial IN 2
5,6,17,18	not assigned
7	-RESET
8	-WRITE EXTERN
9	WRITE EXTERN
10	-05
11	-03
12	-01
13	shield
14,15,16	+ 12V * 1
19	serial IN 1
20	EMERGENCY STOP
21	-serial OUT
22	serial OUT
23	-04
24	-02
25	-00

¹⁾ O0...O7 simultaneously at X21 (PLC output)

²⁾ OV PLC reference potential for testing

^{3) + 24} V PLC supply voltage routed via fuse for the inputs I128 to I152

⁴⁾ PLC board version 01/02: + 24V_A can be switched off PLC board version 03: + 24V cannot be switched off

Issue: 20.08.95

6.1.6 Pin Layout: Processor Board LE 415B/425

X21 V.24/RS-232 Data Interface

flange socket with female insert (25-pin, D-SUB)

Pin No.	Assignment
1	shield
2	RxD
3	TxD
4	CTS
5	RTS
6	DTR
7	GND (0 V * 2)
8 to 19	not assigned
20	DSR
21 to 25	not assigned
housing	external shield = housing

X22 V.11/RS-422 Data Interface

flange socket with female insert (15-pin, D-SUB)

Pin No.	Assignment
1	shield
2	RxD
3	CTS
4	TxD
5	RTS
6	DSR
7	DTR
8	GND
9	-RxD
10	-CTS
11	-TxD
12	-RTS
13	-DSR
14	-DTR
15	do not assign

X23 Handwheel Interface (serial)

flange socket with female insert (9-pin, D-SUB)


Pin No.	Assignment HR 130/330	Assignment HR 332
1,3,5	not assigned	not assigned
4	+ 12V	+ 12V
2	0 V	0 V
6	DTR	DTR
9	not assigned	not assigned
8	RXD	RXD
7	do not assign	TXD
housing	external shield = housing	external shield = housing



Issue: 20.08.95

6.2 Connectors on the PLC I/O Boards

6.2.1 Connectors on PL 400



Issue: 20.08.95

6.2.2 Pin Layout: PL 400

X1	Assignment	
Pin No.	as 1. PL	as 2. PL
1	O32	064
2	O33	065
3	O34	066
4	O35	067
5	O36	068
6	O37	069
7	O38	070
8	O39	071
9	O40	072
10	O41	073
11	O42	074
12	do not assign	

X4	Assignment	
Pin No.	as 1. PL	as 2. PL
1	l126	1254
2	174	1202
3	173	1201
4	172	1200
5	l71	l199
6	170	l198
7	169	l197
8	168	l196
9	167	l195
10	166	l194
11	165	l193
12	164	l192

X2	Assignment	
Pin No.	as 1. PL	as 2. PL
1	O43	075
2	O44	076
3	O45	077
4	O46	078
5	O47	079
6	O48	080
7	O49	081
8	O50	082
9	O51	083
10	O52	084
11	O53	085
12	do not assign	

X5	Assignment	
Pin No.	as 1. PL	as 2. PL
1	186	1214
2	185	1213
3	184	1212
4	183	1211
5	182	1210
6	l81	1209
7	180	1208
8	179	1207
9	178	1206
10	177	1205
11	176	1204
12	175	1203

Х3	Assignment	
Pin No.	as 1. PL	as 2. PL
1	O54	086
2	O55	087
3	O56 ¹⁾	088 ¹⁾
4	O57 ¹⁾	089 ¹⁾
5	O58 ¹⁾	090 ¹⁾
6	O59 ¹⁾	091 ¹⁾
7	O60 ¹⁾	092 ¹⁾
8	O61 ¹⁾	093 ¹⁾
9	O62 ¹⁾	094 1)
10	control ready for operation	
11	do not assign	
12	+24V cannot be switched off	
	via ext. EMERO	G. STOP

X6	Assignment	
Pin No.	as 1. PL	as 2. PL
1	198	1227
2	197	1226
3	196	1225
4	195	1224
5	194	1223
6	193	1221
7	193	1220
8	l91	1219
9	190	1218
10	189	1217
11	188	1216
12	187	1215

¹⁾ outputs cannot be switched off via ext. EMERG. STOP

Page 30

Issue: 20.08.95

X 7	Assignment	
Pin No.	as 1. PL	as 2. PL
1	l110	1238
2	1109	1237
3	1108	1236
4	1107	1235
5	1106	1234
6	1105	1233
7	1104	1232
8	1103	1231
9	1102	1230
10	l101	1229
11	1100	1228
12	199	1227

X8	Assignment	
Pin No.	as 1. PL	as 2. PL
1	l122	1250
2	l121	1249
3	l120	1248
4	l119	1247
5	l118	1246
6	l117	1245
7	l116	1244
8	l115	1243
9	l114	1242
10	l113	1241
11	l112	1240
12	l1111	1239


X9	Assignment	
Pin No.	as 1. PL	as 2. PL
1	do not assign	
2	do not assign	
3	do not assign	
4	l125	1253
5	l124	1252
6	l123	1251

X10 Connection to LE or to 1. PL		
Pin No.	Assignment	
1,2,3	0 V	
4	serial IN 2	
5,6,17,18	not assigned	
7	-RESET	
8	-WRITE EXTERN	
9	WRITE EXTERN	
10	-05	
11	-03	
12	-01	
13	shield	
14,15	+ 12 V	
16	board ID (PK)	
19	serial IN 1	
20	control ready for operation	
21	-SERIAL OUT	
22	SERIAL OUT	
23	-04	
24	-02	
25	-00	

X11 Connection of 2. PL or PA		
Pin No. Assignment		
1,2,3	0V	
4-6, 14-18	do not assign	
7	-RESET	
8	-WRITE EXTERN	
9	WRITE EXTERN	
10	-05	
11	-03	
12	-01	
13	shield	
19	serial IN 2	
20	control ready for operation	
21	-serial OUT	
22	serial OUT	
23	-04	
24	-02	
25	-00	

Page 31 Issue: 20.08.95

6.2.3 Connectors on PL 405



Page 32 Issue: 20.08.95

6.2.4 Pin Layout: PL 405

X1 Connection to Logic Unit or		
to 1. PL		
Pin No.	Assignment	
1,2,3	0V	
5.6.17.18	do not assign	
4	serial IN 2	
7	-RESET	
8	WRITE EXTERN	
9	-WRITE EXTERN	
10	-05	
11	-03	
12	-01	
13	shield	
14, 15	+12V	
16	board ID (PK)	
19	serial IN 1	
20	control ready for operation	
21	-serial OUT	
22	serial OUT	
23	-04	
24	-02	
25	-00	

X3 PLC Inputs			
	Assignment		
Pin No.	as 1. PL	as 2. PL	
1	164	l192	
2	165	l193	
3	166	I194	
4	167	I195	
5	168	I196	
6	169	l197	
7	170	I198	
8	l71	l199	
9	172	1200	
10	173	1201	
11	174	1202	
12	175	1203	
13	176	1204	
14	177	1205	
15	178	1206	
16	179	1207	


X4 PLC Inputs		
Pin No.	Assignment as 1. PL	as 2. PL
1	180	1208
2	l81	1209
3	182	I210
4	183	I211
5	184	1212
6	185	l213
7	186	1214
8	187	l215
9	188	1216
10	189	l217
11	190	l218
12	l91	I219
13	192	1220
14	193	I221
15	194	1222
16	195	1223

X8 PLC Outputs and "Control Ready for Operation"		
	Assignment	
Pin No.	as 1. PL	as 2. PL
1	O48	080
2	O49	O81
3	O50	O82
4	O51	O83
5	O52	O84
6	O53	O85
7	O54	O86
8	O55	087
9	O56	088
10	O57	O89
11	O58	O90
12	O59	O91
13	O60	O92
14	O61	O93
15	O62	O94
16	control ready for operation	

X9, X10, X13, X14 PL 405 Power Supply				
Terminal	Assignment	as 1. PL	as 2. PL	
X9	0V			
X10	+24 V- logic supply and "Cont	+24 V- logic supply and "Control Ready for Operation"		
X13	+24 V- output supply	048 - 055	080 - 087	
X14	+24 V- output supply	056 - 062	088 - 094	

Page 33 Issue: 20.08.95

6.2.5 Connectors on PL 410



Issue: 20.08.95

6.2.6 Pin Layout: PL 410

X1 Connection to Logic Unit or		
to 1. PL		
Pin No.	Assignment	
1,2,3	0V	
5, 6, 17, 18	do not assign	
4	serial IN 2	
7	-RESET	
8	-WRITE EXTERN	
9	WRITE EXTERN	
10	-O5	
11	-O3	
12	-O1	
13	shield	
14, 15	+12V	
16	board ID (PK)	
19	serial IN 1	
20	control ready for operation	
21	-serial OUT	
22	serial OUT	
23	-O4	
24	-O2	
25	-00	

X2 Connection of 2. PL or PA		
Pin No.	Assignment	
1,2,3	OV	
4-6, 14 - 18	do not assign	
7	RESET	
8	-WRITE EXTERN	
9	WRITE EXTERN	
10	-O5	
11	-03	
12	-O1	
13	shield	
19	serial IN 2	
20	control ready for operation	
21	-serial OUT	
22	serial OUT	
23	-04	
24	-O2	
25	-00	

X3 PLC Inputs		
	Assignment	
Pin No.	as 1. PL	as 2. PL
1	164	1192
2	165	l193
3	166	l194
4	167	l195
5	168	l196
6	169	l197
7	170	l198
8	l71	l199
9	172	1200
10	173	1201
11	174	1202
12	175	1203
13	176	1204
14	177	1205
15	178	1206
16	179	1207

X4 PLC Inputs		
Pin No.	Assignment as 1. PL	as 2. PL
1	180	1208
2	l81	1209
3	182	I210
4	183	I211
5	184	1212
6	185	I213
7	186	1214
8	187	I215
9	188	1216
10	189	1217
11	190	I218
12	191	1219
13	192	1220
14	193	1221
15	194	1222
16	195	1223

Page 35 Issue: 20.08.95

X5 PLC Inputs		
Pin No.	Assignment as 1. PL	as 2. PL
1	196	1224
2	197	1225
3	198	1226
4	199	1227
5	l100	1228
6	l101	1229
7	l102	1230
8	l103	1231
9	l104	1232
10	l105	1233
11	l106	1234
12	l107	1235
13	l108	1236
14	l109	1237
15	l110	1238
16	l111	1239

X6 PLC Inputs		
Pin No.	Assignment as 1. PL	as 2. PL
1	l112	1240
2	l113	1241
3	l114	1242
4	l115	1243
5	l116	1244
6	l117	1245
7	l118	1246
8	l119	1247
9	I120 ¹⁾	1248 ¹⁾
10	I121 ¹⁾	1249 ¹⁾
11	I122 ¹⁾	I250 ¹⁾
12	I123 ¹⁾	I251 ¹⁾
13	I124 ¹⁾	I252 ¹⁾
14	I125 ¹⁾	I253 ¹⁾
15	I126 ¹⁾	I254 ¹⁾
16	I127 ¹⁾	I255 ¹⁾

X7 PLC Outputs		
Pin No.	Assignment as 1. PL	as 2. PL
1	O32	O64
2	O33	O65
3	O34	O66
4	O35	O67
5	O36	O68
6	037	O69
7	038	O70
8	O39	O71
9	O40	072
10	O41	073
11	O42	074
12	O43	O75
13	O44	076
14	O45	077
15	O46	078
16	O47	079

X8 PLC Outputs			
and "Control Ready for Operation"			
Pin No.	Assignment as 1. PL	as 2. PL	
1	O48	O80	
2	O49	O81	
3	O50	O82	
4	O51	O83	
5	O52	O84	
6	O53	O85	
7	O54	O86	
8	O55	O87	
9	O56	088	
10	O57	089	
11	O58	O90	
12	O59	O91	
13	O60	O92	
14	O61 ¹⁾	O93 ¹⁾	
15	O62 ¹⁾	O94 ¹⁾	
16	control ready	control ready for operation	

¹⁾ With active analogue inputs (depend on the position of the ENABLE ANALOGUE INPUTS switch on PL140) these PLC inputs and outputs are not available (see section 21.7.2).

Page 36 Issue: 20.08.95

X9, X10, X11, X12, X13, X14 PL Power Supply			
Terminal	Assignment	as 1. PL	as 2. PL
X9	0V	-	
X10	+24 V- supply of LE and "Con	+24 V- supply of LE and "Control Ready for Operation"	
X11	+24 V- output supply	032 - 039	064 - 071
X12	+24 V- output supply	040 - 047	072 - 079
X13	+24 V- output supply	048 - 055	080 - 087
X14	+24 V- output supply	056 - 062	088 - 094

X15 ¹⁾ , X16 ¹⁾ , X17 ¹⁾ , X18 ¹⁾ Analogue Inputs ± 10V		
Pin No.	Assignment	
1	voltage input (± 10V)	
2	OV	
3	shield	


X19 ¹⁾ , X20 ¹⁾ , X21 ¹⁾ , X22 ¹⁾ Inputs for PT 100 Thermistors Four-wire Connector with constant current source		
Pin No.	Assignment	
1	I+ constant current for PT 100	
2	U+ measuring input	
3	U- measuring input	
4	I- constant current for PT 100	
5	shield	

Allocation of Analogue Inputs to Internal PLC Memory Addresses			
Input	Internal	Memory Address	
	1. PL 410	2. PL 410	
X15	W496	W464	
X16	W498	W466	
X17	W500	W468	
X18	W502	W470	
X19	W504	W472	
X20	W506	W474	
X21	W508	W476	
X22	W510	W478	

¹⁾ not with version 11 of PL 410

Page 37 Issue: 20.08.95

6.2.7 Connectors on PA 110



Page 38 Issue: 20.08.95

6.2.8 Pin Layout: PA 110

X1 Connection to Logic Unit or 1.PL		
Pin No.	Assignment	
1, 2, 3	0 V	
4	serial IN 2	
5, 6, 17, 18	do not assign	
7	-RESET	
8	-WRITE EXTERN	
9	WRITE EXTERN	
10	-O5	
11	-O3	
12	-01	
13	shield	
14, 15	+ 12V	
16	board ID (PK)	
19	serial IN 1	
20	control ready for operation	
21	-serial OUT	
22	serial OUT	
23	-O4	
24	-O2	
25	-00	
	_	

X2, X3, X4, X5 Analogue Inputs ± 10V	
Pin No.	Assignment
1	voltage input (+/- 10 V)
2	0 V
3	shield

X6 PA 110 Power Supply	
Pin No.	Assignment
1	+24 V
2	OV


Thermistors	X7, X8, X9, X10 Inputs for PT 100 Thermistors Four-wire connector with const. current source		
Pin No.	Assignment		
1	I+ constant current for PT100		
2	U+ measuring input		
3	U- measuring input		
4	I- constant current for PT100		
5	shield		

Allocation of Analogue Inputs to Internal PLC Memory Addresses		
Input	Internal N	Memory Address
	PA as 1. expansion	PA as 2. expansion
X2	W496	W464
X3	W498	W466
X4	W500	W468
X5	W502	W470
X7	W504	W472
X8	W506	W474
X9	W508	W476
X10	W510	W478

Page 39 Issue: 20.08.95

6.3 Connectors on the Keyboard Units

6.3.1 Connectors on TE 400



Page 40 Issue: 20.08.95

6.3.2 Pin Layout: TE 400


X1 Connection of the Soft Keys of the VDU	
Plug-type conn	ector with female insert (9-pin)
Pin No.	Assignment
1	SL0
2	SL1
3	SL2
4	SL3
5	do not assign
6	RL15
7	RL14
8	RL13
9	RL12

] = kev matri:	X

X2 Connection to Logic Unit (LE)		
flange socket with male insert (37-pin)		
Pin No.	Assignment	
1	RLO	
2	RL1	
3	RL2	
4	RL3	
5	RL4	
6	RL5	
7	RL6	
8	RL7	
9	RL8	
10	RL9	
11	RL10	
12	RL11	
13	RL12	
14	RL13	
15	RL14	
16	RL15	
17	RL16	
18	RL17	
19	RL18	
20	SL0	
21	SL1	
22	SL2	
23	SL3	
24	SL4	
25	SL5	
26	SL6	
27	SL7	
28	SL19	
29	SL20	
30	do not assign	
31	RL21	
32	RL22	
33	RL23	
34	spindle override (wiper)	
35	feed override (wiper)	
36	+ 5V	
37	0V	

Issue: 20.08.95

6.3.3 Connectors on TE 410



Issue: 20.08.95

6.3.4 Pin Layout: TE 410

X1 Connection of the Soft Keys of the Logic Unit flange socket with female insert (9-pin)	
Pin No.	Assignment
1	SL0
2	SL1
3	SL2
4	SL3
5	do not assign
6	RL15
7	RL14
8	RL13
9	RL12

X2 Connection to the Logic Unit		
flange socket with male insert (37-pin)		
Pin No.	Assignment	
1	RLO	
2	RL1	
3	RL2	
4	RL3	
5	RL4	
6	RL5	
7	RL6	
8	RL7	
9	RL8	
10	RL9	
11	RL10	
12	RL11	
13	RL12	
14	RL13	
15	RL14	
16	RL15	
17	RL16	
18	RL17	
19	RL18	
20	SL0	
21	SL1	
22	SL2	
23	SL3	
24	SL4	
25	SL5	
26	SL6	
27	SL7	
28	RL19	
29	RL20	
30	do not assign	
31	RL21	
32	RL22	
33	RL23	
34	spindle override (wiper)	
35	feed override (wiper)	
36	+ 5V	
37	OV	

flange socket with male insert (37-pin)	
Pin No.	Assignment
1	I 128 unlock shelter door ³⁾
2	I 129 coolant ON/OFF
3	I 130 spindle OFF
4	I 131 NC OFF
<u>4</u> 5	I 132 NC ON
6 7	133 axis address key X-1 X+2
8	134 axis address key Y- 1) Z- 2)
9	135 axis address key Z- 1) Y- 2)
	136 axis address key Z+ 1) Y+ 2)
10 11	137 axis address key Y + 1) Z + 2)
12	I 138 axis address key X+ 1) X-2)
13	I 139 axis address key IV+
	I 140 axis address key IV-
14 15	I 141 rapid traverse
	I 142 spindle ON
16	do not assign
17	do not assign
18	do not assign
19	I 146 axis address key V+
20	I 147 axis address key V-
21	I 148 spindle probing operation
22	do not assign
23	do not assign
24	do not assign
25	do not assign
26	do not assign
27	do not assign
28	do not assign
29	do not assign
30	do not assign
31	do not assign
32	do not assign
33	do not assign
34	do not assign
35	do not assign
36	+ 24V - PLC
37	+ 24V - PLC

= key matrix

1) = TE versions 01/03

2) = TE versions 02/04


3) = TE Id.Nos. 264 105 05/06

Issue: 20.08.95

6.4 Connectors on the Visual Display Units

6.4.1 Connectors on the Visual Display Unit BC 110





6.4.2 Pin Layout: Visual Display Unit BC 110

X1 Connection to the Logic Unit flange socket with male insert (15-pin)	
Pin No.	Assignment
7	R analogue
9	V-SYNC
10	H-SYNC
11	0V
14	G analogue
15	B analogue

X2 Connection of the soft keys to the Keyboard Unit flange socket with male insert (9-pin)	
Pin No.	Assignment
1	SL0
2	SL1
3	SL2
4	SL3
6	RL15
7	RL14
8	RL13
9	RL12

X3 Power Connection	
Euro connector	


X4 DC Connection for Integral Fan		
terminal strip (2-pin)		
Pin No.	. Assignment	
1	+24V	
2	0V	

= key matrix

Issue: 20.08.95

6.4.3. Connectors on the Visual Display Unit BC 110 B





6.4.4 Pin Layout: Visual Display Unit BC 110 B

X1 Connection to the Logic Unit flange socket with male insert (15-pin)	
Pin No.	Assignment
7	R analogue
9	V-SYNC
10	H-SYNC
11	0V
14	G analogue
15	B analogue


X2 Connection of the Soft Keys to the Keyboard Unit		
flange socke	t with male insert (9-pin)	
Pin No.	Assignment	
1	SL0	
2	SL1	
3	SL2	
4	SL3	
6	RL15	
7	RL14	
8	RL13	
9	RL12	

I	X3 Power Connection
	terminal strip (3-pin)
	Assignment as labelled

X4 Test Output terminal strip (2-pin)	
Pin No.	Assignment
+	6V
-	0V

= key matrix

TNC 415 Block Diagram




Block Diagrams

SERVICE MANUAL TNC 415B/425Page 45
Issue: 20.08.95

Processor Board

CLP Board



Issue: 20.08.95

8. Board Description

LE 415B/425

PROCESSOR BOARD

- Interfaces

V.24/RS-232-C data interface V.11/RS-422 data interface HR 130/330 handwheel

- Monitoring function

EMERGENCY STOP

- Storage

Operating program (NC software)
PLC programs
Machine parameters
Compensation value lists
NC program (customized programs)

CLP BOARD

- Interfaces

Encoder inputs 3D touch probe

- Monitoring functions

Encoder inputs
Axis position
Program memory
Data processing
EMERGENCY STOP


PLC GRAPHICS BOARD


- Interfaces

57 PLC inputs
31 PLC outputs
Visual display unit
Keyboard unit
Machine operating panel
PLC I/O boards

- Monitoring functions

Temperature Voltages Buffer battery






Page 49 Issue: 20.08.95

Issue: 20.08.95

NOTES



Issue: 20.08.95

10. Power Supply


10.1 External Power Supply Requirements

The voltages must correspond to the following definitions:

Assemb	ly	Power Supply	Voltage Range DC Mean Value	Max. Current Consumption	Power Consumption
LE	NC	24V - (VDE 0551)	lower limit 20.4V upper limit	LE 415/425: 1.5A	LE 415/425: approx. 36W
	PLC	24V - (VDE 0550)	31V 1)	1.8A if half of the inputs/outputs are active simultaneously	approx. 6W if approx. 1/3 of the inputs/outputs are active simultaneously
PL 400 PL 410				21A if half of the inputs/outputs are active simultaneously	approx. 25W if approx. 1/3 of the inputs/outputs are active simultaneously
PA 110)			approx. 100mA	approx. 2.9W

¹⁾ Voltages up to 36V $\overline{\cdots}$ are permissible with t < 100ms.

10.1.1 NC Power Supply



The NC part of the LE must not be connected to the control voltage of the machine tool. It requires its own external power supply generated separately according to the German standard VDE 0551.


24V DC voltage with a permissible AC component (ripple voltage) of 1.5Vpp (recommended filtering capacitor 10 000µF/40V -).

10.1.2 PLC Power Supply

The PLC part (PLC inputs and outputs) of the LE, PL and PA is operated with a control voltage of 24V- of the machine tool (generated according to VDE 0550).

The installation and connection of the measuring resistors and the analogue inputs (PL 410, PA 110) must be safe from contact according to VDE 0160 (section 5.5.1).

If this cannot be ensured, PLC and PL 410 (PA 110) have to be powered according to VDE 0551. Superimposed AC voltage components arising from a non-controlled three-phase bridge connection with a ripple factor of 5% (see German standard DIN 40110/10.75, section 1.2) are permissible. Thus the highest absolute value for the upper voltage limit is 32.6V; the smallest value for the lower voltage limit is 18.5V.




The 0V line of the PLC power supply must be connected to the central signal ground (line $\varnothing \ge 6 \text{mm}^2$) of the machine tool. The ground connector on the PL410 housing must be connected to the protective ground (line $\varnothing \ge 6 \text{mm}^2$). To avoid ground loops the measuring voltage at the analogue inputs must not be grounded.


Issue: 20.08.95

10.1.3 Power Supply of the Visual Display Units

BC 110



BC 110B



X1 = connection of logic unit

X2 = keyboard connection (for soft keys)

X3 = Line connection		
Line voltage	110 V~	220 V~
Voltage range	85 132 V~	170 264 V~
Line fuse	F 3.15 A	F 3.15 A
Frequency	49 61 Hz	
Power consumption	60 W	

X4 = DC connection for fan		
Pin designation	Assignment	
1	+ 24 V	
2	0 V	

X1 = connection of logic unit

X2 = keyboard connection (for soft keys)

X3 = Line connection		
Line voltage	110 V~	220 V~
Voltage range	85 132 V~	170 264 V~
Line fuse	T 2.0 A	T 2.0 A
Frequency 49 61 Hz		61 Hz
Power consumption	60 W	

X4 = Voltage output for testing		
Pin designation Assignment		
+	6 V	
-	0 V	

The fan of BC 110B is supplied internally Note: with + 24V.

Page 53 Issue: 20.08.95

10.2 Power Supply of the NC


The power supply line of the NC is connected to the terminals of X31.


X31 NC power supply

Pin No.	Assignment
1	+ 24 V
2	0 V

The different voltages for the LE are transformed from the voltage fed (+24V) in the POWER SUPPLY assembly (see block diagrams in section 10.2.1).


The input and output voltages are displayed by LEDs. The states of the individual voltages are only displayed approximately by the LEDs. The exact values must be measured; the measured values must correspond to the table in section 10.2.1.





Issue: 20.08.95

10.2.1 NC Power Supply: Block Diagram



X2: connector (12-pin) of connecting cable "power supply <-> processor board"

X1: socket (12-pin) on processor board

Voltage Table

Test point on power supply board	Reference point on power supply board	Output	Unom [V]	Umin [V]	UMAX [V]	INOM [A]
LH22	LH24 (0V)	+ 5V (UP)	+ 5.05	+ 5.00	+ 5.10	2.5
LH20	LH24 (0V)	+ 12V	+ 12	+ 11.4	+ 12.6	0.1
LH18	LH24 (0V)	+ 15V	+ 15.0	+ 14.4	+ 15.6	0.15
LH14	LH24 (0V)	- 15V	- 15.0	- 14.4	- 15.6	0.08
LH10	LH24 (0V)	+ Иватт	+ 4.5	+ 3.9	-	approx. 20 μA
LH1	LH3 (0V*1)	+ 5V * 1 ¹⁾	+ 5	+ 4.75	+ 5.25	0.3
LH12 (reset) 2)						

¹⁾ potential-free voltage

²⁾ reset $U_{Lmax} = 0.4 \text{ V}$, $U_{Hmin} = 3.9 \text{ V}$

Page 55 Issue: 20.08.95

10.3 Checking the Power Supply Unit

Two low-voltage fuses are located on the POWER SUPPLY assembly. The fuse F 2.5A protects the output voltage of +24V BE (not required for TNC 415B/425), and the fuse F 4.0A protects the remaining voltages (see block diagram in section 10.2.1). If an error occurs in the power supply (all voltages missing), first check the +24V at the supply line (2-pin terminal strip X31) and then the low-voltage fuse F 4.0A.

The voltages can be measured directly on the power supply board, the processor board and the CLP board (sections 10.3.1 and 10.3.2).

The values and their tolerances can be seen from the corresponding tables. If the measured values deviate distinctly from the values in the table, the power supply assembly is defective.




Observe the safety instructions!

The power supply unit does not work without load. (Basic load is required)

Page 56 Issue: 20.08.95

10.3.1 Test Points on the Power Supply Board



Voltage Table

Test point on power supply board	Reference point on power supply board	Output	Unom [V]	Umin [V]	UMAX [V]	INOM [A]
LH22	LH24 (0V)	+ 5V (UP)	+ 5.05	+ 5.00	+ 5.10	2.5
LH20	LH24 (0V)	+ 12V	+ 12	+ 11.4	+ 12.6	0.1
LH18	LH24 (0V)	+ 15V	+ 15.0	+ 14.4	+ 15.6	0.15
LH14	LH24 (0V)	- 15V	- 15.0	- 14.4	- 15.6	0.08
LH10	LH24 (0V)	+ Иватт	+ 4.5	+ 3.9	-	approx. 20 μA
LH1	LH3 (0V*1)	+ 5V * 1 1)	+ 5	+ 4.75	+ 5.25	0.3
LH12 (reset) 2)						


¹⁾ potential-free voltage

²⁾ reset $U_{Lmax} = 0.4 \text{ V}$, $U_{Hmin} = 3.9 \text{ V}$

Page 57 Issue: 20.08.95


10.3.2 Test Points on the Boards

Processor board TNC 415B/425 ld.No. 268 553 -




Page 58 Issue: 20.08.95

CLP board TNC 425 Id.No. 265 401 -- and Id.No. 268 927 --



Page 58.1 Issue: 20.08.95



Page 59 Issue: 20.08.95

10.4 Power Supply of the PLC

The power supply line for the internal PLC of LE 415B/425 is connected to the terminal strip X44.

X44 PLC power supply of LE 415B/425

Terminal strip (pluggable) 3-pin

	99 , 1
Pin No.	Assignment
1	+ 24 V_A, can be switched off via EMERGENCY STOP
2	+ 24 V , cannot be switched off via EMERGENCY STOP
3	OV

Fuses: F1: 3.15A (+ 24V_A, can be switched off)

F2: 1.0A (+ 24V, cannot be switched off)

The PLC power supply of PL 400, PL 405, PL 410 or PA 110 is connected to the following terminal strips:

Power supply of PA 110

Pin No.	Assignment
1	+ 24 V - can be switched off via EMERGENCY STOP
2	OV

Power supply of PL 400

Terminal	Assignment
X13	+ 24 V can be switched off via EMERGENCY STOP
X12	OV
X3, pin 12	+ 24V_A cannot be switched off via EMERGENCY STOP

Power supply of PL 405 / 410


	011 2 100 / 110												
X9, X10, X11, X12, X13, X14 Power supply of PL													
Terminal	Assignment	1.PL	2.PL										
X9	OV												
X10	+ 24V- logic unit and "control ready	for operation"											
X11 ¹⁾	+ 24V- logic unit for outputs	O32 - O39	O64 - O71										
X12 ¹⁾	+ 24V- logic unit for outputs	O40 - O47	072 - 079										
X13	+ 24V- logic unit for outputs	O48 - O55	O80 - O87										
X14	+ 24V- logic unit for outputs	O56 - O62	O88 - O94										

Fuse: - F2: T1A (+ 24V- supply for logic unit)

¹⁾ not with PL 405

Issue: 20.08.95

10.4.1 PLC Power Supply: Block Diagram




1) can be powered with 24V or 24V_A

X44 Pin 1, +24V_A (PLC can be switched off): power supply for the PLC outputs O0 - O23. X44 Pin 2, +24V (PLC cannot be switched off): power supply for the PLC outputs O24 - O30 and output

"control ready for operation"; power supply for PLC graphics board.

Page 61 Issue: 20.08.95

10.4.2 Test Points on the PLC Graphics Boar



Page 61.1 Issue: 20.08.95

10.5 Buffer Battery

The buffer battery is the voltage source for the program memory when the machine tool is switched off.

If the error message


EXCHANGE BUFFER BATTERY

is generated, the batteries must be exchanged within one week.

The buffer batteries are located behind a screw fitting in the power supply of the LE. To exchange the batteries, open the LE by undoing the snaps.

In order to protect the program memory of TNC 415B/425, a capacitor (on the processor board) is used in addition to the batteries. Thus, the line voltage may be switched off during battery exchange.


Without the batteries the capacitor is capable of maintaining the memory contents for about one day.



3 AA-size batteries leak-proof IEC designation "LR6"



The capacitor is only being charged when the TNC is switched on.





Page 62 Issue: 20.08.95

11. Keyboard Unit TE 400/410


11.1 Overview

TE 400 Id.No. 250 517 ..






TE 410 Id.No. 258 645 ..



Page 63

Issue: 20.08.95

TE 410 Id.No. 264 105 ..



Page 64 Issue: 20.08.95

11.2 Checking the Keyboard Unit

The keyboard unit can be checked fast and reliably with the measuring adapter.

11.2.1 Checking the Key Functions

Proceeding:




Observe the safety instructions!

- Switch off the main switch.
- Disconnect the keyboard unit from the LE and connect the measuring adapter (see section 20) to the keyboard unit.

Now the contacts of the keys can be measured at the measuring adapter with an Ohmmeter.

If e.g. is pressed at the TNC operating panel, approx. 1 Ω can be measured at the adapter between PIN 8 and PIN 24 (see key matrix, section 11.2.3 and 11.2.4); consider the resistance of the testing wires.

11.2.2 Measuring Setup for Checking the Functions of the NC-Keys



Page 65 Issue: 20.08.95

11.2.3 Key Matrix of the Keyboard Unit

X2 Pin	1	2	3	4	5	6	7	8	9	17	18	19	28	29	31	32	20	21	22	23	24	25	26	27
Key	RLO	1	2	3	4	5	6	7	8	16	17	18	19	20	21	22	SL0	1	2	3	4	5	6	7
!										X							X							
#										x								x						
\$											x						X							
%											x							x						
\												X					X							
&												x						х						
*													X				х							
													x					x						
														x			X							
														x				x						
+															х		х							
															х			х						
X																х	х							
II										X								x						
Q										X										X				
W											х								x					
E											x									x				
R												x							x					
T												X								X				
Y													x						x					
U													x							х				
I														х					x					
0														х						x				
P															х				х					

Page 66

Issue: 20.08.95

X2 Pin	1	2	3	4	5	6	7	8	9	17	18	19	28	29	31	32	20	21	22	23	24	25	26	27
Key	RLO	1	2	3	4	5	6	7	8	16	17	18	19	20	21	22	SL0	1	2	3	4	5	6	7
															X					X				
RET																X			X					
CTRL										x											x			
A										x												x		
S											X										X			
D											x											х		
F												x									X			
G												x										х		
H													x								x			
J													x									х		
K														x							x			
L														X								x		
•															x						X			
															X							X		
																x					x			
SPACE										X													X	
Z										x														x
X											x												x	
C											X													x
V												x											X	
B												X												x
N													x										X	
M													x											x
,														x									х	

Page 67

Issue: 20.08.95

X2 Pin	1	2	3	4	5	6	7	8	9	17	18	19	28	29	31	32	20	21	22	23	24	25	26	27
Key	RLO	1	2	3	4	5	6	7	8	16	17	18	19	20	21	22	SL0	1	2	3	4	5	6	7
•														X										x
?															х								x	
															x									х
SPACE																x							x	
PGM NAME								х													x			
CL PGM							x														X			
PGM CALL						x															x			
EXT					X																X			
						x													x					
MOD		x																						х
	х																						x	
		x															x							
←			x																					х
					x																		x	
	x																							x
		x																					x	
			x																				x	
-				x																			x	
APPR DEP									X								Х							
									x									x						
									х										х					

Page 68

Issue: 20.08.95

X2 Pin	1	2	3	4	5	6	7	8	9	17	18	19	28	29	31	32	20	21	22	23	24	25	26	27
Key	RLO	1	2	3	4	5	6	7	8	16	17	18	19	20	21	22	SL0	1	2	3	4	5	6	7
CHF,									x											x				
L								x												x				
CR							X													x				
RND							x												х					
СТ?								x											x					
¢ cc						X														х				
$\mathcal{J}_{\mathbf{c}}$					х															х				
TOUCH PROBE				х													X							
CYCL DEF								X										X						
CYCL							X											X						
LBL SET						X												X						
LBL					X													X						
STOP					X														X					
TOOL DEF								х									х							
TOOL							X										х							
R ^L						X											х							
R ^R					X												х							
X				Х																	X			
7			X																		Х			
8		х																			Х			
9	х																				х			
Υ				X																X				
4			X																	X				

Page 69

Issue: 20.08.95

X2 Pin	1	2	3	4	5	6	7	8	9	17	18	19	28	29	31	32	20	21	22	23	24	25	26	27
Key	RLO	1	2	3	4	5	6	7	8	16	17	18	19	20	21	22	SL0	1	2	3	4	5	6	7
5		X																		x				
6	x																			X				
Z				x															x					
1			x																x					
2		x																	x					
3	x																		x					
IV				х														х						
0		x																x						
•			x															x						
⁻ /+	х																	x						
V									х												х			
									х													x		
+			x																			x		
Q			x														x							
CE					х																	x		
DEL				х																		x		
P				x																				x
I					х																			х
NO ENT		x																				x		
ENT	x																					x		
END	x																х							
1								х														x		
+						X																x		
ото П							x															x		
-								x															x	
•						x																	x	

Issue: 20.08.95

11.2.4 Key Matrix of the VDU Keys

X1 Pin ¹⁾	4b	3b	2b	1b	1a	2a	3a	4a
X2 Pin ¹⁾	13	14	15	16	20	21	22	23
Key ²⁾	RL12	RL13	RL14	RL15	SL0	SL1	SL2	SL3
∇				x		x		
SK1			x			x		
SK2		x				x		
SK3	x					X		
SK4				x			x	
SK5			x				x	
SK6		x					х	
SK7	х						х	
SK8				х				х
Δ			х					х
	x				x			
		X			x			

¹⁾ connector on keyboard unit

X1: connector for flat cable VDU ⇒ keyboard unit (plug-type connector)

X2: connector for cable keyboard unit ⇒ logic unit (D-SUB, 37-pin)

SK = soft key (SK1...SK8 from left to right)

²⁾ VDU key

Issue: 20.08.95

11.2.5 Checking the Potentiometers

Proceeding:




Observe the safety instructions!

Connect the measuring adapter to X45 of the logic unit. Now the wiper voltages of the potentiometers can be measured with a multimeter.

Potentiometer	PIN	Voltage
override F%	37 = 0V / 35 = + pot.	(0 to approx. 4.95)V
spindle S%	37 = 0V / 34 = + pot.	(0 to approx. 4.95)V

11.2.6 Measuring Setup for Checking the Potentiometers



Page 72 Issue: 20.08.95

11.2.7 Machine Operating Panel of TE 410

The PLC inputs of the machine operating panel of TE 410 (I128 - I148) can be tested at the flange socket X3 (37-pin) on the keyboard unit TE 410 or at the flange socket X46 (connection of machine control panel) of the TNC 415B/425.

For this purpose the TABLE function (see section 19.4) in the PLC mode is helpful as well.

KE of ve		Flange so KEYBOAF	cket X3 on RD UNIT	PLC
01/03	02/04	PIN	PIN	Input
IV+	IV+	12	36.37	l139
Z -1	Y'-1	8	36.37	l135
Y+ 7	Z +	10	36.37	l117
V+	V+	19	36.37	l146
X′+ ←	X′- ←	11	36.37	l138
	5	14	36.37	l141
X′- →	X′+ →	6	36.37	l133
Y- ∠	Z -	7	36.37	l134
Z '+\	Y '+\	9	36.37	l136
IV-	IV-	13	36.37	l140
V-	V-	20	36.37	l147

	EY ersion		Flange socket X3 on KEYBOARD UNIT			
05/06	1)	PIN	PIN	Input		
		3	36.37	l130		
		15	36.37	l142		
()_T	T	21	36.37	l148		
		1	36.37	l128		
4	4	2	36.37	l129		
NC 0	NC 0	4	36.37	l131		
NC I	C-	5	36.37	l132		

¹⁾ remaining versions

 $pin 36/37 = + 24V_PLC$


Page 73 Issue: 20.08.95

12. Visual Display Unit BC 110/B

12.1 Overview

BC 110 Id.No. 254 740 01


BC 110 B Id.No. 260 520 01



12.2 Checking the Visual Display Unit

BC 110 B, Id.No. 260 520 01

If the screen remains dark when the machine is switched on, first check the power supply (line voltage) of the VDU. If the voltage supply is functioning properly, a square highlighted filed can be generated on the screen of the VDU (which must be switched on) by pressing the external test button on the back side of the unit.



If the VDU generates this highlighted field, the PLC graphics board in the logic unit is probably defective. If however, the VDU remains dark after the test button was pressed, the VDU is defective and must be exchanged.

Page 74 Issue: 20.08.95

BC 110, Id.No. 254 740 01

If the screen remains dark when the machine is switched on, first check the power supply (line voltage) of the VDU. The control signals for the screen can only be checked with an oscilloscope.

The following diagrams were generated with the VISUAL DISPLAY UNIT connected. Depending on machine parameters and image depicted, the colour signals R-analog, Y-analog and B-analog may differ from those on page 75.

X43 Visual Display Unit (BC 110)

flange socket with female insert (15-pin)

Pin No.	Assignment
1, 8, 11	GND
2 to 6, 12, 13	do not assign
7	R signal
9	V SYNC
10	H SYNC
14	Y signal
15	B signal

Diagrams


2V/DIV 2V/DIV


10 ms/DIV

H-SYNC PIN 10

20 µs/DIV

Page 75 Issue: 20.08.95





¹ When measuring the colour signals directly at the output of the logic unit (without the VISUAL DISPLAY UNIT connected), the amplitudes are twice as large.

Issue: 20.08.95

13. Encoders

13.1 Error Messages for Axes with Analogue **Speed Controller**

ENCODER <AXIS> DEFECTIVE YA

A = signal amplitude error

ENCODER <AXIS> DEFECTIVE YB

B = signal frequency error

ENCODER <AXIS> DEFECTIVE YC

C = error with distance-coded scales

Y = CPU number 1 = main processor

2 = geometry processor

3 = CLP processor

13.1.1 Error Causes

- Glass scale contaminated or damaged
- Scanning head contaminated or defective
- Cable damaged
- Encoder input of the logic unit (LE) defective

13.1.2 Error Location

In order to determine whether the encoder or the encoder input of the logic unit is defective, the encoders can be switched at the logic unit. For this purpose the corresponding machine parameters must be altered as well:

Function		MP	Entry Value	
Allocation of the axes	Χ	110.0	0 = X1	
to the encoder inputs	Υ	110.1	1 = X2	
	Z	110.2	2 = X3	
	IV	110.3	3 = X4	
	V	110.4	4 = X5	
			$5 = X6^{1}$	


¹⁾ X6 may be used for a machine axis, if no oriented spindle stop is required.

Issue: 20.08.95

Flow-Chart for Error Location

ENCODER X DEFECTIVE 3B

(Example)





Observe the safety instructions!

Issue: 20.08.95

13.2 Error Messages for Axes with Integral Digital Speed Controller

With the integral digital speed controller there are **two** encoder inputs for each axis:

Encoder inputs for the actual position:

Encoder inputs for the actual speed:

encoder 1:	input X1	encoder 1:	input X15
encoder 2:	input X2	encoder 2:	input X16
encoder 3:	input X3	encoder 3:	input X17
encoder 4:	input X4	encoder 4:	input X18
encoder 5:	input X5	encoder 5:	input X19
encoder S:	input X6		

Therefore, there are **two** groups of error messages:

Monitoring of actual position capture (X1, X2, X3, X4, X5, X6)

ENCODER <AXIS> DEFECTIVE YA

A = signal amplitude error, position encoder

Y = CPU number 1 = main processor

2 = geometry processor 3 = CLP processor

B = signal frequency error, position encoder

ENCODER <AXIS> DEFECTIVE YC

C = error with distance-coded scales, position encoder

Monitoring of actual speed capture (X15, X16, X17, X18, X19)

ENCODER <AXIS> DEFECTIVE YA

A = signal amplitude error, speed encoder

ENCODER <AXIS> DEFECTIVE YB

Y = CPU number 1 = main processor

B = signal frequency error, speed encoder

2 = geometry processor 3 = CLP processor

ENCODER <AXIS> DEFECTIVE YC

C = error with distance-coded scales (speed encoder)

13.2.1 Error Causes

- Glass scale contaminated or damaged
- Scanning head contaminated or defective
- Cable damaged
- Encoder input of the logic unit (LE) defective

13.2.2 Error Location

In order to determine whether the one of the encoders of an axis or one of the encoder inputs on the logic unit is defective, the encoders can be switched at the logic unit. For this purpose the corresponding machine parameters must be altered as well (always change **both** parameters!):

Function		MP	Entry value
Allocation of the axes	Χ	110.0	0 = X1 (pos.) / X15 (speed)
to the encoder inputs	Υ	110.1	1 = X2 (pos.) / X16 (speed)
	Z	110.2	2 = X3 (pos.) / X17 (speed)
	IV	110.3	3 = X4 (pos.) / X18 (speed)
	V	110.4	4 = X5 (pos.) / X19 (speed)
			$5 = X6^{1}$ (pos.)


X6 can be used for a machine axis, if no oriented spindle stop is required.

Issue: 20.08.95

Flow-Chart for Error Location

ENCODER X DEFECTIVE 3B

(Example)





Page 80 Issue: 20.08.95

13.3 Electrical Inspection of an Encoder

In order to give a precise statement on the electrical function of an encoder, it must be measured with a phase angle measuring unit (PWM), an oscilloscope and a leak tester. (see operating instructions of encoder diagnostic set)

If no phase angle measuring unit is available, the electrical state of the cable, the lamp and the photocells of an encoder can be checked with an ohmmeter. The following resistances must be measured at the connector of the encoder:


Possible measurements at an encoder with current interface (7 - 16µA)

- encoder connector housing against machine chassis $< 1 \Omega$ (external shield)
- \bullet encoder connector housing against PIN 9 (internal shield external shield) R = ∞
- encoder connector housing against PIN 1 to PIN 8 (external shield signal lines) $R = \infty$
- PIN 9 against PIN 1 to PIN 8 (internal shield signal line) $R = \infty$

pin 1 against pin 2	0°		
• pin 2 against pin 1	0°	(switch poles of ohmmeter)	
pin 5 against pin 6pin 6 against pin 5	90° 90°	(switch poles of ohmmeter)	The measured values should approximately equal.
pin 7 against pin 8pin 8 against pin 7	RP ¹⁾ RP ¹⁾	(switch poles of ohmmeter)	
• pin 3 against pin 4 ²⁾		(approx. 5 - 30 Ω)	

- 1) If encoders with selectable reference mark are used, different resistance values can be measured (or no resistance), depending on the type of activation.
- ²⁾ The encoder check (pin 3 against pin 4) can only be carried out, if the encoder light unit is a lamp. If the encoder features an amplifier section, the light unit cannot be checked at all. With encoders with infrared diodes, a resistance in the conducting direction can be measured between pin 3 (+) and pin 4 (-).

Basic Circuit Diagram with Sinusoidal Signals (7 - 16µA)




Encoders with square-wave signals can only be tested with a phase angle measuring unit (PWM).

Page 81 Issue: 20.08.95

14. Electronic Handwheels


14.1 Handwheel HR 130/330

HR 130 Id.No. 254 040 -- HR 330 Adapter cable for HR 330 HR 130.001 Id.No. 249 371 -- Id.No. 251 534 -- Id.No. 249 889 --



14.1.1 Checking the Handwheel HR 130/330

The serial handwheel HR 130 (without auxiliary keys) and HR 330 (with auxiliary keys) can be checked with an oscilloscope. The following signals can be measured at the handwheel input X23 of LE 415B/425. The signals have to correspond to the diagram below.



The supply voltage for the handwheel is fed via the logic unit (X23 pin 2 = 0V, pin 4 = + 12V).


Page 82 Issue: 20.08.95

14.2 Handwheel HR 332

HR 332 Id.No. 266 064 -

Connecting cable Id.No. 272 292 -

Adapter cable Id.No. 274 556 01 (12-pin to 9-pin)




The assignment of the handwheel keys depends on the version.

Pin	Signal	
	designation	
2	0V	
4	+ 12V	
6	DTR	
7	TxD	
8	RxD	

14.2.1 Checking the Handwheel HR 332

The serial handwheel HR 332 can be checked with an oscilloscope. The following signals can be measured at the handwheel input X23 of LE 415B/425. The signals have to correspond to the diagram below.



t = 6ms

The supply voltage for the handwheel is fed via the logic unit (X23 pin 2 = 0V, pin 4 = + 12V).

^{*} The number of the permissive buttons and the internal wiring depends on the version of HR 332.

Page 83 Issue: 20.08.95

14.3 Error Messages

HANDWHEEL?

- Data transfer (cable) has been interrupted
- Incorrect value entered in MP 7640.

HANDWHEEL DEFECTIVE

The light unit in the electronic handwheel is not emitting enough light, with the result that the signals in the handwheel become too small. An error signal is sent over the serial interface of the handwheel.


Page 84 Issue: 20.08.95

3D-Touch Probes 15.


15.1 Overview


15.1.1 Touch Probes with External Interface Electronics (APE)

TS 111 Id.No. 237 400 --Transmission via cable




APE 110 Id.No. 230 465 -- for **TS 111 APE 510** Id.No. 227 590 -- for **TS 511 APE 511** Id.No. 237 586 -- for **TS 511** with additional connector for a second SE 510









SE 510 ld.No. 230 473 --






15.1.2 Touch Probe with Integral Interface Electronics (APE)

TS 120 ld.No. 243 614 --



Adapter cable for TS 120 Id.No. 244 891 --



Issue: 20.08.95

15.2 Error Messages

15.2.1 Error Messages in the Probing Mode

TOUCH POINT INACCESSIBLE

- After the start of a probing function, the scanning point was not reached within the measuring range defined in the machine parameter MP6130.

EXCHANGE TOUCH PROBE BATTERY

- The battery voltage of the touch probe system with infrared transmission is below the minimum value.

STYLUS ALREADY IN CONTACT

- The stylus was already deflected when the probing function was started.

PROBE SYSTEM NOT READY

- The infrared transmission between the "Touch Probe" and the "Transmitter/Receiver Unit" is faulty (e.g. caused by contamination) or interrupted. The two windows of the touch probe system must be oriented to the transmitter/receiver unit.
- The battery is dead.
- The TM 110 is not connected.
- An error has been detected at one of the encoders of the TM110 (contamination).

15.2.2 Error Messages during Digitizing of 3D-Contours

WRONG AXIS PROGRAMMED

- The touch probe axis in the scanning cycle **RANGE** is not identical with the calibrated touch probe axis.

FAULTY RANGE DATA

- A MIN coordinate value in the scanning cycle **RANGE** is larger than or equal to the corresponding MAX coordinate value.
- One or more coordinates are beyond the limit switch range of the scanning cycle **RANGE**.
- No scanning cycle **RANGE** was defined when calling the scanning cycles **MEANDER** or **CONTOUR** LINES.

MIRRORING NOT PERMITTED

ROTATION NOT PERMITTED

SCALING FACTOR NOT PERMITTED

- Mirroring, rotation or scaling factor were active when the scanning cycles **RANGE**, **MEANDER** or **CONTOUR LINES** were called.

Page 86 Issue: 20.08.95

RANGE EXCEEDED

- The range has been exceeded during probing, i.e. a part of the 3D-contour is outside the range.

CYCL PARAMETER INCORRECT

- The programmed travel or the distance between lines or points is negative or larger than 56 535 mm. (only possible with Q-parameter programming)

TOUCH POINT INACCESSIBLE

- The stylus was deflected before the range was reached during approach.
- In the cycle CONTOUR LINES, the stylus was not deflected within the probing range.

STYLUS ALREADY IN CONTACT

- The stylus is not at rest, although it is not touching the contour.

PLANE WRONGLY DEFINED

- One of the coordinates of the starting point in the cycle CONTOUR LINES is identical with the touch probe axis.

START POSITION INCORRECT

- The starting point coordinate that is identical with the starting probe-axis is beyond the range.

AXIS DOUBLE PROGRAMMED

- The same axis has been programmed for both starting point coordinates in the cycle CONTOUR LINES.

TIME LIMIT EXCEEDED

- In the scanning cycle CONTOUR LINES the first point of the scanned line was not reached within the programmed time limit.

STYLUS DEFLECTION EXCEEDS MAX.

- The stylus was deflected by more than the value programmed in the machine parameter MP6330 (TM110).

Page 87 Issue: 20.08.95

16. Data Interfaces

16.1 Operating Modes of the Data Interfaces

For data transfer the TNC 415B/425 can be switched to the following 6 interface modes:

ME: For connection of the HEIDENHAIN Magnetic Tape Unit ME 101/102 or other peripheral units (e.g. printer).

aah

Data format and protocol adapted to ME! Protocol: standard transfer

Data format: 7 data bits, 1 stop bit, even parity

Baud rate: 110 - 2400 Baud

Interface parameter: fixed

Transmission stop: DC3 (software handshake)

FE 1: For connection of the HEIDENHAIN Floppy Disk Unit FE 401 B (or the Floppy Disk Unit FE 401, from software 230 626 **03**) or other peripheral units.



Data format and protocol adapted to FE 401/B!

Protocol: blockwise transfer

Data format: 7 data bits, 1 stop bit, even parity Baud rate: 110 - 38400 Baud (FE 401B)

9600 Baud (FE 401)

Interface parameter: fixed

Transmission stop: DC3 (software handshake)

FE 2: For connection of the HEIDENHAIN Floppy Disk Unit FE 401 or other peripheral units.



Data format and protocol adapted to FE 401/B!

Protocol: blockwise transfer

Data format: 7 data bits, 1 stop bit, even parity

Baud rate: 110 - 38400 Baud 9600 Baud (FE 401)

Interface parameter: fixed

Transmission stop: DC3 (software handshake)

EXT 1:To adapt the transfer of data to external units in standard data format **EXT 2:**and for blockwise transfer.

Rom

Protocol: standard or blockwise transfer

adaptation from machine parameter MP 5000

Data format: adaptation from machine parameter MP 5000

Baud rate: 110 - 38400 Baud

Interface parameters: adaptation from machine parameter MP 5000

Transmission stop: DC3 (software handshake) or RTS (hardware handshake)

selectable as of MP5000

LSV/2: With the LSV/2 protocol several functions (such as file management, remote control and TNC diagnosis from a PC) can be performed with the appropriate software (TNC REMOTE or LSV/2 TOOLBOX).

Page 88 Issue: 20.08.95

16.1.1 Interface Configuration and Allocation of the **Operating Modes**

In the operating modes PROGRAMMING AND EDITING and TEST RUN the setup menu for the data

interfaces is called after pressing and the soft key

RS 232 RS 422 SETUP

MANUAL OPERATION	PROGRAMMING	AND EDITING	
RS232	INTERFACE	RS422 INTERFACE	
BAUD REFE : EXT1 : EXT2 :	F OP.: LSV2 ATE 38400 9600 9600 38400	MODE OF OP.: FE BAUD RATE FE : 9600 EXT1 : 9600 EXT2 : 9600 LSV2 : 9600	1
ASSIGN	*		
PROGRAM PROGRAM TEST RU	M RUN: RS232	PRINT : RS	
O RS	USER HELP		END

On the left half of the screen the RS-232-C interface is configured, on the right half the RS-422-C. On the lower left of the screen the operating modes PROGRAMMING/EDITING, PROGRAM RUN and TEST RUN can be allocated to either RS-232-C or RS-422-C. (If the MOD function "RS 232/RS 422 SETUP" is called in the PLC editor or the MP editor, the editor can be allocated to one of the interfaces.)

On the lower right of the screen the user can define via PRINT or PRINT TEST, whether outputs with FN15 and digitized positions are to be output via one of the interfaces or into a file in the memory of the control.

Data are output via the data interface RS-232-C. • RS 232 means: • RS 422 means: Data are output via the data interface RS-422-C.

• FILE means: Data are filed in the TNC.

In the machine parameter MP5000 individual interfaces can be disabled.

Page 89 Issue: 20.08.95

END



(operating mode, baud rate, interface allocation) can be selected and set according to your requirements by pressing ENT.


To exit the MOD function RS 232/RS 422 SETUP, press the soft key

16.2 Machine Parameters for the Data Interfaces

In the operating modes ME, FE 1, FE 2 and LSV/2 the interface parameters cannot be changed.

In the operating modes EXT 1 and EXT2 the interface parameters can be set via machine parameter (starting with MP5000).

The detailed functions of the individual machine parameters please see from the "Technical Manual" or from the "Description of the Data Interfaces TNC 407/415" (Id.No. 275 931 –).



Page 90 Issue: 20.08.95

16.3 Error Messages

16.3.1 Error Messages at the TNC in the ME Mode

WRONG OPERATING MODE

The wrong operating mode or no operating mode was selected on the external data medium.

WRONG PROGRAM DATA

Wrong program data have been detected during data transfer. The control attempted three times to read the data from the magnetic tape before interrupting the process.

DATA MEDIUM MISSING

No cassette has been inserted into the drive.

DATA MEDIUM EMPTY

No programs are stored on the data medium (cassette).

DATA MEDIUM WRITE-PROTECTED

The write-enable plug on the cassette is missing.

PROGRAM INCOMPLETE

Data transfer was interrupted before the program was transferred completely.

EXT. INPUT/OUTPUT NOT READY

The DSR-signal is missing at the TNC.

- ME not connected.
- Defective or wrong transfer cable.
- Wrong interface assignment.

ME: TAPE END

The cassette is full. To continue data transfer, turn over or exchange the cassette.

Page 91 Issue: 20.08.95

16.3.2 Error Messages at the ME

In the ME the electronics is tested, and the external operating conditions are checked. If an error is detected, the lamps of the operating mode display start blinking. In the following table the error types are listed:

O LED off

* LED blinking

Indicator Lamp	Error Message	
000 *	Faulty data during transfer	
00 * 0	No cassette inserted	
00 ** 0000	Write-enable plug in cassette missing	
0 * 00	Wrong operating mode selected	
0 * 0* 0000	Data of magnetic tape faulty	
0 ** 0 0000	Magnetic tape empty	
*000 0000		
00 0000		
*0*0 0000	Errors in ME electronics	
*O** 0000		
**00 0000		
**O* 0000		
**** 0000	End of tape	
O*** 0000	Peripheral unit not connected	
***O 0000	Data transfer between TNC and ME or peripheral unit was interrupted with	

Page 92 Issue: 20.08.95

16.3.3 Error Messages at the FE in the ME-Mode

In the ME-mode, errors are displayed by blinking indicator lamps (LEDs).

O LED off

• LED on

★ LED blinking

Indicator Lamp	Error Message
000● 0 * 00	Disk missing or error in the ME electronics
000 * 0 * 00	Disk cannot be formatted, as it is currently being used
*00● *000	Disk missing or not formatted
00 *000	Disk cannot be copied, as a read/write process is active
●○ * ● ○○○○	External unit not ready or not connected
* ○●● ○○○○	Disk missing or not formatted
* ○○● ○○●○	Disk missing or not formatted or no program available
O•	Program cannot be output, as a transfer is active via the TNC interface
00 00•0	Program cannot be output, as a transfer is active via the PRT interface
00*●	External unit not ready or not connected
00●● * 000	Disk missing or not formatted
000●	Disk missing or not formatted
00● * * 000	Program cannot be output, as a transfer is active via the TNC interface
000* *0•0	Program cannot be output, as a transfer is active via the PRT interface
O●O● OO * O	External unit not ready or not connected
O * ○● ○○●○	Disk missing or error in the ME electronics
O*O* ○○●○	Table of contents cannot be output, as a transfer is active via the PRT interface
000 * 00●0	No interface coupling possible, as a transfer is active via the TNC interface
00 ●* 0000	No interface coupling possible, as a transfer is active via the PRT interface
00 * ● 0000	External unit not ready or not connected

sto

the error messages can be cleared.

Page 93 Issue: 20.08.95

16.3.4 Error Messages at the TNC in the FE Mode

In this operating mode, the floppy disk unit outputs errors in the following format:

(SOH) ERR: (SP) (SP) (SP) [XXX] (ETB) (BCC)

XXX = error number

The following errors can be displayed on the screen:

Input/Output Errors

ERR: 001 = wrong command code ERR: 002 = illegal program name ERR: 003 = faulty data transfer ERR: 004 = program incomplete ERR: 005 = receiving buffer overflow ERR: 006 = function currently disabled ERR: 007 = data-buffer overflow

Errors during Program Write or Read

ERR: 010 = program not on disk
ERR: 011 = program erase-protected
ERR: 012 = program is being written to

ERR: 013 = program directory is full

ERR: 014 = disk is full ERR: 015 = text not found

ERR: 016 = program name already exists

ERR: 017 = disk access active

ERR: 018 = program currently being read

Disk / Drive / Controller Errors

ERR: 100 = disk not initialized

ERR: 101 = sector number too large 1)

ERR: 102 = drive not ready 2)

ERR: 103 = disk is write-protected

ERR: 104 = faulty data on disk 1)

ERR: 105 = sector cannot be found1)

ERR: 106 = check sum incorrect 1)

ERR: 107 = disk controller defective 3)

ERR: 108 = DMA defective 3)

ERR: 109 = disk exchanged during program loading

- These error messages indicate that the disk is defective; in most cases, they can only be eliminated by formatting the disk anew.
- 2) If this error message comes up while the disk is inserted, the drive is probably defective.
- 3) Hardware defect

Page 94 Issue: 20.08.95

16.3.5 Error Messages during Data Transfer

TRANSFERRED VALUE ERRONEOUS X

- X = A faulty character frame
 - B character overflow
 - C faulty character frame or character overflow
 - D parity error
 - E faulty character frame or parity error
 - F character overflow or parity error
 - G faulty character frame or character overflow or parity error
 - H receiving-buffer overflow
 - K l incorrect ESC sequence (only in ME mode)

TRANSFERRED DATA INCORRECT X

- X = A faulty character frame
 - D parity error
 - M control has received the character for "negative acknowledgement" (NAK) more than 3 times
 - N control has sent the character for "negative acknowledgement" (NAK) more than 3 times

BAUD RATE NOT POSSIBLE

If both data interfaces (RS 232 / RS 422) are activated simultaneously, the baud rates of **both** interfaces must be the same.

INTERFACE ALREADY ASSIGNED

A data interface cannot be used for two operating modes simultaneously. (e.g. DNC mode and programming at the same time is not possible with one data interface.)

EXT. IN-/OUTPUT NOT READY

- DSR signal at the TNC missing
- Defective or wrong transfer cable
- Wrong interface assignment


PROGRAM INCOMPLETE

Data transfer was interrupted before the program was completely loaded.

Page 95 Issue: 20.08.95

16.4 Wiring Diagrams of the Data Interfaces

16.4.1 RS-232-C Data Interface with RS-232-C Adapter Block (full wiring)




and J

If the pin layout of your peripheral unit differs from the above layout, the HEIDENHAIN connecting cable may not be used.

16.4.2 RS-232C Data Interface with RS-232C Adapter Block (simplified wiring)

Example:




ad

With this wiring, only transfer stop with DC3 is possible (software handshake).

The RS-232-C data interface has **different** pin layouts at the logic unit X21 and the RS-232-C adapter block.

Page 96 Issue: 20.08.95

16.4.3 RS-422 Data Interface





The RS-422 data interface has **identical** pin layouts at the logic unit X22 and at the RS-422 adapter block.

Page 97 Issue: 20.08.95

17. Data Input and Output

17.1 Data Transfer Menu

In the operating mode PROGRAMMING/EDITING (press

), the data transfer menu is activated by

pressing

STROM- UNTERBRECH FEHLER	UNG PR	OGRA	MM-E:	INSP	EICH	HERN/	EDITIE	EREN
TNC:				R	S232/FE1	:		
DATEI-NAM	1E	BYTE	STATUS		DATEI-NA	ME S	SEKTOREN ST	ATUS
\$MDI	•H	6	М	DF	REHUNG	•H	1	
Х	•H	74		E	CKE	•H	1	
XY	•H	86		F	AKTOR	•H	1	
XVZ	•H	98		42	25	•P	1	
XVZ1	•H	98						
TOOL	• T	1820	М					
V- 2 4	• T	1820						
789	•P	108						
1	•D	5632						
TEST-PRO	•A	76	E					
10 DATEI	EN) 15744	10 BYTE I	FREI	4	DATEI	(EN) 759	SEKTOREN F	RE I
PAGE	PAGE ↓	TRANSFI TNC ⇒E	n∣⊃∍	FER THE	RANSFER	SELECT TVPE	m INDOM	END

On the left half of the screen the memory contents of the TNC is displayed; on the right half the memory contents of the peripheral unit.

The memory contents of the peripheral unit is only displayed automatically in the interface mode FE1. In all

other operating modes it can be loaded by means of the soft key

DIRECTORY .

SHOW EXT.

To switch between the screen halves press the arrow keys

By switching the screen half the **direction** of data transfer is changed.

Page 98 Issue: 20.08.95

Explanation of the soft keys:





The program **selected** with



is read in or out.



All programs are read in or out without confirmation.



All programs are read in or out after confirmation.



The following soft keys may be offered depending on the interface mode:

FE1 mode (external directory is loaded automatically):





All file types are displayed.



Only the files with this extension are displayed. e.g. (•H = NC program in HEIDENHAIN plain language)

FE2 / EXT1 / EXT2 mode:

SHOW EXT.	SHOW	SHOW	SHOW	SHOW	SHOW	SHOW	
DIRECTORY	•H	T	I.	₽.	.D	.A	END



Only the files with this extension are displayed. e.g. ($\cdot H = NC$ program in HEIDENHAIN plain language)

SHOW EXT. DIRECTORY

The external directory is loaded.



This soft key cancels the split screen display. Afterwards several settings can be made in the screen half selected before. After pressing the soft key once again, the screen is split again.

ſ	PAGE	PAGE	SELECT	COPY	SELECT	MINDOM	
	Û	Û		ABC)⇒XYZ	TVPE		END

Page 99 Issue: 20.08.95

17.2 Overview of Files for TNC 415B/425

Depending on the subordinate mode (NC, PLC MODE, MP MODE etc.) in which the transfer menu is activated, only certain file types are offered to be downloaded or output.

The following data may be in the RAM:

NC Memory Management	Extension (TNC)	Extension (external)
NC program: HEIDENHAIN language	.H	.H
NC program: ISO	.1	.D
Active tool file	TOOL.T	TOOL.T
Tool data (table)	.Т	.Т
Pocket number table		TOOL_P.R
Pallet table	.P	.L
Datum table	.D	.N
Text file (ASCII)	.Α	.A
Measuring point table (digitizing)	.PNT	.U
PLC Memory Management (RAM)		
PLC program	.PLC	.P
Error messages 1. language	.ER1	.A
Error messages English	.ERE	.A
Dialogues 1. language	.DI1	.A
Dialogues English	.DIE	.A
ASCII file	.Α	.A
Help texts	.HLP	.J
Data for axis error compensation	.COM	.V
Data for axis error compensation	.CMA	.S
Machine Parameter Mode		
Machine parameter lists	.MP	.M
Compensation value table	.KOR	.S
selectable via code number		

Additional information on the files or programs is provided by letters in the status field.

- E: The file/program has been selected in the PROGRAMMING mode.
- S: The file/program has been selected and activated in the TEST RUN mode.
- M: The file/program has been selected and activated in either PROGRAM RUN / FULL SEQUENCE or in PROGRAM RUN / SINGLE BLOCK.
- P: The file/program is protected against erasing and editing.
- IN: The table/program was programmed in Inch.
- W: The file/program was not completely transferred to an external memory and thus is no longer available.

17.3 External Data Output

Preparations:

- Connect the external data medium (FE, ME or other peripheral unit, e.g. personal computer with HEIDENHAIN data transfer software) to the TNC.
- Prepare the external data medium for data transfer:

Press TNC and at the ME

Press at the FE.

- Select the operating mode, the baud rate and the interface assignment at the TNC (see section 16.1).


Page 100 Issue: 20.08.95

17.3.1 Output of Files with the Extensions .H, .I, .T, .D, .P, .A, .PNT

Press Key	Function
♦	Operating mode PROGRAMMING/EDITING
E \$\$\frac{1}{2}\$	Activate data transfer menu

The different file types are distinguished by the file name and the extension.

In the TNC there are the following six different file types that can be selected via soft key:



¹⁾ The file **TOOL.T** (active tool table) must be read out in another operating mode (see section 17.3.2)

²⁾ see section 17.2

Page 101 Issue: 20.08.95

17.3.2 Output of TOOL.T File (Active Tool Table) and of POCKET-TABLE

Press Key	Function
	TNC in MANUAL operating mode
TOOL TABLE	Call tool table
E	Activate data transfer menu
TRANSFER TNC ⇒ EXT	Read out tool table
	The active tool table is output to the external data medium; filename: TOOL.T
POCKET TABLE	Call pocket table
EXÎ	Activate data transfer menu
TRANSFER TNC ⇒ EXT	Read out pocket table
	The POCKET TABLE is output to the external data medium; filename: TOOL_P.R
END	Exit subprogram

Page 102 Issue: 20.08.95

17.3.3 Output of the Machine Parameter List <NAME>.MP

NOTE:

The TNC only displays the external directory in the FE1 mode.

Press Key	Function
\Diamond	TNC in operating mode PROGRAMMING AND EDITING
MOD	Prepare TNC for entry of code number
9 5 1 4 8 ENT	Enter code number and confirm with ENT
MOD	Here an interface can be allocated to the MP editor
END	
EXT	Activate data transfer menu
There may be several files with the extension .MP in t by the STATUS M .	he TNC. The active machine parameter list is distinguished
TRANSFER TNC ⇒ EXT	Soft key for data transfer
END	Exit data transfer menu
END	TNC in operating mode PROGRAMMING AND EDITING

Page 103 Issue: 20.08.95

17.3.4 Output of the Compensation Value List for Multipoint Axis Error Compensation <NAME>.KOR

NOTE:

The TNC only displays the external directory in the FE1 mode.

Until NC software 259 93x.**07** and 259 94x.**07** the compensation values and the axis relations were filed in **one** table (file with extension **.KOR**). This file is stored in the RAM of the TNC and can be read out.


Press Key	Function
◆	TNC in operating mode PROGRAMMING AND EDITING
MOD	Prepare TNC for entry of code number
1 0 5 2 9 6 ENT	Enter code number and confirm with ENT
EKÎ	Activate data transfer menu
TRANSFER TNC ⇒ EXT	Press soft key
	The file <name>.KOR is stored on the external data medium as <name>.S</name></name>
END	Exit data transfer menu
END □	TNC in operating mode PROGRAMMING AND EDITING

Page 104 Issue: 20.08.95

NOTE:

The TNC only displays the external directory in the FE1 mode.

As of NC software 259 93x.**08** and 259 94x.**08** the compensation values and axis relations can be stored as files with the extensions .**COM** and .**CMA**.






If no .CMA file is defined and multipoint axis error compensation selected via MP730, the compensation value tables of the code number 105296 are valid.

Page 105 Issue: 20.08.95

17.3.5 PLC File Management



The PLC is subdivided into two **internal** drives.

Drive TNC:

PLC files in RAM 1)

Drive TNC/EPROM: PLC files in PLC EPROM 1)

The following files may be stored:

PLC programs		.PLC
Error messages	 language 	.ER1
Error messages	English	.ERE
Dialogues	 language 	.DI1
Dialogues	English	.DIE
ASCII files		.A
Help texts		.HLP
Data for axis error compensation		.COM
Data for axis error compensation		.CMA

For each half of the screen the required "drive" can be selected by soft key.

¹⁾ Between the PLC RAM and the PLC EPROM similar functions are possible as between the RAM and external data medium.

Page 106 Issue: 20.08.95

Selecting the Drives

MANUAL OPERATION ERROR PLC PROGRAMMING		
TNC:	TNC/EPROM:	
FILE NAME BYTES STATUS	FILE NAME BYTES STATUS	
252499XA .PLC 14612 M	252499XA .PLC 12098 P	
3DT_SCHA .PLC 1560	4XXER1 .ER1 1402 P	
AUX_FUNK .PLC 5298	4XXERE •ERE 1402 P	
BE_STD_Z .PLC 2818	4XXDI1 .DI1 3154 P	
CLRPLCWI .PLC 216	4XXDIE .DIE 2290 P	
CYCL_FUK .PLC 1730		
EO_MODUL .PLC 154		
HANDRAD .PLC 852		
HIRTH .PLC 6152		
HR330 .PLC 1900		
HR332 .PLC 2276		
HRA110 .PLC 812		
40 FILE(S) 47616 BYTES VACANT	5 FILE(S) 106752 BYTES VACANT	
PAGE PAGE	SELECT WINDOW END	

Press Key	Function
or -	Select the window to be modified
or D	Switch soft key row
MODIFY WINDOW	Press soft key

Page 107 Issue: 20.08.95

MANUAL OPERATION	PLC PROGRAMMING	
ERROR	FILE NAME = HIR	TH .PLC
TNC:		
FILE NAME	BYTE	S STATUS
252499	XA .PLC 146	12 M
3DT_SCH	1A .PLC ₁₅₆	Ø
AUX_FUI	NK .PLC 529	8
BE_STD.	_Z .PLC ₂₈₁	8
CLRPLC	JI .PLC 216	
CYCL_FU	JK .PLC ₁₇₃	0
EO_MODU	JL .PLC ₁₅₄	
HANDRA	.PLC ₈₅₂	
HIRTH	.PLC 615	2
HR330	.PLC ₁₉₀	Ø
HR332	.PLC 227	6
HRA110	.PLC 812	
40 FILE(S)	47616 BYTES VACANT	
PAGE P	PAGE SELECT COPY MOD ABC XYZ WIN	

Press Key		Function
I	LECT XX	Assign the "drive" by pressing a soft key
Е	N D	Press soft key
	or	Switch soft key row back

Page 108 Issue: 20.08.95

17.3.6 Output of Files from PLC Memory

NOTE:

The TNC only displays the external directory in the FE1 mode.

Overview of the Files

DI O		DI O
PLC programs		.PLC
Error messages	 language 	.ER1 ¹⁾
Error messages	English	.ERE 1)
Dialogues	 language 	.DI1 ¹⁾
Dialogues	English	.DIE 1)
ASCII files		.A 1)
Help texts		.HLP
Files for axis error compensation		.COM ²⁾
Files for axis error compensation		.CMA ²⁾

1) Note:


The error messages, dialogues and ASCII files are output as ASCII files with the extension **.A**. Therefore, the files to be output must have different filenames so that they will not be overwritten on the external data medium.

RENAME ABC = XYZ

(to rename a files, press the soft key

Note down filename and the extension!

After having downloaded the files, the extension .A must be reconverted to the original extension



by pressing the soft key

2) see section 17.3.4



There may be several files with the same extension in RAM. Note down status information (see section 17.2).

Page 109 Issue: 20.08.95

Press Key	Function
\Longrightarrow	TNC in operating mode PROGRAMMING AND EDITING
MOD	Prepare TNC for entry of code number
8 0 7 6 6 7 ENT	Enter code number and confirm with ENT
EXT	Activate data transfer menu
in interface mode FE 1 SELECT SHOW ALL TYPE	Soft keys to display all file types
otherwise: SELECT TYPE *** FILES	List desired file type
	Select desired file with arrow keys (if necessary)
RENAME ABC = XYZ	Rename file with soft key (if necessary)
TRANSFER TNC) ⇒ EXT	Start data transfer 1)
	Output further file, if desired
END	Soft key to exit the data transfer menu
END □	TNC in operating mode PROGRAMMING AND EDITING

¹⁾ see section 17.1

Page 110 Issue: 20.08.95

17.4 Downloading External Data


Preparations:

- Connect the external data medium (ME, FE or other peripheral unit) to the TNC.
- Prepare the external data medium for data transfer:



• Select the operating mode, the baud rate and the interface assignment (see 16.1) at the TNC.

17.4.1 Downloading files with the Extensions .H, .I, .D, .P, .T, .A






The TOOL.T file (active tool table) must be downloaded in another operating mode (see section 17.4.2).

Page 111 Issue: 20.08.95

17.4.2 Downloading TOOL.T Files (Active Tool Table) and the POCKET TABLE



Page 112 Issue: 20.08.95

17.4.3 Machine Parameter Input <NAME>.MP

Press Key	Function
♦	TNC in operating mode PROGRAMMING AND EDITING.
MOD	Prepare TNC for input of code number.
9 5 1 4 8 ENT	Enter code number, confirm with ENT.
MOD	Here, the MP editor can be assigned to an interface.
END	
₽	Activate data transfer menu.
	Press arrow key to enter the directory of the external data medium.
interface mode	
atherwise.	If necessary: select the desired MP file by pressing the arrow keys.
otherwise:	Enter name of MP file (ASCII or numerical keys).
TRANSFER (TNC) & EXT	Soft key for data input.
END	Exit the data transfer menu ¹⁾
END □	The machine parameter file loaded in the editor is activated (receives the status M , see section 17.3.3).

¹⁾ If several MP files are downloaded after each other, the TNC activates the MP list downloaded last.

Page 113 Issue: 20.08.95

When the error message

OPERATING PARAMETERS ERASED

is displayed, enter the machine parameter file <NAME>.MP as follows:

(see section 2.1)

Press Key	Function
CE	Clear the error message
	OPERATING PARAMETERS ERASED
MOD	Configure the interface (see section16.1)
END	Activate the data transfer menu.
interface mode FE1	
0 0	If necessary: select the desired MP file by pressing the arrow keys.
otherwise	Enter the name of the MP file (ASCII or numerical keys).
TRANSFER TNC) ← EXT	Start data transfer.
END	Exit the data transfer menu.
END	The machine parameter file loaded in the editor is activated (receives the status M , see section 17.3.3).


Page 114 Issue: 20.08.95

17.4.4 Input of the Compensation Value List for Multipoint Axis Error Compensation <NAME>.KOR

NOTE:

The TNC displays the external directory only in the FE1 mode.


Until NC-software 259 93x.**07** and 259 94x.**07** the compensation values and the relations are filed in **one** table (file with extension **.KOR**).



Page 115 Issue: 20.08.95

From NC-software 259 93x.**08** and 259 94x.**08** the compensation values and the relations can be stored in files with the extensions .**COM** and .**CMA**.

If there is no <NAME>.**CMA** file on the external data medium, the compensation value tables from the code number 105 296 are valid. These files can be read in as described in section 17.4.4.




1) Caution:

Until the software version 12 the dimensions "MM" must be contained after the file name in the header of a <NAME>.COM file; otherwise the file cannot be read in (if required, use a text editor to insert MM)

Example of a header: BEGIN X-AXIS.COM MM DATUM:+90 DIST:2

Page 116

Issue: 20.08.95




Page 117 Issue: 20.08.95

17.4.5 Downloading PLC Program, Error Messages, Dialogues and Help Texts

NOTE:

The TNC displays the external directory only in the FE1 mode.

The error messages and the dialogues are downloaded as **ASCII** files (<NAME>.A). They need to be converted to their original file types afterwards.




Page 118 Issue: 20.08.95



After reading in the files, the error messages and dialogues need to be reconverted into their original file types.

Error messages	1. language:	<name>.A ⇒ <name>.ER1</name></name>
Error messages	English:	$<$ NAME $>$. A \Rightarrow $<$ NAME $>$. ERE
Dialogues	1. language:	$<$ NAME $>$. A \Rightarrow $<$ NAME $>$. DI1
Dialogues	English:	$<$ NAME $>$. A \Rightarrow $<$ NAME $>$. DIE



Page 119 Issue: 20.08.95

If the PLC program is run from RAM (MP 4010 = 1) and several files of the type <NAME>.PLC are contained in RAM, the PLC program that had the status \mathbf{M} before it was transferred, must be loaded into the process memory. (see section 19.5)

If there are several dialogue or error message files in RAM, the desired file can be selected via soft key.

Press key	Function
	TNC in PLC menu.
SELECT •DI1/•ER1 FILES	Press soft key.
or t	Select desired file.
SELECT	Press soft key.
END	Press soft key.

Page 120 Issue: 20.08.95

18. Analogue Outputs

18.1 Specifications

6 outputs 1, 2, 3, 4, 5 and S Machine parameters for the analogue outputs Analogue outputs MP Entry values Load capacity: $R_{Lmin} \ge 5 \text{ k}\Omega$ Χ 120.0 0 = output 1Υ 120.1 1 = output 2 $C_{Lmax} \leq 2 \text{ nF}$ Ζ 120.2 2 = output 3IV 120.3 3 = output 4Voltage range: $U_{amax} = \pm 10V \pm 100 \text{ mV}$ 120.4 4 = output 5 $0V \pm 3 \, \text{mV}$ $U_{amin} =$ 5 = output S

Resolution:	16 Bit = 65 536 steps
Smallest step	$\frac{10 \text{ V}}{65 536} = 0.153 \text{ mV}$

18.2 Checking the Analogue Outputs

18.2.1 Axes with Analogue Speed Controller

Proportionally to the traversing speed, the control generates an analogue voltage of 0V to 9V (rapid traverse). The easiest way to determine this voltage is to connect the test adapter directly to the logic unit or to the connecting terminals of the servo-amplifiers and to measure with a multimeter.

If however, the axis does not move due to a defect, and you want to test whether the error is inside or outside the control, the following steps are recommended:

- Switch off the main switch at the machine tool.
- Connect the test adapter to the connector X8 (nominal value output) of the LE and connect a multimeter to the test adapter sockets for the defective axis. If no test adapter is available, connect a multimeter directly to the nominal value output of the servo-amplifier.
- Switch on the main switch and the control voltage.
- Switch the position display to LAG (servo lag) (see section 18.3).
- Check and adjust the following machine parameters:

 (If you alter a machine parameter, note down the original value and enter it again after finishing the test.)


MP	Entry Value	Function	Original Value
1410.X	30 [mm]	Servo-lag monitoring (erasable), feed forward	
1420.X	30 [mm]	Servo-lag monitoring (EMERG. STOP), feed forward	
1140.X	9.99 [V]	Movement monitoring	
1710.X	300 [mm]	Servo lag monitoring (erasable), trailing mode	
1720.X	300 [mm]	Servo lag monitoring (EMERG. STOP), trailing mode	

- Traverse the reference points that need to be traversed before those of the defective axis.
- Turn the override potentiometer of the keyboard unit completely to the left and start reference mark traverse for the defective axis.
- Check the axis enable for the defective axis at the servo amplifier.
- Check the screen display.
 - * (Control ready for operation) must be ON, the **F** of the feed rate display must be normally lit (if the display is inverse, the feed rate enable is missing), and the symbol for "Axis not in the position loop" (e.g. \rightarrow | \leftarrow **X**) should not follow the position display.
- Turn the override potentiometer slowly to the right and turn it back left again before the servo lag display reaches the limit of the position monitoring.

Page 121 Issue: 20.08.95

When the override potentiometer is turned to the right, the control outputs an analogue voltage which is increased proportionally to the servo lag up to a maximum value of 10V. The control operates correctly, if a voltage of $10V \pm 0.1V$ can be measured at the test adapter with the multimeter. If no voltage can be measured, switch off the main switch, unplug the connector X8 from the logic unit, disconnect the nominal value line from the servo amplifier and test this line for short-circuit. If the nominal value line is in order, connect X8 to the logic unit again (leave the nominal value line disconnected), switch on the main switch and repeat the measurement with reference mark traverse. If an analogue voltage can be measured now, the control operates correctly. If no voltage can be measured, the analogue output of the logic unit is probably defective.

Measuring Setup to Check the Analogue Outputs



X8 Nominal value output for 1, 2, 3, 4, 5, S

flange socket with female insert (15-pin

Pin No.	Signal
1	analogue output 1
3	analogue output 2
5	analogue output 3
7	analogue output 4
4	analogue output 5
8	analogue output S axis
9	0V analogue output 1

Pin No.	Signal
11	0V analogue output 2
13	0V analogue output 3
14	0V analogue output 4
6	0V analogue output 5
15	0V analogue output S axis
housing	external shield = housing
2, 10, 12	
do not assign	



Page 122 Issue: 20.08.95

18.2.2 Axes with Integral Digital Speed Controller

Depending on the machine parameter MP1900 the driving axes of TNC 425/E are individually defined as **analogue axes** (as TNC 415 B/F) or as **digital axes**.

With axes with **integral digital speed controller** (corresponding bit of MP1900 = 1) a TTL voltage is output at the analogue output.

If however, the axis does not move due to a defect, and if you want to test whether the error is inside or outside the control, the following steps are recommended:

- · Switch off the main switch.
- Disconnect the **nominal value line** from the connector X8 and check for short-circuit and line disconnection.
- If the **nominal value line** is in order, leave it disconnected and connect the test adapter to the connector X8.
- Switch on main switch and machine control voltage.
- Switch the position display to LAG (servo lag); see section 18.3.
- Define the axis to be checked as **analogue** controlled axis (MP1900, corresponding bit = 0)

Function		MP No.	Bit	Entry range	Original 1) Entry Values
Axes with				0 to 31	
digital speed controller		1900		0 = analogue-controlled axis	
	X		0	+1 = X-axis digital controlled	
	Υ		1	+2 = Y-axis digital controlled	
	Z		2	+4 = Z-axis digital controlled	
	IV		3	+8 = IV. axis digital controlled	
	V		4	+16 = V. axis digital controlled	

• The following machine parameters need to be checked and adapted. (Do not forget to re-enter the original values after having finished the test!)


MP	Entry Value	Function	Original Entry Values
1410.X	30 [mm]	Servo lag monitoring (cancellable), feed forward control	
1420.X	30 [mm]	Servo lag monitoring (EMERG. STOP), feed forward control	
1140.X	9.99 [V]	Movement monitoring	
1710.X	300 [mm]	Servo lag monitoring (cancellable), trailing operation	
1720.X	300 [mm]	Servo lag monitoring (EMERG. STOP), trailing operation	

- Turn the override potentiometer of the keyboard unit completely to the left and start reference mark traverse for the defective axis.
- Check the axis enable for the defective axis at the servo amplifier.
- Check the screen display
 - * (control ready for operation) must be switched on, the **F** of the feed rate display must be lit normally (if the display is inverse the feed rate enable is missing) and the symbol for "axis not in position loop" (e.g. \rightarrow) \leftarrow **X**) must not follow the position display.
- Turn the override potentiometer slowly to the right and turn it back left before the servo lag display reaches the limit of the position monitoring.

Page 123 Issue: 20.08.95

When the override potentiometer is turned to the right, the control outputs an analogue voltage which is increased proportionally to the servo lag up to a maximum value of 10V. The control operates correctly, if a voltage of $10V \pm 0.1V$ can be measured at the test adapter with the multimeter. If no voltage can be measured, the analogue output of the logic unit is probably defective.

Measuring Setup to Check the Analogue Outputs



X8 Nominal value output for 1, 2, 3, 4, 5, S

flange socket with female insert (15-pin)

Pin No.	Signal
1	analogue output 1
3	analogue output 2
5	analogue output 3
7	analogue output 4
4	analogue output 5
8	analogue output S axis
9	0V analogue output 1

Pin No.	Signal
11	0V analogue output 2
13	0V analogue output 3
14	0V analogue output 4
6	0V analogue output 5
15	0V analogue output S axis
housing	external shield = housing
2, 10, 12	
do not assign	



Page 124 Issue: 20.08.95

18.3 Switching Over the Position Display

Press Key		Function		
	MOD	TNC in operating mode MACHINE (manuactivate MOD function	al, full sequence etc	c.)
MANUAL	OPERATION		PLC	1

MANUAL OPERATION


POSITION DISPLAY

REF

CHANGE MM/INCH MM
PROGRAM INPUT HEIDENHAIN
AXIS SELECTION %00000

NC : SOFTWARE NUMBER 280540 04
PLC: SOFTWARE NUMBER 252499 01
OPT: 1

POSITION/		AXIS	AXIS	HFIP		FND
INPUT PGM	LIMIT (1)	LIMIT (2)	LIMIT (3)	11661		LND



Page 125 Issue: 20.08.95

18.4 Adjustment of the Feed Rate

18.4.1 Axes with Analogue Speed Controller

Check and adapt the machine parameters (note down the original entry values).

MP	Entry Value	Function	Original Entry Value
1390	0	feed forward control 1) ON	
		in automatic operating modes	
7290.X	6	display step = 0.1 μm	

- Switch position display to LAG (servo lag).
- Enter the following test program (e.g. for X axis)
- 0 BEGIN PGM X MM
- 1 LBL 1
- 2 X + 0 F MAX
- 3 X + 100 F MAX (select a larger traverse range if possible!)
- 4 CALL LBL 1 REP 100/100
- 5 END PGM X MM
- Run the test program in the operating mode "PROGRAM RUN / FULL SEQUENCE".
- Adjust the feed rate at the servo amplifier (tachometer) until the servo lag display is approximately zero for positioning in both directions.
- Repeat the adjustment for all axes.
- Reset the machine parameters and the position display to the original values.
- 1) The operating mode "feed forward control" must be optimized.

18.4.2 Axes with Integral Digital Speed Controller

Depending on the machine parameter MP1900 the driving axes of TNC 425/E are individually defined as **analogue axes** (as TNC 415 B/F) or as **digital axes**.

With axes with **integral digital speed controller** (corresponding bit of MP1900 = 1) the feed adjustment of the servo amplifier as described in section 18.4.1 is not required.


Page 126 Issue: 20.08.95

18.5 Offset Adjustment 18.5.1 Axes with Analogue Speed Controller

a) Offset Adjustment with Code Number

Press Key	Function
	TNC in operating mode PROGRAMMING AND EDITING
MOD	Prepare TNC for entry of code number
7 5 3 6 8 ENT	Enter code number for offset adjustment and confirm with ENT

Now the contents of the offset memory is displayed on the screen in converter steps (1 conv. step = 0.153 mV). From left to right: X, Y, Z, IV, V.





Page 127 Issue: 20.08.95

b) Cyclic Offset Adjustment via Machine Parameters

In the machine parameter MP1220 the cycle time is defined [1s] after which an offset is compensated by one converter step.

To switch off the automatic offset adjustment, enter the value 0 in the machine parameter MP1220.



NOTE:

If an offset voltage of 100 mV is reached with automatic offset adjustment, the control switches off, generating the error message

GROSS POSITIONING ERROR <axis><CPU number> E

c) Offset Adjustment at the Servo Amplifier

• Check and adjust the following machine parameters. (Note down the original values before changing.)

MP	Entry Value	Function	Original Entry Value
1080.0	0		
1080.1	0		
1080.2	0	integral factor	
1080.3	0	_	
1080.4	0		
1220	0	cycle time for	
		automatic offset adjustment	
1390	0	feed forward control ON	
1510.0	≥ 1		
1510.1	≥ 1		
1510.2	≥ 1	KV factor for feed forward control	
1510.3	<u>-</u> · ≥ 1		
1510.4	≥ 1		
7290.X	6	display step = 0.1 μm	

- Switch position display to LAG (display of servo lag); see section 18.3.
- Cancel the offset compensation with code number (see item a)
- Adjust the offset at the servo amplifier until the values of the individual axes are zero or oscillate symmetrically about zero.
- Reset the machine parameter values and the position display to their original values.


18.5.2 Axes with Integral Digital Speed Controller

With axes with **integral digital speed controller** (TNC 425, corresponding bit of MP1900 = 1) the offset adjustment as described in section 18.5.1 is not required.

.

Page 128 Issue: 20.08.95

NOTES



Page 129 Issue: 20.08.95

18.6 Oscilloscope Function

TNC 415B/425 features an integral oscilloscope. To activate the OSCILLOSCOPE mode, enter the code number 688 379.

MANUAL OPERATION	OSCILLOSCOPE			
OUTPUT NOML. F	FEED RATE	RAMP 0		
SAMPLE	TIME	0,6 MS		
CHANNEL CHANNEL CHANNEL	2 Y 3 Z	VOLT.ANLOG OFF VOLT.ANLOG OFF		
TRIGGER TRIGGER SLOPE PRE-TRI	R THRESHOLD	FREE RUN +0 + 0 %		
OSCI			MP EDIT	END

The axes, parameters and trigger conditions to be recorded are selected by pressing the cursor keys which move the cursor to the desired position.

The following characteristic curves can be displayed:

F ACTL	actual value (mm/min)
F NOML	nominal value (mm/min)
N ACTL	actual value (mm/min)
N NOML	nominal value (mm/min)
N INT	difference of nominal and actual for speed controller (mm/min)
S ACTL	actual value (mm)
S NOML	nominal value (mm)
S DIFF	servo lag for position control (mm)
U ANALOG	analogue voltage output (V)
	F NOML N ACTL N NOML N INT S ACTL S NOML S DIFF


¹⁾ only for digital controlled driving axes

Page 130 Issue: 20.08.95

18.6.1 Soft Key Rows

OSZI						MP EDIT	END
CH 1	CH 2	сн з	CH 4		SET UP	START	END
	+		— →	□ □ □			END
INVERT	ļ	†	‡	‡		CURSOR 1/2	END

Explanation of the soft keys:





optimum vertical resolution, centered on screen

Page 131 Issue: 20.08.95

18.6.2 Trigger

The following possibilities are available:

• FREE RUN Recording is terminated by hand.

• SINGLE SHOT Recording of a memory contents; started by trigger condition

• CHANNEL ... Recording starts when the trigger threshold of the selected channel is exceeded.

Trigger Threshold

The trigger threshold for the selected channel is indicated as a numerical value; the units are as follows:

- feed rate (mm/min)
- position (mm)
- shaft speed (mm/min)
- servo lag (µm)
- analogue voltage (mV)

Edges

Triggering with rising (positive) and falling (negative) edge.

Pre-Trigger

Definition of recording start in % of the total recording time; possible entry values are 0%, 25%, 50%, 75%, 100%; selectable by pressing ENT.

18.6.3 Recording

The recording parameters to be edited are selected via arrow keys. The values for the feed rate threshold and the trigger threshold are entered via the numerical keys. The entry values for all other recording parameters are selected by pressing ENT.

Output

To output a nominal value in the MANUAL mode, it is possible to chose between a pre-set ramp and a jump function. The jump function (only possible with digital controlled axes) is required for the adjustment of the speed encoder. Moreover, if the preliminary entry value is unknown, the maximum acceleration can be determined from jump function and recording with the oscilloscope. In MDI and AUTOMATIC the axes are always accelerated following the selected ramp.

Feed Rate

If a jump function is selected as output signal, the feed rate is entered in mm/min. The programmed feed rate is valid for the acceleration subsequent to the ramp.

Time Resolution

The recording time is between 2.4576 seconds and 24.576 seconds (selected time x 4096). The selected time (0.6 ms to 6 ms) is the clock time for recording the characteristic lines. The recording time is displayed below the grating. Beginning and end of display (relative to the trigger point; cursor line T1) are displayed as well.

Page 132 Issue: 20.08.95

Channel 1 to Channel 4

Four channels can be selected for recording. The assignment of the axes to the channels is variable; select the axis to be changed, press ENT to switch the channel.

For each channel a characteristic line is selected. It consists of the following values:

Feed rate	V ACTL	actual value (mm/min)
	V NOML	nominal value (mm/min)
Shaft speed	N ACTL	actual value (mm/min)
	N NOML	nominal value (mm/min)
Speed controller	N INT	difference of nominal/actual value for the speed controller (mm/min)
Position	S ACTL	actual value (mm)
	S NOML	nominal value(mm)
Servo lag	S DIFF	servo lag for position controller (mm)
Analogue voltage	U ANALOG	analogue voltage output (V)
Channel	OFF	channel is displayed
	SAVED	channel is stored

Recording is started by pressing the START soft key. A soft key row is displayed which only contains a STOP key. The process can be interrupted at any time.

During recording the stored channels cannot be displayed simultaneously, since it is not possible to synchronise the stored channels and the newly recorded channels.

Evaluation of the recorded channels via cursor

Whereas the entire memory contents is displayed after start, the time window selected before the start is displayed after re-setup of the screen.

On the left side of the screen the time T1 (time of trigger event) is displayed. Below there is the absolute value in [mm/min], [mm] or [mV].

If an additional cursor with the time T2 is displayed by means of the key CURSOR 1/2, it can be shifted with the arrow keys on the TNC operating panel. The time T2 is the difference to T1; the numerical value displayed below is the difference to the value belonging to T1.

The T2 display and the additional cursor can be erased by pressing the soft key END or "Cursor 1/2".

Vertical Zoom

For the display of each selected channel the vertical grid can be changed in steps via soft key. The vertical grid size is displayed on the left side of the screen below the designations of the channel and the recording.

Centering the Display

The vertical resolution is selected such that an optimum display is ensured.

Returning to the original vertical resolution:

By pressing NOENT the original display of the stored data is re-established.

Horizontal Zoom

The recording comprises 4096 evaluated data. The time resolution (i.e. the clock time of the recorded data) can be set between 0.6 and 6 ms. The range for extension and compression is limited as follows:

	evaluated data	data: pixels
minimum display	4096	8:1
max. extended display	64	1:8

The length of the displayed detail and its starting point as absolute position within the duration of the recorded data is depicted as scroll bar in the status window.

Page 133 Issue: 20.08.95

19. PLC Inputs and Output

19.1 PLC Inputs

19.1.1 PLC Inputs on LE

Connector X42: I0 to I31 and acknowledgement "control ready for operation" Connector X46: I128 to I152

"0" signal $U_{e} = -20V \text{ to } 3.2V$

 $I_e = 1.0 \text{mA} \text{ with } U_e = 3.2 \text{V}$

 $U_{e} = 13V \text{ to } 30.2V$ "1" signal

 $l_e = 3.8 \text{mA} \text{ to } 8.9 \text{mA}$

19.1.2 PLC Inputs on PL 400

Terminal strips X4 to X9: I64 (I192) to I126 (I254)

"0" signal $U_e = -20V \text{ to } 4V$

 $I_e = 1.6 \text{mA} \text{ with } U_e = 4 \text{V}$

 $U_{e} = 16.5V \text{ to } 30V$ "1" signal

 $l_e = 6.2 \text{mA} \text{ to } 12.6 \text{mA}$

19.1.3 PLC Inputs on PL 405/410

PL 405, terminal strips X3 to X4: I64 (I192) to I95 (I223) PL 410, terminal strips X3 to X6: I64 (I192) to I127 (I255)

"0" signal $U_e = -20V \text{ to } 4V$

 $I_e = 1.6 \text{mA} \text{ with } U_e = 4 \text{V}$

 $U_e = 16.5V \text{ to } 30V$ "1" signal

 $I_e = 6.2 \text{mA} \text{ to } 12.6 \text{mA}$

19.2 PLC Outputs

19.2.1 PLC Outputs on LE

Connector X41: O0 to O30 and output "control ready for operation"

Connector X46: O0 to O7 1)

1) outputs available at X46 or X41

"1" signal **UB** - 3V U_{a min} =

> la NOML = 0.1A

19.2.2 PLC Outputs on PL 400

Terminal strips X1 to X3: O32 (O64) to O62 (O94) and output "control ready for operation"

"1" signal **UB - 3V** Ua min

1.2A la NOML =

19.2.3 PLC Outputs on PL 405/410

O48 (O80) to O62 (O94) and output "control ready for operation" PL 405, terminal strip X8: PL 410, terminal strips X7 to X8: O32 (O64) to O47 (O79) and output "control ready for operation"

"1" signal U_{a min} = **UB - 3V**

1.2A la NOML =

Pin layout: see section 6

Page 134 Issue: 20.08.95

19.3 Checking the PLC Inputs and Outputs

The test unit (see section 20) can be used to check the PLC inputs and outputs on the logic unit (X41, X42, X46). The voltage level of the PLC inputs and the output current of the PLC outputs on the PL 400/405/410 can be measured directly at the terminals.

19.3.1 PLC Inputs

The PLC inputs can be checked as follows:

• Connect the test unit between LE and PLC (measure directly at the PL boards).

Press Key	Function				
(♦)	TNC in operating mode PROGRAMMING/EDITING				
MOD	Prepare TNC for input of code number				
8 0 7 6 6 7 ENT	Enter code number, confirm with ENT				
TABLE	Call TABLE function				
I NPUT	Display of input table				
Now the logic states of the inputs are displayed on the screen. They must correspond to the voltage levels of the corresponding inputs (voltage levels: see section 19.1). If there is a difference and the input voltage is correct, the input board of the PLC graphics board or the PLC I/O board PL 400/405/410 is defective.					
END	Exit the TABLE function				
END	TNC in operating mode PROGRAMMING/EDITING				



Page 135 Issue: 20.08.95



19.3.2 PLC Outputs

The PLC outputs can be checked as follows:


• Connect the test unit between the PLC and the LE (measure directly at the PL boards).

Press Key	Function				
€	TNC in operating mode PROGRAMMING/EDITING				
MOD	Prepare TNC for input of code number				
8 0 7 6 6 7 ENT	Enter code number, confirm with ENT				
TABLE	Call TABLE function				
Оитрит	Display of output table				
Now the logic states of the outputs are displayed on the screen. They must correspond to the voltage levels of the corresponding outputs. If there is a difference, check the output cable for short circuit and measure the output current at the interface (max. 100 mA for LE outputs, max. 1.2 A for PL outputs). If the output current is not exceeded and connecting cable is in order, the output board of the PLC graphics board or the PLC I/O board PL 400/405/410 is defective.					
END	Exit the TABLE function				
END	TNC in operating mode PROGRAMMING/EDITING				



Page 136 Issue: 20.08.95

19.3.3 Measurement Setup for PLC Inputs and Outputs at the LE



X41 : PLC output X42 : PLC input

X46: machine operating panel



Page 137 Issue: 20.08.95

19.4 Diagnosis Possibilities in the PLC Mode

19.4.1 TRACE Function

TRACE

Activation via soft key


MANUAL OPERATION	PLO	PR	0 G	RAM 1	TRACE	MODE		
OPERAND	ACCU AC	TIVE	LINE	COMMA	ND		COMMENT	
0	0	*	40	XON	M2207			
0	0	*	41	=	M902			
1	1	*	42	ХО	I131			
0	0	*	43	XON	M2207			
Ø	0	*	44	=	M903			
			45	; FREIGA	BEN DER WE	RKZEUGACHS	EN	
0	0	*	46	А	M2000			
0	0	*	47	=	00			
0	0	*	48	А	M2001			
0	0	*	49	=	01			
0	0	*	50	А	M2002			
0	0	*	51	=	02			
0	0	*	52	А	M2003			
0	0	*	53	=	03			
SELECT M/I/O/T/C	LOGIC DIAGRAM	FIND		HEX	START STOP DISPLAY	START TRACE	STOP TRACE	END

The TRACE function provides the possibility of controlling the logic states of the markers, inputs, outputs, timers and counters; it also serves to check the contents of bytes, words and double words of the compiled PLC program.

An instruction list (AWL) of the compiled program is displayed. In addition, the contents of the operand and of the accumulator is displayed in HEX code or decimal code. All active commands of the instruction list are marked by "*". Use the cursor keys or the GOTO function to display the requested program part.

Page 138 Issue: 20.08.95

19.4.2 LOGIC Diagram



The logic states of up to 16 operands (M, I, O, T, C) can be depicted simultaneously on the screen. 1024 PLC scans can be traced.

Activation of the Logic Diagram:

Press Key	Function
TRACE	Press soft key
LOGIC DIAGRAM	Press soft key

Page 139 Issue: 20.08.95

Selecting the Operands and Starting the Logic Diagram

Press Key		Function
	SELECT M/I/O/T/C	
a dialogue. Wr operand. 512 s	ong inputs can be cleared by pres states are traced before and after a	n be selected. The control requests the positions of the table in sing DEL. It is possible to enter a trigger condition for each a trigger event. The following trigger conditions are possible:
	ace if the operand is a logical "1" rigger on positive edge)	
(t)	ace if the operand is a logical "0" rigger on negative edge)	
If	o trigger no trigger condition is entered for ontinuously and the last 1024 state	any of the operands, the operand states are traced es are stored.
e.g.: 0 I5 1 O6 2 M20	 1 ⇒ trigger on positive edge 0 ⇒ trigger on negative edge 03 ⇒ no trigger 	
	START TRACE	Start TRACE function
		TNC in operating mode "MACHINE" (key on VDU)
The trace func	tion is started with START TRACE	; END TRACE or a trigger event terminate the tracing.
PCTR blinking PCTR on PCTR off	: trigger condition has not occurred: trigger condition has occurred: buffer memory is full; LOGIC	d; write access to buffer memory
		Switch to TRACE mode
	LOGIC DIAGRAM	Call logic diagram

Page 140 Issue: 20.08.95

19.4.3 TABLE Function

Press Key			F	Function				
TABLE				Call TABLE function				
SET	Reset	Marker	I NРUТ	Оитрит	COUNTER	T IMER	END	
)	K	ey on VDU				
Вуте	Word	Double	HEX Û DECIMAL				END	


After pressing a soft key, the corresponding table is activated.

The logic states of the markers, inputs, outputs, counters and timers are dynamically displayed. In the tables for bytes, words and double words, the display can be switched between HEX and DECIMAL.

With the cursor keys or the GOTO key, positions of a table can be selected.

Page 141 Issue: 20.08.95

Notes




Page 142 Issue: 20.08.95

19.5 Compiling the PLC Program

EDIT	TABLE	TRACE	COMPILE	OUTPUT BINARY CODE 0001	SELECT •DI1/•ER1 FILES	MP EDIT	END
PGM I	N ED	IT MEN	1: E0.	_ M O D U L	PLC		
PGM I	N EXE	EC.MEN	1: 252	2499XA	I.PLC		
	ESSING	G TIME	CURI	I MUM RENT KBYTE	15 12	% %	
MANUAL OPERATION	PLO	PROG	SRAMM:	ING			

Selecting a File as EDITOR PGM:



Page 143 Issue: 20.08.95

19.6 Output "Control Ready for Operation" and **Acknowledgement for Test " Control Ready for Operation** "

Important functions are monitored by the TNC 415B/425 by way of a self-diagnosis system (electronic assemblies such as micro-processor, EPROM, RAM, positioning systems, encoders etc.).

If an error is detected, a blinking error message in plain language is displayed in the dialogue line. As soon as this error message is generated, the control opens the output "Control Ready for Operation".

The output "Control Ready for Operation" is available via:

Logic unit,	connector X41	pin 34
PL 400,	terminal strip X3	pin 10
PL 405,	terminal strip X8	pin 16
PL 410,	terminal strip X8	pin 16

By switching off the power switch or by pressing this state can be cancelled, provided that the error cause has been eliminated.



The output "Control Ready for Operation" is to switch off the +24V control voltage in the machine tool interface. Since this is an important safety function, the switch-off function of the output "Control Ready for Operation" is tested via the input "Acknowledgement Control Ready for Operation" each time the control is switched on.

TNC 415B/425 features three monitoring systems (main processor, geometry processor and CLP processor) which are also tested when the machine tool is switched on.

If the +24V at the input "Acknowledgement Control Ready for Operation" are missing during the test routine after power-on, the error message "RELAY EXT. DC VOLTAGE MISSING" is displayed. If however, the acknowledgement is switched off too late (or not at all) after the output has been switched off, the blinking error message "EMERGENCY STOP DEFECTIVE" is generated. This error message is also displayed, if the power supply of the PLC is missing (power supply of the PLC: see section 10).

If the control detects an error during the power-on test routine, a bridge can be inserted between the output "Control Ready for Operation" and the input "Acknowledgement Control Ready for Operation" (disconnect the wires) in order to determine whether the defect is due to the control or to the interface. If the error is still present after inserting the bridge and with correct PLC power supply, the defect is located in the logic unit. If however, the error does not occur with the bridge being inserted, the defect is located in the interface.

Warning!


Do not forget to remove the bridge and to install the standard operating state after the test.




Observe the safety instructions!

Page 144 Issue: 20.08.95

19.6.1 Wiring of the EMERGENCY STOP Interface



19.6.2 TNC 415B/425 Flow Diagram




Time	Remarks	Error Message
1		POWER INTERRUPTED
2	Waiting for control voltage	RELAY EXT. DC VOLTAGE MISSING
3	After switching off the output "Control Ready for Operation", the "Acknowledgement Control Ready for Operation" must be switched off within 114 ms; otherwise the blinking error message is generated.	YX = 1(= Communication processor 1) = Geometry processor 1. = CLP processor
4	If the acknowledgement is switched off during operation, the error message is displayed.	EMERGENCY STOP

Page 145 Issue: 20.08.95

20. Test Units

20.1 Test Unit for the PLC Inputs and Outputs


PL Test Unit, Id.No. 247 359 01 to test the PLC inputs and outputs on PL 400



20.2 Universal Measuring Adapter


Used[.]

as universal test unit for D-Sub connectors, 9-pin to 37-pin (Id.No. 255 480 01)




The measuring adapter can be used to test the inputs and outputs of D-Sub connectors (9-pin to 37-pin). On the following page the adapter cables are shown that are required for the different connectors.


Page 146 Issue: 20.08.95




Adaptor Cable,9pin Id.No. 255 481 01



Adaptor Cable, 15pin Id.No. 255 482 01



Adaptor Cable, 25pin Id.No. 255 483 01




Adaptor Cable, 37pin Id.No. 255 484 01

Page 147 Issue: 20.08.95

20.3 Encoder Diagnostic Set, Id.No. 254 599 01

Used:

to test the electrical functions of an encoder (Further information please see from the operating instructions of the Diagnostic Set.)



Page 148 Issue: 20.08.95

21. Exchange Instructions

21.1 Important Notes



Observe the safety instructions!

21.1.1 Required Equipment

- 1 external data medium, e.g. FE 401/B or PC with connecting cable
- 1 tool set (screw driver, socket wrench etc.)
- 1 MOS protection device (only required for exchanging boards or EPROMs)

21.1.2 MOS Protection


If the processor board, the PLC graphics board, the CLP boards or EPROMs are to be exchanged, a MOS protection is definitely required, since otherwise MOS components on the boards or the EPROMs may be destroyed.



Caution!

Avoid any unprotected handling of the boards or EPROMs with statically charged objects (packaging material, storage etc.).

MOS Protection



21.1.3 Software Compatibility

Exchange units (LOGIC UNIT) are always supplied with the most recent software version. Exchange boards, however, are delivered **without** software and without software enable module. Therefore, the EPROMs and the software enable module of the defective board must be inserted into the exchange board at site. Always remove the EPROMs and the software enable module before sending us boards for repair!)

Page 149 Issue: 20.08.95

21.1.4 Backing up RAM Data

Before the LOGIC UNIT, an assembly (e.g. processor board, power supply etc.) or the NC software are exchanged, all RAM data (files, settings etc.) must be backed up.

The following files may be stored in RAM and must be backed up on a external data medium:

NC memory management	Extension in TNC	Extension on external medium
NC program, HEIDENHAIN dialogue	.H	.H
NC program, ISO	.1	.l
Active tool table	TOOL.T	TOOL.T
Tool data (table)	.Т	.Т
Pocket table		TOOL_P.R
Pallet table	.P	.L
Datum table	.D	.N
Text file (ASCII)	.A	.A
Point table (digitizing)	.PNT	.U
PLC memory management (RAM)		
PLC program	.PLC	.P
Error messages 1. language	.ER1	.А
Error messages English	.ERE	.А
Dialogues 1. language	.DI1	.A
Dialogues English	.DIE	.A
ASCII files	.А	.A
Help texts	.HLP	.J
Data for axis error compensation	.COM	.V
Data for axis error compensation	.CMA	.S
Machine parameter mode		
Machine parameter list	.MP	.M
Compensation value table	.KOR	.S
(accessible via code number)		

Letters representing additional information on the files and programs are displayed in the status display:

- E: The file or the program was selected in PROGRAMMING.
- S: The file or the program was selected and activated in TEST RUN.
- M: The file or the program was selected and activated in PROGRAM RUN/FULL SEQUENCE or in PROGRAM RUN/SINGLE BLOCK.
- P: The file or the program is protected against deleting and editing.
- IN: The file or the program was programmed in inches.
- W: The file or the program was not completely transferred to the external medium and thus is no longer available.

Page 150 Issue: 20.08.95

The data can be read out as described in section 17.3.

The **BACKUP routine** is a very useful function to read out all data.

After pressing MOD in the operating mode "Machine Parameter Editing" (code number 95148) the menu for interface configuration is displayed, comprising the soft keys

BACKUP DATA

RESTORE DATA

MONITOL	MOOLLT	NE DODO	WETER RRADA	O M M	TNO
OPERATION	мнині	NE PHRH	METER PROGRE	HMM	ING
RS232 1	NTERF	ACE	RS422 INTER	RFA	CE
MODE OF	OP.:	LSV2	MODE OF OP	. :	FE 1
BAUD RA	TE		BAUD RATE		
FE :	38400		FE : 9600	9	
EXT1 :	9600		EXT1 : 9600	9	
EXT2:	9600		EXT2 : 9600	9	
LSV2 :	38400		LSV2 : 9600	9	
ASSIGN:	:				
PROGRAM	MING:	RS232	PRINT	:	RS232
PROGRAM	1 RUN:	RS232	PRINT-TEST	:	RS232
TEST RU	JN :	RS232	PLC EDITOR	:	RS232
			MP EDITOR	:	RS232
RS 422		STORE ITA			END

BACKUP DATA With

all operating parameters and the data of all file types are transferred via the data

RESTORE DATA

interface and filed in \$BACKUP.A. To reload the data into the TNC, press the soft key

Page 151 Issue: 20.08.95

Moreover, the pre-set values and the entry values for the supplementary operating modes must be determined so that they can be re-entered after the exchange.

Switch off and on the main switch of the machine tool.

TNC Dialogue	Press Key	Notes
MEMORY TEST	-	
POWER INTERRUPTED	CE	
RELAY EXT. DC VOLTAGE MISSING		Switch on control voltage
MANUAL OPERATION TRAVERSE REF. POINT AXIS TRAVERSE REF. POINT AXIS TRAVERSE REF. POINT AXIS TRAVERSE REF. POINT AXIS	MOD	Do not yet traverse the reference points!
POSITION DISPLAY (upper)		Mark the selected position
O O O O O ACTL REF LAG NOML DIST		display with a cross and then switch the upper POSITION DISPLAY to ACTL
POSITION DISPLAY (lower)		ENT
ACTL REF LAG NOML DIST The lower position display can be activated with the STATUS ON soft key (only in the split screen mode)		by pressing if necessary.
UNIT O O MM INCH		Mark the unit
PROGRAM INPUT OHEIDENHAIN ISO		Mark the type of program input
Software number:		
NC		Note down NC and PLC software number
PLC.		

Page 152 Issue: 20.08.95

TNC Dialogue		Press Key	Notes
SIGN of LIMIT X-	=	AXIS LIMIT	Press soft key, note down the values.
LIMIT X+	=		(do not forget the sign!) If MP7490 = 1, three different limits may be active.
LIMIT Y-	=		In this case, note down all three values.
LIMIT Y+	=		
LIMIT Z-	=		Note down the values (do not forget the sign!)
LIMIT Z+	=		
LIMIT IV-	=		
LIMIT IV+	=		
LIMIT V-	=		
LIMIT V+	=	END	
ACTL X			Note down the pre-set values
ACTL Y			(do not forget the sign!)
ACTL Z			
ACTL IV			
ACTL V			

Page 153 Issue: 20.08.95

TNC Dialogue	Press Key	Notes
	MOD	(key on VDU)
	RS 232 RS 422 SETUP	
OPERATING MODE ME FE1 FE2 EXT1 EXT2 LSV2 BAUD RATE		Mark the operating mode of the RS 232 interface Mark the baud rate of the
FE: BAUD		RS 232 interface
EXT 1: BAUD		
EXT 2: BAUD		
LSV 2:		
OPERATING MODE ME FE1 FE2 EXT1 EXT2 LSV2 O O O O		Mark the operating mode of the RS 422 interface Mark the baud rate of the RS 422 interface
FE: BAUD		
EXT 1: BAUD		
EXT 2: BAUD		
LSV 2: BAUD		
ASSIGNMENT LATCH	END	Mark the assignment of the interfaces to the operating modes

21.1.5 Labelling the Connecting Cables

If the connecting cables are labelled incompletely or not at all, they have to be marked such that the correct plug connections can be re-established after having exchanged the logic unit or another assembly. Pin layout: see section 6



WARNING:

Switching the connecting cables may destroy the unit!

Page 154 Issue: 20.08.95


21.2 Exchanging the Logic Unit

21.2.1 Observe the exchange instructions (section 21.1)!

21.2.2 Dismounting the Logic Unit

- a) Switch off the main switch.
- b) Loosen all plug connections and clamped joints at the logic unit.

Round connector Loosen knurled coupling rings (TNC 415B/F only)




D-Sub connector Loosen knurled screws

NOTE:

If a PL400/410 is mounted on the upper side of the housing, it must be removed before dismounting the logic unit.

Page 155 Issue: 20.08.95

c) Loosen the 4 mounting screws on the logic unit



d) Remove the old logic unit and insert the new logic unit.

21.2.3 Mounting the Logic Unit

The logic unit is mounted in the reverse order that is was dismounted.

- a) Insert and secure the logic unit.
- b) Engage the connectors.



Observe that no connectors are switched!

- c) Switch on the main switch.
- d) Read in the machine tool data (machine parameters, PLC program, NC programs and tables) that have been backed up before the exchange.
- e) Enter the pre-set values and the supplementary operating modes from the table in section 21.1.4 (**before** traversing the reference marks).
- f) Offset adjustment with code number (see section 18.5).

Exchange is now finished.

Page 156 Issue: 20.08.95


21.3 Exchanging the Processor Board

21.3.1 Observe the exchange instructions (section 21.1)!


21.3.2 Dismounting the Processor Board

- a) Switch off the main switch on the machine tool.
- b) Disengage the connectors on the processor board (X21, X22, X23).
- c) Undo the lock and open the logic unit.

Undo lock




d) Disengage internal connectors



Page 157 Issue: 20.08.95

e) Loosen/remove fixing screws



f) Lift out the processor board; exchange the EPROMs, if required (see section 21.8). Insert the new board.

21.3.3 Mounting the Processor Board

The processor board is mounted in the reverse order that is was dismounted.

- a) Insert and secure the processor board.
- b) Engage the connectors.



Observe that no connectors are switched!

- c) Close the logic unit and the lock.
- d) Switch on the main switch.
- e) Read in the machine data (machine parameters, PLC program, NC programs and tables) that have been backed up before the exchange.
- f) Enter the pre-set values and the supplementary operating modes from the table in section 21.1.4 (**before** traversing the reference marks).
- g) Offset adjustment with code number (see section 18.5).

Exchange is now finished.

Warning!



Send and store the boards **only** in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.


Page 158 Issue: 20.08.95

21.4 Exchanging the CLP Board

21.4.1 Observe the exchange instructions (section 21.1)!


21.4.2 Dismounting the CLP Board

- a) Switch off the main switch at the machine tool.
- b) Disengage the connectors at the CLP board.
- c) Undo the locks and open the logic unit.




d) Disengage internal connectors

CLP board TNC 415B




Page 159 Issue: 20.08.95

CLP board TNC 425




e) Loosen/remove the fixing screws.

CLP board TNC 415B



Page 160 Issue: 20.08.95

CLP board TNC 425



f) Lift out the CLP board; exchange the EPROM, if required (see section 21.8). Insert the new board.

21.4.3 Mounting the CLP Board

The CLP board is mounted in the reverse order that is was dismounted.

- a) Insert and secure the CLP board.
- b) Engage the connectors.



Observe that no connectors are switched!

- c) Close the logic unit and the locks.
- d) Switch on the main switch.
- e) Offset adjustment with code number (see section 18.5).

Exchange is now finished.



Warning!

Send and store the boards **only** in the **original packaging** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.


Page 161 Issue: 20.08.95

21.5 Exchanging the PLC Graphics Board

21.5.1 Observe the exchange instructions in section 21.1!


21.5.2 Dismounting the PLC Graphics Board

- a) Switch off the main switch of the machine tool.
- b) Disengage the connectors on the PLC graphics board.
- c) Undo the lock and open the logic unit.




PLC graphics board

d) Disengage internal connectors.



Page 162 Issue: 20.08.95

e) Loosen/remove fixing screws



f) Lift out the PLC graphics board and insert the new board.

21.5.3 Mounting the PLC Graphics Board

The PLC graphics board is mounted in the reverse order that it was dismounted.

- a) Insert and secure the PLC graphics board.
- b) Engage the connectors.



Observe that no connectors are switched!

- c) Close the logic unit and the lock.
- d) Switch on the main switch.
- e) Carry out offset adjustment with code number (see section 18.5).

Exchange is now finished.



Warning!


Send and store the boards **only** in the **original packaging material** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

Page 163 Issue: 20.08.95


21.6 Exchanging the POWER SUPPLY Unit

- a) Observe the exchange instructions in section 21.1!
- b) Switch off the main switch on the machine tool.
- c) Undo the lock and open the logic unit.





d) Disengage the connection to the power supply unit at the processor board.




e) Pull the cable harness to the power supply through the housing.




To pull the cable harness the PLC graphics board and the CLP board must be removed. (see sections 21.4 and 21.5)

Page 164 Issue: 20.08.95

f) Disengage the connector of the NC power supply and loosen the mounting screws.





Slide out the power supply unit to the right and insert the new power supply unit.

- g) Fasten the mounting screws.
 - Pull the cable harness through the housing again.
 - Engage the connectors.
 - Close the logic unit, switch on the main switch.

Exchange is now finished.



Observe that no connectors are switched!




Warning!

Send and store the boards **only** in the **original packaging material** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.


Page 165 Issue: 20.08.95

21.7 Exchanging the PLC I/O Boards

21.7.1 Exchanging the PLC I/O Board PL 400




d) Unscrew the cover of the PL 400 and disconnect the cable to the PLC graphics board from the PL 400.



Page 166 Issue: 20.08.95

e) Unscrew the PL 400 from the logic unit. 1)



- f) The new PLC I/O board PL 400 is mounted in reverse order:
 - Mount the PL 400 to the logic unit. 1)
 - Engage the connectors.
 - Switch on the main switch.

Exchange is now finished.



Warning!

Send and store the boards **only** in the **original packaging material** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.


1) The PL 400 may also be located in the switch cabinet.

Page 167 Issue: 20.08.95

21.7.2 Exchanging the PLC I/O Board PL 410

a) Observe the exchange instructions in section 21.1!

- b) Switch off the main switch.
- c) Loosen the connectors at the PL 410.



d) Loosen the PL 410 mounting screws

- e) The new PLC I/O board PL 410 is mounted in reverse order:
 - Engage all connectors.
 - Check the correct position of the switch ENABLE ANALOGUE INPUTS. (ON position: analogue part activated, other position: analogue part not activated)
 - Switch on the main switch.

Exchange is now finished.



Warning!


Send and store the boards **only** in the **original packaging material** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

Page 168 Issue: 20.08.95

21.7.3 Exchanging the Analogue Board PA 110

a) Observe the exchange instructions in section 21.1!

- b) Switch off the main switch.
- c) Disengage the connectors at the PA 110.



D-Sub connector Loosen knurled screw

d) Dismounting the PA 110

The PA 110 may be fixed in two ways:

1) via fixing bar

Dismounting: Use a screwdriver to pry the lock upwards and remove the PA 110 from the bar.

2) via four mounting screws:

Dismounting: • Loosen the mounting screws in the housing $(* \rightarrow)$

- Unscrew the base plate and reassemble the PA for shipping.
- e) The new PA 110 is mounted in reverse order:
 - Engage the connectors.
 - Switch on the main switch.

Exchange is now finished.



Warning!

Send and store the boards **only** in the **original packaging material** that protects them from acquiring static charge. Never use conventional plastics to wrap the boards in.

Page 169 Issue: 20.08.95

21.8 Exchanging the EPROMs

21.8.1 MOS Protection

To exchange the EPROMs MOS protection is indispensable, as otherwise the EPROMs could be destroyed by static charge.


Observe the mark on the EPROMs (do not turn them by 180°); be sure not to damage any components during the exchanged. Use an appropriate tool. After the software exchange the logic unit must be marked with the new NC-software number (see sections 5.1 and 5.2).

e.g. IC drawing punch and insertion tool






21.8.2 EPROM Designation



PROCESSOR Board


ld.No. 268 553 01



Note:

With the current software version IC-P3 / IC-P4 are not inserted.

RUN-IN: Internal test program (does not have to be exchanged together with the software)



Page 170 Issue: 20.08.95

22. Machine Parameter List



Code Numbers

123	MACHINE PARAMETER EDITING FOR END USERS (marked by *)
75368	OFFSET ADJUSTMENT
79513	VOLTAGE AND TEMPERATURE DISPLAY
86357	REMOVE EDIT/ERASE PROTECTION
95148	MP MODE
105296	COMPENSATION VALUE LIST
531210	RESET M 1000 TO M 2000 AND BYTES 0 - 127
620159	DOWNLOAD RUN-IN PROGRAM VIA INTERFACE
807667	PLC MODE
688379	INTERNAL OSCILLOSCOPE
951026	START RUN-IN PROGRAM FROM FPROM

Machine Parameters

In the following list the machine parameters for all software versions are listed.

Since however, certain machine parameters are only valid for a certain software version, or are only active from a certain software version on, columns with symbols for differentiation have been introduced after the machine parameter number.

Explanation of the Symbols:

- = The machine parameter applies for all software versions of this control.
- 04 = The machine parameter has been introduced with a certain software version (e.g. 04 means: introduced with software version 04).
- 104 = The machine parameter is inactive.
- = The machine parameter is not available with this control.

Explanation of the Columns:

- A = TNC 415B/F/BR/FR and TNC 425/E with NC software 259 93* or 259 94*
- B = TNC 415B/F/BR/FR and TNC 425/E with NC software 280 54* -- or 280 56* -- (special software)
- C = reserved
- AE6 = entry values for operation with HEIDENHAIN test unit

1.0 TNC 415B/425 Machine Parameters Overview 18.03.96 5.1

User Parameters

By means of the MOD function "User Parameters" certain machine parameters can be altered easily (e.g. adaptation of the data interface). The user parameters that are accessible via this MOD function are determined in machine parameters by the machine tool manufacturer.

Input Values

Input values are e.g.

- the numbers 0 and 1 to select functions, algebraic signs or the counting direction or
- numerical values for feed rates, displacement etc.
- decimal input values that can be calculated by combining several functions (bit-coded)
- bit patterns (selectable with %)

e.g. MP 10 : % 00111

i.e. X,Y,Z with encoder (1)

IV, V without encoder (0)

- hexadecimal values (selectable with \$)

e.g. MP 7353.0: \$ 0F818A0

Structure

RH

The machine parameters are subdivided into groups.

The parameter numbers are structured such that the list can be expanded easily.

0-999	Encoders and machine tool axes: allocation, evaluation, compensation
1000	Positioning
1400	Operation with feed precontrol
1700	Operation with servo lag
1900	Integral digital speed control (TNC 425)
2000	Integral speed and current control (TNC 426 PA)
3000	Spindle
4000	Integral PLC
5000	Adaptation of the data interface
6000	3D-touch probe (general parameters)
6200	Connection of measuring touch probe or touch trigger probe
6210	Digitizing with 3D-touch probe
6500	Tool calibration with TT 110
7100	Tapping
7200	Display and programming
7330	User parameters
7350	Colours, general display and FK graphics
7400	Operation and program run

Tilting the working plane

1.0 TNC 415B/425

Machine Parameters

Overview

7500

7600 Hardware

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Axes with encoder		10		+	•	•	0 = no encoder	
	Χ		0				+1 = X axis with encoder	% 11111
	Υ		1				+2 = Y axis with encoder	
	Ζ		2				+4 = Z axis with encoder	
	IV		3				+8 = IV. axis with encoder	
	V		4				+16 = V. axis with encoder	
Encoder monitoring		30		•	•	•	0 = no axis monitored	
Absolute position of distance-coded	Χ		0				+1 = X axis monitored	% 111111
reference marks	Υ		1				+2 = Y axis monitored	
	Ζ		2				+4 = Z axis monitored	
	IV		3				+8 = IV. axis monitored	
	V		4				+16 = V. axis monitored	
	S		5				+32 = S axis monitored	
Signal amplitude		31		•	•	•	0 = no axis monitored	
9 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	Χ		0				+1 = X axis monitored	% 111111
	Υ		1				+2 = Y axis monitored	
	Ζ		2				+4 = Z axis monitored	
	IV		3				+8 = IV. axis monitored	
	V		4				+16 = V. axis monitored	
	S		5				+32 = S axis monitored	
Edge separation		32		•	•	•	0 = no axis monitored	
	X	0_	0	,			+1 = X axis monitored	% 111111
	Y		1				+2 = Y axis monitored	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	Z		2				+4 = Z axis monitored	
	IV		3				+8 = IV. axis monitored	
	V		4				+16 = V. axis monitored	
	Š		5				+32 = S axis monitored	

1.0 TNC 415 B/425 Machine Parameters MP 10 - MP 32 03.01.95 5.2 1

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
VDU display	40					0 = no axis displayed	-
X		0	•	•	•	+1 = X axis displayed	% 111111
Υ		1	•	•	•	+2 = Y axis displayed	
Z		2	•	•	•	+4 = Z axis displayed	
IV		3	•	•	•	+8 = IV. axis displayed	
V		4	•	•	•	+16 = V. axis displayed	
S		5	80	•	•	+32 = position of regulated spindle	
						(not with M03/M04)	
Controlled axes	50		•	•	•	0 = no axis controlled	
		0				+1 = X axis controlled	% 11111
Υ		1				+2 = Y axis controlled	-
Z IV V		2				+4 = Z axis controlled	
		3				+8 = IV. axis controlled	
		4				+16 = V. axis controlled	
·		•				The state controlled	
PLC auxiliary axes	60		•	•	•	0 = no auxiliary axis	
X						+1 = X axis is auxiliary axis	% 00000
Υ						+2 = Y axis is auxiliary axis	
Z IV V						+4 = Z axis is auxiliary axis	
						+8 = IV. axis is auxiliary axis	
						+16 = V. axis is auxiliary axis	
Assignment of the encoder inputs						0 to 5	
to the machine axes X	110.0		•	•	•	TNC 415B/426CA: TNC 425: TNC 426PA: ²⁾	0
	110.1		•	•		0 = X1 $0 = X1/X15$ $0 = X1$	1
Z	110.2		•	•	•	1 = X2 $1 = X2/X16$ $1 = X2$	2
IV V	110.3		•	•		2 = X3 $2 = X3/X17$ $2 = X3$	3
	110.4		•			3 = X4 $3 = X4/X18$ $3 = X4$	4
			•	•	•	4 = X5 $4 = X5/X19$ $4 = X5$	·
						$5 = X6^{11}$ $5 = X6^{11}$ $5 = X6^{11}$	

1.0 TNC 415B/425 Machine Parameters MP 40 - MP 110.4 03.01.95 *5.2* 2

¹⁾ X6 may only be used for a machine axis, if no regulated spindle (GS) is required. ²⁾ The input assignment for the speed encoders (X15 - X20) is fixed: X15 = X axis, X16 = Y axis etc.

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Assignment of the nominal value outputs to the machine axes (no function, if MP 2000.X ≠ 0)	X Y Z IV V	120.0 120.1 120.2 120.3 120.4		•	• • •	•	0 to 5 0 = output 1 1 = output 2 2 = output 3 3 = output 4 4 = output 5 5 = output S 1)	0 1 2 3 4
Count direction of the encoder signals	X Y Z IV V	210	0 1 2 3 4	•	•	٠	0 = positive +1 = X axis negative +2 = Y axis negative +4 = Z axis negative +8 = IV. axis negative +16 = V. axis negative	(% 00000)
Signal period (displacement per grating period; consider the screw pitch when using a rotary encoder.) With square-wave input signals the displacement per square-wave period must be entered. (Consider external interpolation.)	X Y Z IV V	330.0 330.1 330.2 330.3 330.4		• • •	•	102 102 102 102 102	0.1 to 1000[μm]	20 20 20 20 20 20
Calculation of the signal period Path for counting pulses from MP 332.X	X Y Z IV V	331.0 331.1 331.2 331.3 331.4		- - - -	- - - -	02 02 02 02 02 02	0 to 99 999.9999 [mm]	0.02 0.02 0.02 0.02 0.02
Number of counting pulses from MP 331.X	X Y Z IV V	332.0 332.1 332.2 332.3 332.4		- - - -	- - - -	02 02 02 02 02 02	1 to 16 177 215 [counting pulses] The TNC automatically calculates the signal period. signal period [mm] = $\frac{MP331}{MP332}$	1 1 1 1 1

¹⁾ S-analogue may only be used for a machine axis, if no analogue output of the spindle speed is required.

1.0 TNC 415B/425 Machine Parameters MP 120.0 - MP 332.4 03.01.95 5.2 3

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Interpolation factor of the EXE						0, 1, 5	
at the encoder input	X	340.0	•	•	-		0
(TNC 415BR/FR only)	Υ	340.1	•	•	-	0 = no EXE	0
	Z	340.2	•	•	-	1 = 1-fold EXE	0
	IV	340.3	•	•	-	5 = 5-fold EXE	0
	V	340.4	•	•	-		0
Axis designation							
_	IV	410.3	•	•	•	0 = A $1 = B$ $2 = C$	4
	V	410.4	•	•	•	3 = U $4 = V$ $5 = W$	5
Hirth coupling							
Activation	IV	420.3	•	•	•	0 = inactive	0
	V	420.4	•	•	•	1 = active	0
Prescribed step	IV	430.3	•	•	•	0 to 30.0000 [°]	1
•	V	430.4	•	•	•		1

1.0 TNC 415B/425 Machine Parameters MP 340.0 - MP 430.4 03.01.95 5.2

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Axis correction:								
Backlash compensation	X	710.0		•	•	•	-1.0000 to +1.0000 [mm]	0
	Υ	710.1		•	•	•		0
	Z	710.2		•	•	•		0
	IV	710.3		•	•	•		0
	V	710.4		•	•	•		0
compensation of reversal spikes	in							
ircular interpolation								
magnitude of reversal spike	Χ	711.0		•	•	•	0 to 1 [mm]	0
	Υ	711.1		•	•	•		0
	Z	711.2		•	•	•		0
	IV	711.3		•	•	•		0
	V	711.4		•	•	•		0
feed rate to compensate								
the reversal spike	Χ	712.0		•	•	•	0 to 1 [mm per CLP cycle time]	0
	Υ	712.1		•	•	•		0
	Z	712.2		•	•	•		0
	IV	712.3		•	•	•		0
	V	712.4		•	•	•		0
magnitude of reversal spike								-
(only effective with M05)	Χ	715.0		08	•	•	0 to 1 [mm]	0
(ermy emocrate with wide)	Y	715.1		08	•	•		0
	Z	715.2		08	•	•		0
	IV	715.3		08	•	•		0
	V	715.4		08	·	·		0
feed rate to compensate the revers	al .							
spike (only effective with M05)	Х	716.0		08	•	•	0 to 1 [mm per CLP cycle time]	0
Spike (officetive with 1000)	Y	716.1		08	•	•	o to i [iiiii poi oli oyolo timoj	0
	Z	716.1		08		•		0
	IV	716.2		08		•		0
	\/	716.4		08		•		

1.0 TNC 415 B/425 Machine Parameters MP 710.0 - MP 716.4 03.01.95 5.2

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Factor for multipoint axis error								
compensation	X	720.0		•	•	•	-1.0000 to +1.0000 [mm/m]	0
	Υ	720.1		•	•	•		0
	Ζ	720.2		•	•	•		0
	IV	720.3		•	•	•		0
	V	720.4		•	•	•		0
Multipoint axis error compensation	1	730		•	•	•	0 = linear compensation active	% 00000
•	Χ		0				+1 = X axis, multipoint compensation active	
	Υ		1				+2 = Y axis, multipoint compensation active	
	Z		2				+4 = Z axis, multipoint compensation active	
	IV		3				+8 = IV. axis, multipoint compensation active	
	V		4				+16 = V. axis, multipoint compensation active	
Display mode							0 to ± 99 999.9999 [mm] or [°]	
for rotary axes and PLC auxiliary axes	Χ	810.0		•	•	•	$0 = \text{display} \pm 9999.9999$	0
,	Υ	810.1		•	•	•	(software limit switch active)	0
	Z	810.2		•	•	•	≠ 0 modulo value for display	0
	IV	810.3		•	•		(software limit switch inactive)	0
	V	810.4					(SOLLANGIE IIITIIL SANITOLI ILIGOTIAE)	0

1.0 TNC 415B/425 Machine Parameters MP 720.0 - MP 810.4 03.01.95 5.2 0

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Gantry axes							0 to 5	
Configuration	X	850.0		80	•	•		0
	Υ	850.1		80	•	•	0 = main axis	0
	Z	850.2		80	•	•	1 = tracked to X axis	0
	IV	850.3		80	•	•	2 = tracked to Y axis	0
	V	850.4		80	•	•	3 = tracked to Z axis	0
							4 = tracked to IV. axis	
							5 = tracked to V. axis	
Monitoring the synchronized movement o	f						0 to 100.0000 [mm]	
the coupled axes	×	855.0		_	02	06	0 = monitoring inactive	0
	Y	855.1		_	02	06	≠ 0 maximum deviation of master	0
	7	855.2		_	02	06	and slave axes	0
	ĪV	855.3		_	02	06	and clave axes	0
	V	855.4		-	02	06		0
Defining the relationship between the axe	S						0, 1	
	Χ	860.0		80	•	•	0 = referenced to position after power-on	0
	Υ	860.1		80	•	•	1 = referenced to REF marks (machine datum)	0
	Z	860.2		80	•	•		0
	IV	860.3		80	•	•		0
	V	860.4		80	•	•		0

1.0 TNC 415B/425 Machine Parameters MP 850.0 - MP 860.4 06.03.95 5.2 7

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Software limit switch ranges								
Range 1	X+	910.0		•	•		linear axis:	+99 999.9999
Default setting after power-on:	Y+	910.1		•	•		-99 999.9999 to +99 999.9999 [mm]	п
	Z+	910.2		•	•			п
Activation by PLC:	IV+	910.3		•	•		rotary axis:	ıı .
M2817 = 0, $M2816 = 0$	V+	910.4		•	•		-99 999.9999 to +99 999.9999 [°]	п
strobe marker M2824	X-	920.0		•	•			-99 999.9999
	Y-	920.1		•	•			п
	Z-	920.2		•	•			п
	IV-	920.3		•	•			п
	V-	920.4		•	•			п
Range 2								
- 3-	X+	911.0		•	•			+99 999.9999
Activation by PLC:	Y+	911.1		•	•			П
M2817 = 0, M2816 = 1	Z+	911.2		•	•			н
strobe marker M2824	IV+	911.3		•	•			п
	V+	911.4		•	•			н
	X-	921.0		•	•			-99 999.9999
	Y-	921.1		•	•			П
	Z-	921.2		•	•			п
	IV-	921.3		•	•			II
	V-	921.4		•	•			п
Range 3		02		•	•			
3 - 3	X+	912.0		•	•			+99 999.9999
Activation by PLC:	Y+	912.1		•	•			"
M2817 = 1, M2816 = 1	Z+	912.2		•	•			п
strobe marker M2824	IV+	912.3		•	·			п
	V+	912.4		•	·			п
	X-	922.0		•	•			-99 999.9999
	Y-	922.1		•	·			"
	Z-	922.2		•	·			п
	IV-	922.3		•	•			ıı ı
	V-	922.4		•	•			п
	v -	022.7		•	_			

1.0 TNC 415B/425 Machine Parameters MP 910.0 - MP 922.4 06.03.95 5.2 8

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Datum for positioning blocks with M92 (referenced to the machine datum)	X Y Z IV V	950.0 950.1 950.2 950.3 950.4		* * * *	* * * * * * * * * * * * * * * * * * * *	* * * * * * * * * * * * * * * * * * * *	linear axis: -99 999.9999 to +99 999.9999 [mm] rotary axis: -99 999.9999 to +99 999.9999 [°]	0 0 0 0
Target position for simulated tool change for TOOL CALL with block scan	X Y Z IV V	951.0 951.1 951.2 951.3 951.4		08 08 08 08	* * *	* * *	linear axis: -99 999.9999 to +99 999.9999 [mm] rotary axis: -99 999.9999 to +99 999.9999 [°]	0 0 0 0 0
Shifting the machine datum (referenced to the REF mark of the encoder)	X Y Z IV V	960.0 960.1 960.2 960.3 960.4		* * *	*	•	linear axis: -99 999.9999 to +99 999.9999 [mm] rotary axis: -99 999.9999 to +99 999.9999 [°]	0 0 0 0

1.0 TNC 415B/425 Machine Parameters MP 950.0 - MP 960.4 03.01.95 5.2 9

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Rapid traverse	Χ	1010.0		•	٠	•	linear axis:	10000
	Υ	1010.1		•	•	•	10 to 30 000 [mm/min]	п
	Ζ	1010.2		•	•	•	rotary axis:	п
	IV	1010.3		•	•	•	10 to 30 000 [°/min]	п
	V	1010.4		•	•	•		п
Manual feed	Х	1020.0		•	•	•	linear axis:	10000
	Υ	1020.1		•	•	•	10 to 30 000 [mm/min]	п
	Z	1020.2		•	•	•	rotary axis:	п
	IV	1020.3		•	•	•	10 to 30 000 [°/min]	п
	V	1020.4		•	•	•		п
Positioning window	Х	1030.0		•	•	•	linear axis:	0.05
-	Υ	1030.1		•	•	•	0.0001 to 2.0000 [mm]	п
	Z	1030.2		•	•	•	rotary axis	п
	IV	1030.3		•	•	•	0.0001 to 2.0000 [°]	п
	V	1030.4		•	•	•		п
Polarity		1040		•	•	•	0 = positive	
of the nominal value voltage	Χ		0				+1 = X axis negative	% 00000
(TNC 415B/425 1)/426CA)	Υ		1				+2 = Y axis negative	
or of the nominal shaft speed	Z		2				+4 = Z axis negative	
(TNC 425/426PA)	IV		3				+8 = IV. axis negative	
with positive traverse direction	V		4				+16 = V. axis negative	
Analogue voltage for rapid travers		1050.0		•	•	•	4.5 to 9 [V]	9
	Υ	1050.1		•	•	•		9
	Z	1050.2		•	•	•	no function with TNC 426 PA	9
	IV	1050.3		•	•	•	(entry value: 1)	9
	V	1050.4		•	•	•		9

¹⁾ analogue controlled

Machine Parameters MP 1010.0 - MP 1050.4 03.01.95 1.0 *5.2* 10

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Acceleration	Х	1060.0	•	•	•	0.001 to 3.0 [m/s ²]	1
	Υ	1060.1	•	•	•		1
	Ζ	1060.2	•	•	•		1
	IV	1060.3	•	•	•		1
	V	1060.4	•	•	•		1
Radial acceleration		1070	•	•	•	0.0001 to 3.0 [m/s ²]	1.5
Integral factor 1)	Х	1080.0	•	•	•	0 to 65 535	0
	Υ	1080.1	•	•	•		0
	Ζ	1080.2	•	•	•		0
	IV	1080.3	•	•	•		0
	V	1080.4	•	•	•		0
Standstill monitoring		1110.0	•	•	•	0.0001 to 30 [mm]	0.1
		1110.1	•	•	•		0.1
		1110.2	•	•	•		0.1
	IV	1110.3	•	•	•		0.1
	V	1110.4	•	•	•		0.1
							0.1
Movement monitoring	Χ	1140.0	•	+	•	0.03 to 10 [V] for TNC 415B/425 1)	1
	Υ	1140.1	•	•	•	0.03 to 10 [1000/min] for TNC 426 PA	1
	Ζ	1140.2	•	•	•	Note: entry value 10 ⇒ monitoring inactive	1
	IV	1140.3	•	•	•		1
	V	1140.4	•	•	•		1
							1
Time out to switch off the residual voltage on error message "Positioning Error"		1150	*	•	•	0 to 65 535 [s]	0
Automatic cyclical ²⁾ offset adjustment		1220	*	•	•	1 to 65 535 [s] 0 = no automatic adjustment	1

R H 1.0 TNC 415B/425 **Machine Parameters** MP1060.0 - MP 1220 06.03.95 **5.2** 11

¹⁾ analogue controlled ²⁾ no function with TNC 425 (MP 1900 \neq 0) and TNC 426 PA (MP 2000 \neq 0): entry value = 0

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Reference mark evaluation		1320		*	•	•	0 = positive	-
Direction for traversing the reference ma			0				+1 = X axis negative	% 00000
	Y		1				+2 = Y axis negative	
	Z		2				+4 = Z axis negative	
	IV		3				+8 = IV. axis negative	
	V		4				+16 = V. axis negative	
Feed rate for traversing the reference ma	arks							
	X	1330.0		•	•	•	linear axis:	10 000
	Υ	1330.1		•	•	•	10 to 30 000 [mm/min]	П
	Z	1330.2		•	•	•		П
	IV	1330.3		•	•	•	rotary axis:	П
	V	1330.4		•	•	•	10 to 30 000 [°/min]	П
Feed rate for leaving the reference end-								
position	X	1331.0		•	•	•	linear axis:	200
(only if $MP1350 = 2$)	Υ	1331.1		•	•	•	10 to 500 [mm/min]	П
1117 11 1000 = 27	Z	1331.2		•	•	•		П
	IV	1331.3		•	•	•	rotary axis:	П
	V	1331.4		•	•	•	10 to 500 [°/min]	п
Axis sequence for reference mark travers	se						0 = no ref. mark traverse	
·	1. axis	1340.0		•	•	•	1 = X	1
	2. axis	1340.1		•	•	•	2 = Y	2
	3. axis	1340.2		•	•	•	3 = Z	3
	4. axis	1340.3		•	•	•	4 = IV	4
	5. axis	1340.4		•	•	•	5 = V	5
Type of reference mark approach	X	1350.0		•	•	•	0 = position encoder with distance-coded	1
,,	Υ	1350.1		•	•	•	reference marks (1. mode)	1
	Z	1350.2		•	•	•	1 = position encoder without distance-coded	1
	IV	1350.3		•	•	•	reference marks	1
	V	1350.4		•	•	•	2 = special function (linear measurement	1
							with rotary encoder)	
							3 = position encoder with distance-coded	
							reference marks (2. mode)	

1.0 TNC 415B/425 Machine Parameters MP 1320 - MP 1350.4 03.01.95 5.2 12

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Feed forward control or trailing		1390		•	•	•	0 = feed forward control	0
mode							1 = trailing mode	
in the operating modes								
"Positioning with MDI"								
"Program Run / Single Block"								
"Program Run / Full Sequence"								
Feed forward control		1391		-	02	02	bit not set:	% 00000
in all operating modes	Χ		0				control in the operating modes "Positioning with	
	Υ		1				MDI", "Program Run / Single Block" and "Program	
	Ζ		2				Run / Full Sequence" according to MP1390	
	IV		3				bit set:	
	V		4				feed forward control in all operating modes	

Operation with Feed Forward Control

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Position monitoring in operation with feed forward control cancellable (POSITIONING ERROR)	X Y	1410.0 1410.1		•	•	•	0.0001 to 30.0000 [mm]	3 3
	Z IV V	1410.2 1410.3 1410.4		• •	* *	• •		3 3 3
EMERGENCY STOP (GROSS POSITIONING ERROR)	X Y Z IV V	1420.0 1420.1 1420.2 1420.3 1420.4		•	*	* * *	0.0001 to 30.0000 [mm]	4 4 4 4 4

ъп 1.0 TNC 415B/425 Machine Parameters MP1390 - MP 1420.4 03.01.95 5.2 13

Cams for "Reference End Position":

The reference marks can either be traversed manually using the axis direction keys or automatically with the start key. It is not necessary to enter a code number for the manual traverse as was the case with preceding TNC models. The traverse direction for automatic traverse of the reference marks is defined in MP1320. In order to reverse the traverse direction at the end of the traverse range, a cam for "reference end position" is required. The trigger signals "ref. end position" are assigned to free PLC inputs. By the PLC software these PLC inputs are connected to the PLC markers M2506 and M2556 to M25599. Depending on the entry value of MP1350 the TNC behaves differently.

Linear Encoder with Distance-Coded Reference Marks (MP 1350.X = 0), Mode 1

If the trigger signal "ref. end position" is set when starting reference mark traverse, the axis moves in the direction opposite to that set in the MP1320. If the trigger signal "ref. end position" is only set during automatic traverse, the TNC ignores this signal. Thus, there must be at least two reference marks within the range of the "reference end position". Ref. mark evaluation takes place either in the range of the "ref. end position" or else beyond this range. In case of an evaluation beyond the software limit switch range, the axis automatically moves to the software limit switch after evaluation.

Linear Encoder without Distance-Coded Reference Marks (MP 1350.X = 1)

The traverse direction is automatically reversed, if the axis traverses the cam for "ref. end position". If the axis is already in the range of the "reference end position" range when starting, it moves immediately in the opposite direction. For this reason the reference mark has to be outside the "ref. end position" range.

Special Operation: Linear Measurement with a Rotary Encoder (MP1350.X = 2)

The axis automatically moves to the cam for "reference end position" at the defined feed rate (MP1330). This axis is started again at a reduced feed rate (MP1331) in the opposite direction; the first reference mark is evaluated after the end of the "reference end position" range has been reached. Then the axis is stopped. If the axis is already in the "reference end position" range when starting, it moves immediately at the reduced feed rate (MP1331) in the direction opposite to that indicated in MP1320.

Linear Encoder with Distance-Coded Reference Marks (MP1350.X = 3), Mode 2

If the trigger signal "reference end position" is set during reference mark traverse, the axis moves opposite to the direction defined in MP1320. The signal "ref. end position" is not ignored by the NC. it is only set during automatic traverse. The traverse direction is reversed immediately. Thus, no reference marks are required in the "ref. end position" range.

1.0 TNC 415B/425 Machine Parameters MP1350.X 03.01.95 5.2 14

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
1. block of Kv factors	Χ	1510.0	+	+		0.1 to 20	1
for operation with feed forward	Υ	1510.1	•	•			1
control	Z	1510.2	•	•			1
	IV	1510.3	•	•			1
	V	1510.4	•	•			1
Stiction compensation	Χ	1511.0	•	•		0 to 16 777 215 [µs]	0
Duration of stiction compensation	Υ	1511.1	•	•			0
(differential part)	Z	1511.2	•	•			0
	IV	1511.3	•	•			0
	V	1511.4	•	•			0
Limit of extent of stiction compensation	Χ	1512.0	•	•		0 to 16 777 215 [counting steps]	0
(differential part)	Υ	1512.1	•	•			0
·	Z	1512.2	•	•			0
	IV	1512.3	•	•			0
	V	1512.4	•	•			0
Feed rate for stiction compensation	Χ	1513.0	•	•		0 to 300 000 [mm/min]	0
(differential part)	Υ	1513.1	•	•			0
·	Ζ	1513.2	•	•			0
	IV	1513.3	•	•			0
	V	1513.4	•	•			0
2. block of Kv factors	Χ	1515.0	•	•		0.1 to 10	1
for operation with feed forward	Υ	1515.1	•	•			1
control	Ζ	1515.2	•	•			1
M105: enable	IV	1515.3	•	•			1
M106: inhibit	V	1515.4	•	•			1
Approach speed and transient		1520	•	•		0.1 to 10 [m/min]	1
behaviour when accelerating							
Feed rate below which the						0.1 to 10.000 [mm/min]	
positioning window is monitored	X	1525.0	-	02			0
	Υ	1525.1	-	02		recommended value: 0.5 mm/min	0
	Z	1525.2	-	02		·	0
	IV	1525.3	-	02			0
	V	1525.4	_	02			0

1.0 TNC 415B/425 Machine Parameters MP 1510.0 - MP 1525.4 08.05.95 5.2 15

Operation with Servo Lag

Function		MP No. Bi	A	В	С	Input	AE-6 Entry value
Position monitoring during operation with servo lag cancellable (POSITIONING ERROR)	X Y Z IV	1710.0 1710.1 1710.2 1710.3	•	* *	•	0 to 300 [mm]	20 20 20 20 20
EMERGENCY STOP	V	1710.4	•	•	•		20
(GROSS POSITIONING ERROR)	X Y Z IV V	1720.0 1720.1 1720.2 1720.3 1720.4	* * *	* * *	* * *	0 to 300 [mm]	30 30 30 30 30
1. block of Kv factors for the trailing mode	X Y Z IV V	1810.0 1810.1 1810.2 1810.3 1810.4	*	* * *	* * *	0.1 to 10	1 1 1 1
2. block of Kv factors for the trailing mode M105: enable M106: inhibit	X Y Z IV V	1815.0 1815.1 1815.2 1815.3 1815.4	*	* * *	•	0.1 to 10	1 1 1 1

1.0 TNC 415B/425 Machine Parameters MP 1710.0 - MP 1815.4 03.01.95 5.2 16

Function		MP No. B	it A	`	В	С	Input	AE-6 Entry value
Multiplication factor for Kv (not effective with M105)	X Y Z IV V	1820.0 1820.1 1820.2 1820.3 1820.4	•		• • •	* * *	0.001 to 1.000	1 1 1 1 1
Kink point	X Y Z IV V	1830.0 1830.1 1830.2 1830.3 1830.4	•		• • •	* * *	0 to 100.000 [%]	100 100 100 100 100

TNC 415B/425 Machine Parameters MP 1820.0 - MP 1830.4 03.01.95 *5.2* 17

Integral Digital Speed Control (TNC 425)

		MP						AE-6
Function		No.	Bit	A	В	С	Input	Entry value
Selecting the axes		1900		•	•		0 to 31	% 11111
with digital speed controller	Χ		0				0 = axis with analogue controller	
	Υ		1				+1 = X axis with digital controller	
	Ζ		2				+2 = Y axis with digital controller	
	IV		3				+4 = Z axis with digital controller	
	V		4				+8 = IV. axis with digital controller	
							+16 = V. axis with digital controller	
Speed controller monitoring	Χ	1910.0		*	•		1 to 167 215 [counting steps]	5000
	Υ	1910.1		•	•			5000
	Ζ	1910.2		•	•			5000
	IV	1910.3		•	•			5000
	V	1910.4		•	•			5000
Integral component for the speed	Χ	1920.0		•	•		0 to 65 535	100
controller	Υ	1920.1		•	•			100
	Ζ	1920.2		•	•			100
	IV	1920.3		•	•			100
	V	1920.4		•	•			100
Limitation of the integral factor for							0 to 30.000 [s]	
the speed controller (PT1 element)	Χ	1925.0		-	•		0 = inactive (normal case)	0
	Υ	1925.1		-	•		Standard value: 0.1 to 2.0 [s]	0
	Ζ	1925.2		-	•		entry value 2: → normal effect	0
	IV	1925.3		_	•		entry value 0.1: → very strong effect	0
	V	1925.4		_			This function should only be used, if the drive jogs	0
	•						during standstill due to stiction.	
							The larger the entry value, the more the behavior	
							resembles that of a PI controller.	
Proportional component for the						-	0 to 65 535	
speed controller	Χ	1940.0			•		0 10 00 000	250
apoeu controller	Y	1940.0		*				250
	Z	1940.1		•				250
	۱V	1940.2		•	•			250
	\/	1940.3		•	•			250
	V	1940.4		•	•			250

1.0 TNC 415B/425 Machine Parameters MP 1900 - MP 1940.4 03.06.96 5.2 18

	MP						AE-6
Function	No.	Bit	Α	В	С	Input	Entry value
Factor for acceleration feedforward						0 to 9.999 [V/(m/s²)]	
control of the speed controller X	1945.0			•			0
Y	1945.1			•			0
Z	1945.2			•			0
IV	1945.3			•			0
V	1945.4			•			0
Polarity of torque signal	1950		•	•		0 to 31	% 00000
, X		0				0 = positive	
Υ		1				+1 = X axis negative	
Z		2				+2 = Y axis negative	
IV		3				+ 4 = Z axis negative	
V		4				+ 8 = IV. axis negative	
						+ 16 = V. axis negative	
Selecting the measuring systems	1951		•	•		0 to 31	% 00000
						0 = 2 measuring systems for each axis:	
						- linear encoder for position	
						- rotary encoder for speed	
X		0				+1 = 1 measuring system (rotary encoder) for both	
						position and speed (X axis)	
Υ		1				+2 = Y axis	
Z		2				+4 = Z axis	
ĪV		3				+8 = IV. axis	
V		4				+16 = V. axis	
Ratio of grating period		-					
LS to ROD X	1955.0		•	•		0.1 to 100	1
Y	1955.1		•	·			1
Ž	1955.2		•	·		(the entry values should be >5)	1
IV	1955.3		•	·		(and sindy randod direction and polytopic	1
\ <u></u>	1955.4		•	•			'1

1.0 TNC 415B/425 Machine Parameters MP 1945.0 - MP 1955.4 03.06.96 5.2 19

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Compensation for reversal spikes							
with digitally controlled driving	Χ	1960.0	•	•		-1.0000 to +1.0000 [mm]	0
axes	Υ	1960.1	•	•			0
	Z	1960.2	•	•			0
	IV	1960.3	•	•			0
	V	1960.4	•	•			0
Movement monitoring for position							
and speed	X	1970.0	•	•		0 to 1 [mm]	0,5
(only for digitally controlled driving axes)	Υ	1970.1	•	•			0,5
	Z	1970.2	•	•		Note : entry value 0 ⇒ monitoring inactive	0,5
	IV	1970.3	•	•			0,5
	V	1970.4	•	•			0,5
Delayed shutdown of speed							
controller in EMERGENCY STOP		1980	•	•		0 to 1.999 [s]	0

1.0 TNC 415B/425 Machine Parameters MP 1960 - MP 1980 18.03.96 5.2 20

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Maximum current 1)	Χ	2110.0	-	-	•	0 to 999.999[Ap]	0
of the power stage	Υ	2110.1	-	-	•	e.g. with SIEMENS power stage 6SN1123-1AA00-	0
	Z	2110.2	-	-	•	OBAO:	0
	IV	2110.3	-	-	•	6SN1123-1AA00-0BA0:	0
	V	2110.4	-	-	•	$18 \text{ A} \cdot \sqrt{2} = 25.45 \text{ Ap}$	0
	S	2110.5	-	-	•	see MP2310	0
Nominal current 1)	Χ	2120.0	-	-	•	0 to 999.999[Ap]	0
(reference value for I ² t monitoring)	Υ	2120.1	-	-	•	e.g.with SIEMENS power stage 6SN1123-1AA00-0BA0:	0
	Z	2120.2	-	-	•	6SN1123-1AA00-0BA0:	0
	IV	2120.3	-	-	•	$9 \text{ A} \cdot \sqrt{2} = 12.72 \text{ Ap}$	0
	V	2120.4	-	-	•	377 12.72	0
	S	2120.5	-	-	•		0
Voltage of the current sensor	Χ	2130.0	-	-	•	0 to 99.999[V]	0
with peak current	Υ	2130.1	-	-	•	with HEIDENHAIN interface card: 7.5V	0
	Z	2130.2	-	-	•		0
	IV	2130.3	-	-	•		0
	V	2130.4	-	-	•		0
	S	2130.5	-	-	•		0
Motor type 2)	Χ	2200.0	-	-	•	0 to 5	0
	Υ	2200.1	-	-	•	0 = synchronous motor	0
	Z	2200.2	-	-	•	1 = asynchronous motor	0
	IV	2200.3	-	-	•	2 to 5 = reserved	0
	V	2200.4	-	-	•		0
	S	2200.5	-	-	•		0

¹⁾ entry values depending on the power stage: see table 1 on page 21.1 ²⁾ entry values depending on the motor: see table 2 on page 21.1

1.0 TNC 415B/425/426 Machine Parameters MP 2110.0 - MP 2200.5 06.03.95 *5.2* 21

Table 1: Entry values depending on the power stage

The following SIEMENS power stages can be connected to TNC 426 PA:

					6SN112	3-1AA00					6SN	1123-1 <i>A</i>	AB00
	0AA0	OBAO	ОС	A0	0D	A 0	0E	A0	OF	A 0	0AA0	0BA0	0CA0
			VSA	HSA	VSA	HSA	VSA	HSA	VSA	HSA			
MP2110	14.14	25.45	50.91	50.91	79.2	79.2	158.4	158.4	198	198	14.14	25.45	50.91
MP2120	7.07	12.72	25.45	33.94	39.6	42.42	79.2	84.85	99	120.2	7.07	12.72	25.45

When using non-SIEMENS power stages, please contact HEIDENHAIN.

Table 2: Entry values depending on the motor

The following SIEMENS drives can be connected to TNC 426 PA:

	1FT6064 6AC71	1FT6084 8AC71	1FT6086 8AC71	1FT6062 6AH71	1FT6082 8AH71	1PH6103 4NG4	1PH6107 4NG4
MP2200	0	0	0	0	0	1	1
MP2210	2 000	2 000	2 000	4 500	4 500	2 000	2 000
MP2220	2 915	3 080	2 970	6 435	6 930	9 900	9 900
MP2230	3	4	4	3	4	2	2
MP2280	0	0	0	0	0	14.0	22.1
MP2290	0	0	0	0	0	162	189
MP2300	5.4	11.8	15.4	5.5	11.5	28.3	43.8
MP2310	21.5	46.95	61.7	22.06	62.2	45.3	70.1

When using non-SIEMENS drives, please contact HEIDENHAIN.

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Nominal speed (synchronous motor) 1)	Χ	2210.0	-	-	•	0 to 10 000[rpm]	0
Kink point rpm (asynchronous motor) 1)	Υ	2210.1	-	-	•		0
	Ζ	2210.2	-	-	•		0
	IV	2210.3	-	-	•		0
	V	2210.4	-	-	•		0
	S	2210.5	-	-	•		0
Maximum shaft speed ¹⁾	Χ	2220.0	-	-	•	0 to 99 999[rpm]	0
	Υ	2220.1	-	-	•	(value from table plus 10%)	0
	Ζ	2220.2	-	-	•	When operating with servo lag, the speed is limited to	0
	IV	2220.3	-	-	•	the value of MP 2220. When operating with feed for-	0
	V	2220.4	-	-	•	ward control, the error message GROSS POSITIONING	0
	S	2220.5	-	-	•	ERROR <axis> B is generated when the value of MP 2220 is reached.</axis>	0
Number of pairs of poles 1)	Χ	2230.0	-	-	•	1 to 4	1
•	Υ	2230.1	-	-	•		1
	Ζ	2230.2	-	-	•		1
	IV	2230.3	-	-	•		1
	V	2230.4	-	-	•		1
	S	2230.5	-	-	•		1
ine count of rotary encoder	Χ	2240.0	-	-	•	0 to 10 000 [lines per revolution]	0
speed encoder)	Υ	2240.1	-	-	•	0 = non-controlled axis (no encoder monitoring)	0
	Ζ	2240.2	-	-	•		0
	IV	2240.3	-	-	•		0
	V	2240.4	-	-	•		0
	S	2240.5	-	_	•		0

¹⁾ entry values depending on the motor: see table 2 on page 21.1

1.0 TNC 415B/425/426 Machine Parameters MP 2210.0 - MP 2240.5 06.03.95 5.2 22

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Counting direction of the signals o	f X	2250.0	-	-	•	0 = not inverted	0
the rotary encoder	Υ	2250.1	-	_	•	1 = inverted	0
•	Ζ	2250.2	-	_	•		0
	IV	2250.3	-	_	•		0
	V	2250.4	-	_	•		0
	S	2250.5	-	-	•		0
Motor constant	Χ	2260.0	-	-	•	0 to 99.999[Nm/A]	0
	Υ	2260.1	-	-	•	with SIEMENS drives: 0	0
	Z	2260.2	-	-	•		0
	IV	2260.3	-	-	•		0
	V	2260.4	-	-	•		0
	S	2260.5	-	-	•		0
Max. motor temperature	Χ	2270.0	-	-	•	0 to 255[°C]	0
	Υ	2270.1	-	-	•	255 = no monitoring	0
	Z	2270.2	-	-	•	with SIEMENS drives: 150	0
	IV	2270.3	-	-	•		0
	V	2270.4	-	-	•		0
	S	2270.5	-	-	•		0
Magnetising current 1)	X	2280.0	-	-	•		0
	Υ	2280.1	-	-	•	0 to 99.999[Ap]	0
	Z	2280.2	-	-	•	e.g. with SIEMENS motor 1PH6103/:	0
	IV	2280.3	-	-	•	$9.9 \text{ A} \cdot \sqrt{2} = 12.72 \text{ Ap}$	0
	V	2280.4	-	-	•		0
	S	2280.5	-	-	•		0

¹⁾entry values depending on the motor: see table 2 on page 21.1

1.0 TNC 415B/425/426 Machine Parameters MP2250.0 - MP 2280.5 06.03.95 5.2 23

Function		MP	Α	В	С	Input	AE-6
		No. B	it				Entry value
Time constant of armature 1)	Χ	2290.0	-	-	•	0 to 10 000[ms]	0
	Υ	2290.1	-	-	•	Example: Calculation of time constant of the armature from the motor	0
	Ζ	2290.2	-	-	•	parameters of the SIEMENS spindle motor 1PH6107-4GN4	0
	IV	2290.3	-	-	•	SIEMENS motor parameters:	0
	V	2290.4	-	-	•	P164 = nom. frequency = 68.9 Hz	0
	S	2290.5	-	-	•	P168 = resistance of armature (cold) = 157 m Ω	0
						P170 = leakage reactance of armat. = 785 m Ω	
						P171 = reactance of main field = 12 090 m Ω	
						$MP2290 = \frac{(P171[m\Omega] + P170[m\Omega] \cdot 1000}{2 \cdot \Pi \cdot P164[Hz] \cdot P168[m\Omega]} [ms] =$	
						$= \frac{(12090 + 785) \cdot 1000}{2 \cdot \Pi \cdot 68,9 \cdot 157} [ms] = 189 [ms]$	
Nominal value of motor 1)	Χ	2300.0	-	-	•	0 to 100.000[A]	0
(reference value for "utilization"	Υ	2300.1	-	-	•	MP 2300 is used to calculate the I ² t monitoring and the utilization	0
display and for I2t monitoring)	Ζ	2300.2	-	-	•	display (modules 9160 and 9166)	0
	IV	2300.3	-	-	•		0
	V	2300.4	-	-	•		0
	S	2300.5	-	-	•		0
Maximum current 1)	Χ	2310.0	-	-	•	0 to 100.000[Ap]	0
of motor	Υ	2310.1	-	-	•		0
	Ζ	2310.2	-	-	•	The speed controller limits the maximum current to the minimum	0
	IV	2310.3	-	-	•	value of MP2110 and MP2310.	0
	V	2310.4	-	-	•		0
	S	2310.5	-	-	•		0
reserved		2320.x	-	-	•	entry value 0	0
reserved		2330.x	-	-	•	entry value 0	0

¹⁾ entry values depending on the motor: see table 2 on page 21.1

1.0 TNC 415B/425/426 Machine Parameters MP 2290.0 - MP 2330.x 06.03.95 5.2 24

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Amplification for current controller	Χ	2400.0	-	_	•	0 to 30 000 [1/V]	0
•	Υ	2400.1	-	-	•	0 = controller inhibited	0
	Ζ	2400.2	-	-	•		0
	IV	2400.3	-	-	•		0
	V	2400.4	-	-	•		0
	S	2400.5	-	-	•		0
reserved	Χ	2410.0	-	-	•	0	0
	Υ	2410.1	-	-	•		0
	Ζ	2410.2	-	-	•		0
	IV	2410.3	-	-	•		0
	V	2410.4	-	-	•		0
	S	2410.5	-	-	•		0
Proportional factor of the current	Χ	2500.0	-	-	•	0 to 100 000[Ap]	0
controller	Υ	2500.1	-	-	•		0
	Ζ	2500.2	-	-	•		0
	IV	2500.3	-	-	•		0
	V	2500.4	-	-	•		0
	S	2500.5	-	-	•		0
Integral factor of the current	Χ	2510.0	-	-	•	0 to 100 000[A]	0
controller	Υ	2510.1	-	-	•		0
	Ζ	2510.2	-	-	•		0
	IV	2510.3	-	-	•		0
	V	2510.4	-	-	•		0
	S	2510.5	-	-	•		0
reserved	Χ	2520.0	-	-	•	0	0
	Υ	2520.1	-	-	•		0
	Ζ	2520.2	-	-	•		0
	IV	2520.3	-	-	•		0
	V	2520.4	-	-	•		0
	S	2520.5	-	-	•		0
reserved	Χ	2530.0	-	-	02	0	0
	Υ	2530.1	-	-	02		0
	Ζ	2530.2	-	-	02		0
	IV	2530.3	-	-	02		0
	V	2530.4	-	-	02		0
	S	2530.5	-	-	02		0

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
reserved	Χ	2600.0	-	-	•	0	0
	Υ	2600.1	-	-	•		0
	Z	2600.2	-	-	•		0
	IV	2600.3	-	-	•		0
	V	2600.4	-	-	•		0
	S	2600.5	-	-	•		0
reserved	X	2610.0	-	-	•	0	0
	Υ	2610.1	-	_	•		0
	Ζ	2610.2	-	_	•		0
	IV	2610.3	-	_	•		0
	V	2610.4	-	_	•		0
	S	2610.5	-	_	•		0
eserved	Х	2620.0	_	-	•	0	0
	Υ	2620.1	-	_	•		0
	Z	2620.2	-	_	•		0
	IV	2620.3	-	_	•		0
	V	2620.4	-	_	•		0
	S	2620.5	-	_	•		0
Holding current for height axes	Х	2630.0	-	-	06	0 to ± 30 [A]	0
3	Y	2630.1	_	_	06		0
	Ž	2630.2	_	_	06		0
	ĪV	2630.3	_	_	06		0
	V	2630.4	_	_	06		0
	S	2630.5	-	_	06		0
Movement monitoring	X	2800.0	_	_	02	0 to 99 999.999[mm]	0
position and speed	Y	2800.1	_	-	02	0 = no monitoring	0
	Ž	2800.2	-	_	02	The position is calculated from the pulses of the	0
	١V	2800.3	-	_	02	position encoder and from the pulses of the speed	0
	V	2800.4	-	-	02	encoder. If the difference of the results exceeds the	0
	·	2000.1			02	value of MP2800, the error message GROSS POSITIONING ERROR <axis> C is generated.</axis>	0

1.0 TNC 415B/425/426 Machine Parameters MP 2600.0 - MP 2800.4 06.03.95 5.2 26

Spindle

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Output of the spindle speed	3010	•	•	•	0 = spindle speed not output	6
coded					1 = only if speed changes 2 = with every TOOL CALL	
analogue					 3 = gear switching signal only if gear range changes 4 = gear switching signal with every TOOL CALL 5 = no gear switching signal 	
controlled spindle for orientation					6 = gear switching signal only if gear range changes 7 = gear switching signal with every TOOL CALL 8 = no gear switching signal	
Output of an analogue voltage at the analogue output of the spindle (only if MP3010 < 3)	3011	* * -	*	•	0 = no function 1 = voltage is proportional to the current feed rate 2 = voltage defined via PLC (module 9130) 3 = voltage defined via M-function (M200 - M204)	0
Feed rate that corresponds to an analogue voltage of 10V (only if MP3011 = 1)	3012	•	•	•	0 to 300 000 [mm/min]	0

1.0 TNC 415B/425/426 Machine Parameters MP 3010 - MP 3012 06.03.95 5.2 27

Function	MP No. B	it A	В	С	Input	AE-6 Entry value
LASER function with M202					10 to 300 000 [mm/min]	-
Characteristic curve kink points					, ,	
Speed	3013.0	-	•	•		0
	3013.1	-	•	•		0
	3013.2	-	•	•		0
	3013.3	-	•	•		0
	3013.4	-	•	•		0
	3013.5	-	•	•		0
	3013.6	-	•	•		0
	3013.7	-	•	•		0
	3013.8	-	•	•		0
	3013.9	-	•	•		0
	3013.10	-	•	•		0
	3013.11	-	•	•		0
Characteristic curve kink points	3014.0	-	•	•	0 to 9.999 [V]	0
Voltage	3014.1	-	•	•	,	0
	3014.2	-	•	•		0
	3014.3	-	•	•		0
	3014.4	-	•	•		0
	3014.5	-	•	•		0
	3014.6	-	•	•		0
	3014.7	-	•	•		0
	3014.8	-	•	•		0
	3014.9	-	•	•		0
	3014.10	-	•	•		0
	3014.11	-	•	•		0
Definition of the spindle speed	3020	04	•	•	0 to 99 999	00991
range					00991 = no limitation	

1.0 TNC 415B/425/426 Machine Parameters MP 3013 - MP 3020 03.01.95 5.2 28

Function			MP No. Bit	A	В	С	Input	AE-6 Entry value
Axis halt on TOOL spindle speed outp		a	3030	•	•	•	0 = axis halt 1 = no axis halt	0
Programming the s S = 0 (if MP3240.1 ≠	•		3120	•	•	•	$0 \Rightarrow S = 0$ permitted $1 \Rightarrow S = 0$ not permitted	0
Polarity • of S-analogue voltag (TNC 415B/425/426CA) • of nominal spindle sp (TNC 426 PA)	A)		3130	•	•	•	0 = M03: positive M04: negative 1 = M03: negative M04: positive 2 = M03 and M04: positive 3 = M03 and M04: negative	0
Count direction of encoder	the spindle		3140	*	•	•	0 = positive 1 = negative	0
Line count of the s	spindle encoder		3142	-	-	•	0 = 1024 lines 1 = 2048 lines	0
S-analogue voltage	e with							
nominal speed	gear range	1	3210.0	•	•	•	0 to 9.999 [V]	9
	gear range	2	3210.1	•	•	•		9
	gear range	3	3210.2	•	•	•		9
	gear range	4	3210.3	•	•	•		9
	gear range	5	3210.4	•	•	•		9
	gear range	6	3210.5	•	•	•		9
	gear range	7	3210.6	•	•	•		9
	gear range	8	3210.7	•	•	•		9
Revolutions of the	motor with							
nominal speed							0 to 9.999 [1000/min]	
(TNC 426 PA)	gear range	1	3210.0	-	-	•		9
	gear range	2	3210.1	-	-	•		9
	gear range	3	3210.2	-	-	•		9
	gear range	4	3210.3	-	-	•		9
	gear range	5	3210.4	-	-	•		9
	gear range	6	3210.5	-	-	•		9
	gear range	7	3210.6	-	-	•		9
	gear range	8	3210.7	-	-	•		9

1.0 TNC 415B/425/426 Machine Parameters MP 3030 - 3210.7 06.03.95 5.2 29

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Controlled range for S-analogue output	-					,
Min. S-analogue voltage that can be output	3240.1	•	•	•	0 to 9.999 [V]	0
Jog voltage for gear switching (markers for direction of rotation: M2490/M2491)	3240.2	•	•	•	0 to 9.999 [V]	0.1
Controlled range for S-speed output (TNC 426 PA)						
Min. motor speed that can be output	3240.1	-	-	•	0 to 9.999 [1000/min]	0
Motor speed for gear switching (markers for direction of rotation: M2490/M2491)	3240.2	-	-	•	0 to 9.999 [1000/min]	0.1
Limit with S-override max.	3310.0	•	•	•	0 to 150 [%]	150
min. Ramp gradient of the spindle:	3310.1	•	*	•	0 to 1.999 [V/ms]	0
• Spindle ON/OFF, M03, M04, M05;	3410.0	•	•	•		0.1
Oriented spindle stop	3410.1	•	•	•		0.1
• "Tapping" cycle	3410.2	•	•	•		0.1
 Tapping without floating tap holder (Rigid Tapping) 	3410.3	•	•	•		0.1
Ramp gradient of the spindle: (TNC 426 PA)					0 to 1.999 [\frac{1000 / \text{min}}{\text{max}}]	
• Spindle ON/OFF, M03, M04, M05;	3410.0	-	-	•	IIIS	0.1
Oriented spindle stop	3410.1	-	-	•		0.1
• "Tapping" cycle	3410.2	-	-	•		0.1
 Tapping without floating tap holder (Rigid Tapping) 	3410.3	-	-	•		0.1

Function			MP No. E	Bit	A	В	С	Input	AE-6 Entry value
Transient response of	of the spindle:							0 to 1000[ms]	
• Spindle ON/OFF, M03,	M04, M05;		3415.0		-	-	•		1
 Oriented spindle stop 			3415.1		-	-	•		1
• "Tapping" cycle			3415.2		-	-	•		1
• "Rigid Tapping" cycle			3415.3		-	-	•		1
Positioning window	for the spindle		3420		•	•	•	0 to 65 535 [increments]	10
Spindle pre-set			3430		•	•	•	0 to 360 [°]	0
Kv factor for the spi	ndle								
(per gear range)	gear range	1	3440.0		•	•	•	0.1 to 10	1
	gear range	2	3440.1		•	•	•		1
	gear range	3	3440.2		•	•	•		1
	gear range	4	3440.3		•	•	•		1
	gear range	5	3440.4		•	•	•		1
	gear range	6	3440.5		•	•	•		1
	gear range	7	3440.6		•	•	•		1
	gear range	8	3440.7		•	•	•		1

1.0 TNC 415B/425/426 Machine Parameters MP 3415.0 - MP 3440.7 03.01.95 5.2 31

Function		MP No. Bi	A A	В	С	Input	AE-6 Entry value
Nominal spindle speed gear range gear range gear range	1 2 3	3510.0 3510.1 3510.2	•	• •	•	0 to 99 999.999 [rpm]	1000 2000 3000
gear range gear range gear range gear range gear range	4 5 6 7 8	3510.3 3510.4 3510.5 3510.6 3510.7	•	* * *	•		4000 5000 6000 7000 8000
Maximum spindle speed gear range	1 2 3 4 5 6 7 8	3515.0 3515.1 3515.2 3515.3 3515.4 3515.5 3515.6 3515.7	•	•	•	0 to 99 999 [rpm]	1200 2400 3600 4800 6000 7200 8400 9600
Spindle speed activated by marker 2501		3520.0	•	•	•	0 to 99 999.999 [rpm] direction of rotation is always positive	200
Spindle speed for oriented spindle stop		3520.1	•	•	•	0 to 99 999.999 [rpm]	100

1.0 TNC 415B/425/426 Machine Parameters MP 3510.0 - MP 3520.1 06.03.95 5.2 32

Integral PLC

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
PLC program from RAM or from EPROM		4010		•	•	-	+ 0 = EPROM operation + 1 = RAM operation	0
PLC compatibility to TNC 415/425		4020		-	-	•	0 to 31	%00000
convert axis words W1024ff to markers			0				corresponding bit = $0 \Rightarrow$ function inactive	
convert new markers into old markers			1				corresponding bit = $1 \Rightarrow$ function active	
convert configuration bits from MP4210 into markers			2					
error markers are available			3					
non-volatile markers in the range M1000 to M1999			4					
Automatic lubrication	X Y Z IV V	4060.0 4060.1 4060.2 4060.3 4060.4		• • •	* * *	•	0 to 65 535 [65 536 μm]	100 200 300 400 0
Maximum change of the temperature compensation per PLC scan in the PLC words W576 - W584	е	4070		*	•	•	0.0001 to 0.005 [mm]	0.0001

1.0 TNC 415B/425/426 Machine Parameters MP 4010 - MP 4070 03.01.95 5.2 33

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
PLC: Time for	4110.0	•	•	•	0 to 65 535 [PLC cycles]	100
T 0 - T 29	4110 1	•	•	•		22
	44400	•	•	•		50
	44400	•	•	•		100
	4440.4	•	•	•		4
	4440 5	•	•	•		5
	4440.0	•	•	•		6
	4440 7	•	•	•		7
	44400	•	•	•		8
	4440.0	•	•	•		9
	4440.40	•	•	•		10
	4440.44	•	•	•		11
	4440.40	•	•	•		12
	4440.40	•	•	•		13
	444044	•	•	•		14
	4440.45	•	•	•		15
	4440.40	•	•	•		25
	4440.47	•	•	•		0
	4440.40	•	•	•		0
	444040	•	•	•		0
	4440.00	•	•	•		0
	4440.04	•	•	•		0
	4440.00	•	•	•		0
	4110.00					0
	4110.04	*	•	•		0
	4440.05	*	•	•		0
	4440.00	*	•	•		0
	4110.07	*	•	•		0
	4110.00	•	•	•		
		•	•	•		0
	4110.29	•	•	•		U

1.0 TNC 415B/425/426 Machine Parameters MP 4110.0 - MP 4110.29 03.01.95 5.2 34

Functi	on	MP No. Bit	A	В	С	Input	AE-6 Entry value
PLC:	Time for					0 to 65 535 [PLC cycles]	_
	T 30 - T 47	4110.30	•	•	•	, , , , , , , , , , , , , , , , , , , ,	0
		4110.31	•	•	•		0
		4110.32	•	•	•		0
		4110.33	•	•	•		0
		4110.34	•	•	•		0
		4110.35	•	•	•		0
		4110.36	•	•	•		0
		4110.37	•	•	•		0
		4110.38	•	•	•		0
		4110.39	•	•	•		0
		4110.40	•	•	•		0
		4110.41	•	•	•		0
		4110.42	•	•	•		0
		4110.43	•	•	•		0
		4110.44	•	•	•		0
		4110.45	•	•	•		0
		4110.46	•	•	•		0
		4110.47	•	•	•		0
			-			0 to 65 535 [PLC cycles]	-
PLC:	Pre-set values for	4120.0	•	•	•	0 to 00 000 [1 20 0y0100]	0
	counters 0 - 10	4120.1	•	•			1
		4120.2	•	•	•		2
		4120.3	•	•			3
		4120.4	•	•			4
		4120.5	•	•			5
		4120.6	•	•	•		6
		4120.7	•	•	•		7
		4120.8	•				8
		4120.9	•	•	•		9
		4120.10	•				10

R H

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
PLC: Pre-set values for						
counters 11 - 31	4120.11	•	•	•		11
	4120.12	•	•	•		12
	4120.13	•	•	•		13
	4120.14	•	•	•		14
	4120.15	•	•	•		15
	4120.16	•	•	•		16
	4120.17	•	•	•		17
	4120.18	•	•	•		18
	4120.19	•	•	•		19
	4120.20	•	•	•		20
	4120.21	•	•	•		21
	4120.22	•	•	•		22
	4120.23	•	•	•		23
	4120.24	•	•	•		24
	4120.25	•	•	•		25
	4120.26	•	•	•		26
	4120.27	•	•	•		27
	4120.28	•	•	•		28
	4120.29	•	•	•		29
	4110.30	•	•	•		30
	4110.31	•	•	•		31
ast PLC input						
Defining the fast input	4130	•	•	•	0 to 254	0
					0 = activation with LOW level	
Defining the active level of the fast input	4131	•	•	•	1 = activation with HIGH level	0

1.0 TNC 415B/425/426 Machine Parameters MP 4120.11- MP 4131 03.01.95 5.2 36

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Setting a number	D768	4210.0	•	•	•	-99 999.9999 to +99 999.9999 [mm] or [°]	+10
	D772	4210.1	•	•	•		+1
	D776	4210.2	•	•	•		+2
	D780	4210.3	•	•	•		+3
	D784	4210.4	•	•	•		+4
	D788	4210.5	•	•	•		+5
	D792	4210.6	•	•	•		+6
	D796	4210.7	•	•	•		+7
	D800	4210.8	•	•	•		+8
	D804	4210.9	•	•	•		+9
	D808	4210.10	•	•	•		+10
	D812	4210.11	•	•	•		+11
	D816	4210.12	•	•	•		+12
	D820	4210.13	•	•	•		+13
	D824	4210.14	•	•	•		+14
	D828	4210.15	•	•	•		+15
	D832	4210.16	•	•	•		+16
	D836	4210.17	•	•	•		+17
	D840	4210.18	•	•	•		+18
	D844	4210.19	•	•	•		+19
	D848	4210.20	•	•	•		+20
	D852	4210.21	•	•	•		+21
	D856	4210.22	•	•	•		+22
	D860	4210.23	•	•	•		+23
	D864	4210.24	•	•	•		+24
	D868	4210.25	•	•	•		+25
	D872	4210.26	•	•	•		+26
	D876	4210.27	•	•	•		+27
	D880	4210.28	•	•	•		+28
	D884	4210.29	•	•	•		+29
	D888	4210.30	·	•			+30
	D892	4210.31	·	•			+31

RH

Function			MP No. Bit	A	В	С	Input	AE-6 Entry value
Setting a number		D896	4210.32	•	•	•		+0
-		D900	4210.33	•	•	•		+0
		D904	4210.34	•	•	•		+0
		D908	4210.35	•	•	•		+0
		D912	4210.36	•	•	•		+0
		D916	4210.37	•	•	•		+0
		D920	4210.38	•	•	•		+0
		D924	4210.39	•	•	•		+0
		D928	4210.40	•	•	•		+0
		D932	4210.41	•	•	•		+0
		D936	4210.42	•	•	•		+0
		D940	4210.43	•	•	•		+0
		D944	4210.44	•	•	•		+0
		D948	4210.45	•	•	•		+0
		D952	4210.46	•	•	•		+0
		D956	4210.47	•	•	•		+0
Machine parameters with	W960	Х	4220.0	•	•	•	10 to 30 000	1800
multiple function	W962	Υ	4220.1	•	•	•	- setting a number in PLC	1800
	W964	Z	4220.2	•	•	•	or	1800
	W966	IV	4220.3	•	•	•	- feed rate for reapproaching the contour	1800
	W968	V	4220.4	•	•	•	[mm/min] or [°/min]	1800
Setting a number			4230.0	•	•	•	-99 999.9999 to +99 999.9999 [mm]	0
(readable with module9032)								-
								-
								-
			4230.31	•	•	•		0

R H 1.0 TNC 415B/425/426

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
PLC: setting a number	4231.0	•	*	•	-99 999.9999 to +99 999.9999	0
(readable with module 9032)						-
						-
						-
	4231.31	•	•	•		0
PLC: setting a number					-99 999.9999 to +99 999.9999	
W976 (M2192 to 2207)	4310.0	•	•	•		20480
W978 (M2208 to 2223)	4310.1	•	•	•		0
W980 (M2224 to 2239)	4310.2	•	•	•		0
W982 (M3200 to 3215)	4310.3	•	•	•		0
W984 (M3216 to 3231)	4310.4	•	•	•		0
W986 (M3232 to 3247)	4310.5	•	•	•		0
W990 (M3248 to 3263)	4310.6	•	•	•		0
Adaptation of the PLC extension	4410	•	•	◆ 1)		0
interface (X47)	0				+0 = no analogue inputs activated on 1. extension	
	1				+1 = analogue inputs on 1. extension (PA 100 or analogue inputs activated on PL 410)	
	·				+0 = no analogue inputs activated on	
					2. extension	
					+2 = analogue inputs on 2. extension (PA 100	
					or analogue inputs activated on PL 410)	

¹⁾ reserved, entry value 0

1.0 TNC 415B/425/426 Machine Parameters MP 4231.0 - MP 4410 03.01.95 5.2 39

Adaptation of the Data Interface

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Inhibiting a data interface					0 = no interface inhibited	-
_	5000	•	•	•	1 = RS-232 inhibited	0
					2 = RS-422 inhibited	
Data format and transfer stop						
operating mode EXT1	5020.0*	•	•	•	0 to 255	168
operating mode EXT2	5020.1*	•	•	•		168
operating mode EXT3 (PLC)	5020.2*	•	•	•		168
7 or 8 data bits	0				+0 = 7 data bits, bit 8 = parity	
					+1 = 8 data bits, bit $8 = 0$, bit $9 = parity$	
Block check character	1				+0 = BCC character optional	
					+2 = control character not BCC	
Transmission stop through RTS	2				+0 = inactive	
					+4 = active	
Transmission stop through DC3	3				+0 = inactive	
1					+8 = active	
Character parity even/odd	4				+0 = even	
, ,					+16 = odd	
Character parity on/off	5				+0 = off	
, ,					+32 = on	
Number of stop bits	6				$+64 \rightarrow bit 6 = 1$	
	7				+128 → bit 7 = 1	
					bit 6 bit 7	
					$0 1 = 1\frac{1}{2} stop bits$	
					1 0 = 2 stop bits	
					0 1 = 1 stop bit	
					1 1 = 1 stop bit	

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 5000 - MP 5020.2 03.01.95 5.2 4

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Operating mode for							
EXT1		5030.0*	•	•	•		1
EXT2		5030.1*	•	•	•	0 = "standard data transfer"	1
EXT3 (PLC)		5030.2*	•	•	•	1 = "blockwise transfer"	1
Data transfer rate for PLC coupling (EXT3)		5040	•	•	•	0 to 9 0 = 110 Bd	7
Control characters for "Blockwise Transfer"							
ASCII character for beginning of						0 to 127	
program	(STX)	5200.0*	•	•	102		0
EXT1	,	5200.1*	•	•	102		0
EXT2		5200.2*	•	•	102		0
EXT3 (PLC)							
ASCII character for end of program						0 to 127	
EXT1	(ETX)	5201.0*	•	•	102		0
EXT2		5201.1*	•	•	102		0
EXT3 (PLC)		5201.2*	•	•	102		0
ASCII character for file type (for							
data transfer)						0 to 127	
EXT1		5202.0*	•	•	102		0
EXT2		5202.1*	•	•	102		0
EXT3 (PLC)		5202.2*	•	•	102		0

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 5030.0 - MP 5202.2 06.03.95 5.2 4

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
ASCII character for input						0 to 127	
identification	(E)	5203.0*	•	•	102		0
EXT1		5203.1*	•	•	102		0
EXT2		5203.2*	•	•	102		0
EXT3 (PLC)							
ASCII character for file type							
(for data output)						0 to 127	
EXT1		5204.0*	•	•	102		0
EXT2		5204.1*	•	•	102		0
EXT3 (PLC)		5204.2*	•	•	102		0
ASCII character for output						0 to 127	
identification		5205.0*	•	•	102		0
EXT1	(A)	5205.1*	•	•	102		0
EXT2		5205.2*	•	•	102		0
EXT3 (PLC)							
ASCII character for beginning of							
command block						0 to 127	
EXT1	(SOH)	5206.0*	•	•	102		0
EXT2		5206.1*	•	•	102		0
EXT3 (PLC)		5206.2*	•	•	102		0
ASCII character for end of							
command block						0 to 127	
EXT1	(ETB)	5207.0*	•	•	102		0
EXT2		5207.1*	•	•	102		0
EXT3 (PLC)		5207.2*	•	•	102		0

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 5203.0 - MP 5207.2 03.01.95 5.2 42

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
ASCII character for positive								
acknowledgement							0 to 127	
EXT1	(ACK)	5208.0*		•	•	102		0
EXT2		5208.1*		•	•	102		0
EXT3 (PLC)		5208.2*		•	•	102		0
ASCII character for negative								
acknowledgement							0 to 127	
EXT1	(NAK)	5209.0*		•	*	102		0
EXT2		5209.1*		•	*	102		0
EXT3 (PLC)		5209.2*		•	•	102		0
ASCII character for end of transfer								
EXT1	(EOT)						0 to 127	
EXT2		5210.0*		•	•	102		0
EXT3 (PLC)		5210.1*		•	•	102		0
		5210.2*		•	•	102		0

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 5208.0 - MP 5210.2 03.01.95 5.2 43

3D-Touch Probe (General Parameters)

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Selection of touch trigger probe	6010*	•	•		0 = transmission via cable (TS 120) 1 = infrared transmission (TS 510)	0
Probing feed rate	6120*	•	•		10 to 3 000 [mm/min]	80
Maximum measuring range	6130*	•	•		0.001 to 99 999.9999 [mm]	1
Safety clearance over measure- ment point for automatic measurement	6140*	•	•		0.001 to 99 999.9999 [mm]	1
Rapid traverse for probe cycle	6150*	•	•		10 to 10 000 [mm/min]	2000
M-function for 180° spindle	6160*	•	•		0 = function inactive 1 to 88 = number of M-function for probing	0
		ı	04		1 = oriented spindle stop via NC 0 = function inactive +1 to 88 = number of M function for oriented spindle stop via PLC	0

Connection of Measuring Touch Probe or Touch Trigger Probe

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Selecting the touch probe (probing and digitizing cycles)	6200 *	10	•		0 = touch trigger probe 1 = measuring touch probe	0

^{*} accessible via code number 123

1.0 TNC 415B/425 Machine Parameters MP 6010 - MP 6200 08.05.95 5.2 4

Digitizing with 3D-Touch Probe

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Number of oscillations in normal direction	6210	•	•	•	0 to 65.535 [1/sec]	0
 Lubrication of touch probe axis displacement for lubrication at the end of a line 	6220	-	•	•	0.000 to 999.999 [mm]	0
• time intervals for lubrication	6221	-	•	•	0 to 65 535 [min]	0
Feed rate in normal direction	6230	•	•	•	0 to 1 000 [mm/min]	0
Maximum deflection of the stylus	6240	•	•	•	0 to 10 [mm]	0
Output of M90 on NC blocks of digitized data	6260	•	•	•	0 = no output 1 = output	0
Rounding of decimal places (NC blocks)	6270	•	•	•	0 = output in 0.001 mm (1 μm) 1 = output in 0.01 mm (10 μm) 2 = output in 0.0001 mm (0.1 μm)	0

1.0 TNC 415 B/425/426 Machine Parameters MP 6210 - MP 6270 03.01.95 5.2 45

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Deflection depth of stylus	6300 ¹⁾		10	-	-	0.1 to 2.0000 [mm]	1
Deflection depth of stylus	6310		-	•	•	0.1 to 2.0000 [mm]	1
Counting direction of the encoders in the touch probe	,	0 1 2	10	10	•	0 = positive +1 = X axis negative +2 = Y axis negative +4 = Z axis negative	0
Calculating the center offset when calibrating the TM 110	6321		-	•	•	0 = calibrate and measure center offset 1 = calibrate without measuring center offset	0
Allocation of the touch probe axes to the machine axes machine axis machine axis machine axis 7	6322.1		- - -	* *	• •	0 = touch probe axis X 1 = touch probe axis Y 2 = touch probe axis Z	0 1 2
Maximum deflection of the stylus	6330		10	10	•	0.1 to 4 [mm]	3
Minimum deflection of the stylus	6340		l12	l12	-	0.001 to 0.5 [mm]	0.005
Feed rate for positioning to the MIN point and contour approach	6350		10	•	•	10 to 3 000 [mm/min]	300
Feed rate for probing in measuring cycles	6360		10	•	•	10 to 3 000 [mm/min]	1000
Rapid traverse for probing	6361		10	•	•	10 to 10 000 [mm/min]	2000
Feed rate reduction if the stylus (TM 110) is deflected away from its path	6362		-	•	•	0 = feed reduction inactive 1 = feed reduction active	0

¹⁾ with special software and for TNC 426 this function has been shifted to MP 6310!

1.0 TNC 415B/425/426 Machine Parameters MP 6300 - MP 6362 06.03.95 5.2 4

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Kv factor for column control	6370	10	-	-	0.1 to 10	1
Factor for friction compensation	6380	10	-	-	0 to 0.999	0.1
Target window for contour lines	6390	10	•	•	0.1 to 4.0	1

1.0 TNC 415B/425/426 Machine Parameters MP 6370 - MP 6390 03.01.95 5.2 47

Tool Calibration with TT 110

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Tool calibration cycles	6500	-	•	•	0 = cycles inhibited 1 = cycles not inhibited	0
Probing direction for tool calibration	6505	-	•	•	 0 = pos. probing direction in the angle reference axis (0° axis) 1 = pos. probing direction in the +90° axis 2 = neg. probing direction in the angle reference axis (0° axis) 3 = neg. probing direction in the +90° axis 	0
Calculating the probing feed rate	6507	-	•	٠	 0 = calculation of probing feed rate with constant tolerance 1 = calculation of probing feed rate with variable tolerance 2 = constant probing feed 	0
Maximum permissible measuring error for measurement with a rotating tool	6510	-	•	•	0.002 to 0.999 [mm]	0.005
Probing feed rate for measurement with a non-rotating tool	6520	-	•	•	10 to 3 000 [mm/min]	10
Distance between lower edge of tool and upper edge of stylus for tool radius measurement	6530	-	•	•	0.001 to 99.9999 [mm]	10
Diameter or edge length of the TT 110 stylus	6531	-	•	•	0.001 to 99 999.9999 [mm]	10

1.0 TNC 415B/425/426 Machine Parameters MP 6500 - MP 6531 03.01.95 5.2 48

Function	MP No. B	it A	В	С	Input	AE-6 Entry value
Safety zone around the stylus of TT 110 for pre-positioning	6540	-	•		0.001 to 99 999.9999 [mm]	10
Rapid traverse in the probing cycle	6550	-	•		10 to 10 000 [m/min]	10
M function for oriented spindle stop for measuring individual cutting edges	6560	-	•		-1 = oriented spindle stop via NC 0 = function inactive 1 to 88 = number of M function for oriented spindle stop via PLC	10
Maximum permissible surface cutting speed at the cutting edges of the tool	6570	-	•		1.0000 to 120.0000 [m/min]	100
Center coordinates of the TT 110 stylus					- 99 999.9999 to + 99 999.9999 [mm]	
referenced to the machine datum						
X	6580.0	-	•			0
Y	6580.1	-	•			0
Δ	6580.2	-	•			0

1.0 TNC 415B/425 Machine Parameters MP 6540 - MP 6580.2 08.05.95 5.2 49

Tapping

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Minimum feed override when tapping	7110.0	•	•	•	0 to 150 [%]	95
Maximum feed override when tapping	7110.1	•	•	•	0 to 150 [%]	105
Dwell time for change of direction of spindle rotation in a tapping cycle	7120.0	•	•	•	0 to 65.535 [s]	0
Spindle run-on time in a tapping cycle (only effective with BCD output of the spindle speed)	7120.1	•	•	•	0 to 65.535 [s]	0
Spindle slow-down time after reaching the boring depth	7120.2	•	•	•	0 to 65.535 [s]	0
Tapping without floating tap holder						
• run-in behaviour of the spindle	7130	•	•	•	0.001 to 10 [°/min]	0.5
 transient response of the spindle during acceleration 	7140	•	•	-	0.01 to 0.999	0.15
Positioning window for tool axis	7150	•	•	•	0.0001 to 2 [mm]	0.05
Oriented spindle stop at the beginning of cycle 17 "Rigid Tapping"	7160	•	•	•	0 = spindle orientation is executed 1 = spindle orientation is not executed	1

1.0 TNC 415B/425/426 Machine Parameters MP 7110.0 - MP 7160 03.01.95 5.2 50

Display and Programming

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Programming station		7210*		*	•	•	0 = control	0
							1 = programming station: PLC active	
							2 = programming station: PLC inactive	
POWER INTERRUPTED		7212		•	•	•	0 = press [CE] to confirm the message	1
							1 = message is confirmed automatically	
Block number increment size		7220*		*	•	*	0 to 250	0
(for ISO programming)							0 = no generation	
Maximum length of file names		7222*		*	•	102	0 = max. 8 characters	
when opening a file							1 = max. 12 characters	
							2 = max. 16 characters	
Disabling file types		7224.0*		*	•	•	0 = no file type disabled	% 00000000
(for selection, table of contents and ext								
data transfer)								
HEIDENHAIN programs	(.H)		0	•	•	•	+ 1 = disabled	
ISO programs	(.)		1	•	•	•	+ 2 = disabled	
Tool tables	(.T)		2	•	•	•	+ 4 = disabled	
Datum tables	(.D)		3	•	•	•	+ 8 = disabled	
Pallet tables	(.P)		4	•	•	•	+16 = disabled	
ASCII (text) files	(.A)		5	•	•	•	+32 = disabled	
PLC help files	(.HLP)		6	80	•	•	+64 = disabled	
Measuring point tables	(.PNT)		7	80	•	•	+128 = disabled	

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 7210 - MP 7224.0 03.01.95 5.2 5

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Protecting file type	es	7224.1*	•	•	•	0 = no file type protected	% 00000000
HEIDENHAIN program	ns (.H)	0	•	•	•	+ 1 = protected	
ISO programs	(_1)	1	•	•	•	+ 2 = protected	
Tool tables	(.T)	2	•	•	•	+ 4 = protected	
Datum tables	(.D)	3	•	•	•	+8 = protected	
Pallet tables	(.P)	4	•	•	•	+16 = protected	
ASCII (text) files	(.A)	5	•	•	•	+32 = protected	
PLC help files	(.HLP)	6	08	•	•	+64 = protected	
Measuring point tables	s (.PNT)	7	08	•	•	+128 = protected	
Preset size							
Pallet table	(.P)	7226.0*	•	•	•	0 to 255 = number of reserved entries	10
Datum table	(.D)	7226.1*	•	•	•	(can be expanded via soft key)	10
Size of NC memory	y for						
DNC mode	Minimum	7228.0	08	•	•	1 to 1024 [kBytes]	1
	Maximum	7228.1	08	•	•	1 to 1024 [kBytes]	100
Length of program	1						
- to check the pro	gram	7229.0	-	-	•	100 to 9999	100
	blocks are permitted	7229.1	-	-	•		
Changing the dialo	og language	7230*	•	•	-	0 = 1. language 1 = 2. language	0
Changing the dialo	og language					0 = English $6 = Portuguese$	
NC dialog		7230.0	_	_	•	1 = German 7 = Swedish	1
PLC dialog (0	DEM cycles.	7330.1	_	_	•	2 = Czech 8 = Danish	1
USER param						3 = French 9 = Finnish	
PLC error me		7230.2	_	_	•	4 = Italian $10 = Dutch$	1
	3					5 = Spanish	
Deviation from Gre	eenwich time	7235	_	-	•	-23 to +23 [hours]	
						0 = Greenwich time	
						1 = CET	
						2 = Central European summer time	
						The factory setting of the internal clock of the control is Greenwich time. To	
						adapt the time of the program manager to the local time, the difference	
						between local time and Greenwich time must be entered in MP 7235.	

^{*} accessible via code number 123

RH1.0 TNC 415B/425/426

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Inhibiting program entry if	7240*	•	•	•	0 = inhibited	1
PGM No. = No. of OEM cycle					1 = not inhibited	
Inhibiting HEIDENHAIN cycles	7245.0	•	•	•	0 to 65 535	\$ 0000
cycle 1	1				Bit = $0 \Rightarrow$ cycle not inhibited	
cycle 2	2				Bit = 1 ⇒ cycle inhibited	
cycle 3	3					
cycle 4	4					
cycle 5	5					
cycle 6	6					
cycle 7	7					
cycle 8	8					
cycle 9	9					
cycle 10	10					
cycle 11	11					
cycle 12	12					
cycle 13	13					
cycle 14	14					
cycle 15	15					
	7245.1	•	•	•	0 to 65 535	\$ 0000
cycle 16	0				Bit = 0 ⇒ cycle not inhibited	
cycle 17	1				Bit = 1 ⇒ cycle inhibited	
cycle 18	2					
cycle 19	3					
cycle 20	4					
cycle 21	5					
cycle 22	6					
cycle 23	7					
cycle 24	8					
cycle 25	9					
cycle 26	10					
cycle 27	11					
cycle 28	12					
cycle 29	13					
cycle 30	14					
cycle 31	15					

1.0 TNC 415B/425/426 Machine Parameters MP 7240 - MP 7245.1 03.01.95 5.2 53

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Disable paraxial positioning blocks with R+/R- compensation	7246	*	•	•	0 = enabled 1 = disabled	0
Difference between Q-parameter numbers for DLG-DEF block and DLG-CALL block in OEM cycle	7250	•	•	•	0 to 50 0 if only "DLG-CALL" blocks	0
Number of global Q-parameters transferred form OEM cycle to calling program	7251	*	•	•	0 to 100 40 = the Q-parameters Q60 to Q90 are global	0
Central tool file	7260*	•	•	•	0 to 254: central tool file entry value = number of tools 0 = no central tool file	254
Number of tools with pocket number	7261*	•	•	•	0 to 254	254

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP7246 - MP 7261 03.01.95 5.2 54

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
Items in th	e tool table (.T file) that can					0 = not displayed	-
be display	ed and output via interface:					1 - 99 = position of the element in the tool table	
NAME	(tool name)						
L	(tool length)	7266.0	•	•		smallest value = first position	1
R	(tool radius 1)	7266.1	•	•		highest value = last position	2
R2	(tool radius 2)	7266.2	•	•			3
DL	(oversize tool length)	7266.3	•	•			4
DR	(oversize tool radius 1)	7266.4	•	•			5
DR2	(oversize tool radius 2)	7266.5	•	•			6
TL	(tool locked)	7266.6	•	•			7
RT	(replacement tool)	7266.7	•	•			8
TIME1	(max. tool life)	7266.8	•	•			9
TIME2	(max. tool life with TOOL CALL)	7266.9	•	•			10
CUR.TIME	· ·	7266.10	•	•			11
DOC	(commentary on tool)	7266.11	•	•			12
CUT	(number of cutting edges)	7266.12	•	•			13
LTOL	(tolerance for tool length)	7266.13	_	•			14
RTOL	(tolerance for tool radius)	7266.14	_	•			15
DIRECT	(cutting direction of the tool)	7266.15	_	•			16
PLC	(PLC status)	7266.16	_	•			17
	(tool offset, length)	7266.17	_	02			18
	(tool offset, radius)	7266.18	_	04			19
LBREAK	(breakage tolerance, tool length)	7266.19	_	04			20
RBREAK	(breakage tolerance, tool radius)	7266.20	_	04			21
	(1 11 191 11111111111111111111111111111	7266.21	_	04			22
Items in th	e pocket table (TOOL.P file)	, 200.21		<u> </u>		0 = not displayed	
T	(tool number)	7267.0	•	•	•	1 - 99 = position of the element in the tool table	1
ST	(replacement tool)	7267.1				- 33 - position of the distribution for the tool table	2
F	(fixed pocket)	7267.1				smallest value = first position	3
I	(locked pocket)	7267.3				highest value = last position	4
PLC	(PLC status)	7267.4				Trigitode value – lade position	5

^{*} accessible via code number 123

1.0 TNC 415B/425 Machine Parameters MP 7266.0 - MP 7267.4 08.05.95 5.2 55

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Display of the feed rates in the MANUAL operating modes	7270 *		*	•	٠	0 = display of the axis feed rate only when an axis- direction key is pressed (axis-specific feed rate from MP1020.X) 1 = display of the axis feed rate before operating an axis-direction key (smallest value from MP1020.X for all axes)	0
Decimal sign	7280*		•	*	•	0 = decimal comma 1 = decimal point	0
Tool length in nominal / actual value display	7285*		•	•	•	0 = tool length ignored 1 = tool length taken into account	0
Display step	X 7290.0 Y * Z 7290.1 IV 7290.2 Y 7290.3 * 7290.4		•	*	•	0 = 0.1 mm or 0.1° 1 = 0.05 mm or 0.05° 2 = 0.01 mm or 0.01° 3 = 0.005 mm or 0.005° 4 = 0.001 mm or 0.001° 5 = 0.0005 mm or 0.0005° 6 = 0.0001 mm or 0.0001°	6 6 6 6
Inhibiting datum setting (axis keys and soft key)	7295* X Y Z IV V	0 1 2 3 4	*	*	٠	0 = not disabled + 1 = X axis disabled + 2 = Y axis disabled + 4 = Z axis disabled + 8 = IV axis disabled +16 = V axis disabled	0
Datum setting with axis keys	7296		08	•	•	0 = datum can be set with axis keys and soft key 1 = datum can be set with soft key only	0

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 7270 - MP 7296 06.03.95 5.2 56

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Cancelling	7300		•	•	•	0 to 7	0
- status data (S) - TOOL data (T)		0					
- Q-parameters (Q)		2				program end program selection	
						0 = S Q T	
with M02, M30, END PGM						1 =	
						2 = S Q T - Q -	
						3 =	
						4 =	
						6 = S Q T - Q T	
						7 =	
						- = data are erased	
Graphics display	7310*		•	•	•		
3-plane display		0				+ 0 = German standard	0
						+ 1 = American standard	
 rotation of the coordinate system in the 		1				+ 0 = no rotation	
machining plane						+ 2 = coordinate system is rotated by + 90°	
 BLK form after datum shift 		2				+ 0 = BLK form will not shift	
		_				+ 4 = BLK form will shift	
 display of cursor position in 3-plane 		3				+ 0 = not shown	
display						+ 8 = cursor position shown	

^{*} accessible via code number 123

1.0 TNC 415B/425/426 Machine Parameters MP 7300 - MP 7310 03.01.95 5.2 57

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Graphic simulation of a program without TOOL CALL or without infeed movement in the tool axis in "Program Run" and "Test Run"							
Tool radius	7315*		•	•	•	0 to 99 999 [mm]	0
Penetration depth (from top surface of the blank)	7316*		•	•	•	0 to 99 999 [mm]	0
M function to start the simulation	7317.0*		•	•	*	0 to 88	0
M function ton interrupt the simulation	7317.1*		•	•	•	0 to 88	0

1.0 TNC 415B/425/426 Machine Parameters MP 7315 - MP 7317.1 03.01.95 5.2 58

User Parameters

Function		MP No. Bit	A	В	С	Input	AE-6 Entry value
USER Parameters							-
Determination of the USER parameters	0	7330.0	•	•	•	0 to 9999.99	0
	1	7330.1	•	•	•	number of desired machine parameter	0
	2	7330.2	•	•	•	NOTE: the index must have 2 decimal places, i.e. 110.10 instead of 110.1	0
	3 4	7330.3 7330.4	•	•	•	i.e. 110.10 instead of 110.1	0
	4 5	7330.4	•	•	•		0
	6	7330.6	•	•	*		0
	7	7330.7	•	•	•		0
	8	7330.8	•	•	•		Ö
	9	7330.9	•	•	•		Ö
	10	7330.10	•	•	•		0
	11	7330.11	•	•	•		0
	12	7330.12	•	•	•		0
	13	7330.13	•	•	•		0
	14	7330.14	•	•	•		0
	15	7330.15	•	•	•		0
Allocation of the dialogs to the defined	0	7340.0	•	•	•	0 to 4095	0
JSER parameters	1	7340.1	•	•	•	0 = first line of the corresponding file	0
	2	7340.2	•	•	•		0
	3	7340.3	•	•	•		0
	4	7340.4	•	•	•		0
	5	7340.5	•	•	•		0
	6	7340.6	•	•	•		0
	7	7340.7	•	•	•		0
	8	7340.8	•	•	•		0
	9	7340.9	•	•	•		0

1.0 TNC 415B/425/426 Machine Parameters MP 7330.0 - MP 7340.9 03.01.95 5.2 59

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
						_
10	7340.10	•	•	•		0
11	7340.11	•	•	•		0
12	7340.12	•	•	•		0
13	7340.13	•	•	•		0
14	7340.14	•	•	•		0
15		•	•	•		0

Colours, General Display and FK Graphics

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Window frame	7350	•	•	•	\$000 000 to \$3F3F3F	\$030200C
Error messages	7351	•	•	•		\$03F3F0F
Operating mode display "Machine" Background Text for operating mode Dialogue	7352.0 7352.1 7352.2	* *	• •	•		\$0000000 \$0342008 \$03F3828
Operating mode display "Programming" Background Text for operating mode Dialogue	7353.0 7353.1 7353.2	• •	* *	•		\$0000000 \$0342008 \$03F3828

1.0 TNC 415B/425/426 Machine Parameters MP 7340.10 - MP 7353.2 03.01.95 5.2 6

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Program text display "Machine"					\$000000 to \$3F3F3F	-
Background	7354.0	•	•			\$0080400
General program text	7354.1	•	•			\$038240C
Current block	7354.2	•	•			\$038341C
Background of active window	7354.3	•	•			\$00C0800
Background of inactive window	7354.3	-	04			\$0040800
Program text display					\$000000 to \$3F3F3F	
"Programming"						
Background	7355.0	•	•			\$0080400
General program text	7355.1	•	•			\$038240C
Current block	7355.2	•	•			\$038341C
Background of active window	7355.3	•	•			\$00C0800
Status-and PLC window					\$000000 to \$3F3F3F	
Background	7356.0	•	•			\$00C0800
Axis pos. in the status display	7356.1	•	•			\$03F2C18
Status display, except axis positions	7356.2	•	•			\$03F280C
Soft key display "Machine"					\$000000 to \$3F3F3F	
Background	7357.0	•	•			\$000000
Symbols	7357.1	•	•			\$03F3828
Soft key display "Programming"					\$000000 to \$3F3F3F	
Background	7358.0	•	•			\$000000
Symbols	7358.1	•	•			\$03F3828
Graphics: 3D-view					\$000000 to \$3F3F3F	
Background	7360.0	•	•			\$000000
Surface	7360.1	•	•			\$0203038
Front face	7360.2	•	•			\$00C1820
Text display in graphics window	7360.3	•	•			\$03F3F3F
Side face	7360.4	•	·			\$0102028

1.0 TNC 415B/425 Machine Parameters MP7354 - MP 7360.4 08.05.95 5.2 61

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Graphics: View in 3 planes					\$000000 to \$3F3F3F	
(and oscilloscope)						
Background	7361.0	•	•	•		\$000000
Plan (grating)	7361.1	•	•	•		\$0203038
Front and side view (not selected channel)	7361.2	•	•	•		\$0203038
Axis cross and text in graphics display						
(cursor, data, screen window)	7361.3	•	•	•		\$03F3F3F
Cursor (selected channel)						
	7361.4	•	•	•		\$03F0000
Additional status display in					\$000000 to \$3F3F3F	
graphics window						
Background graphics window	7362.0	•	•	•		\$0080400
Background status display	7362.1	•	•	•		\$00C0800
Status symbols	7362.2	•	•	•		\$038240C
Status values	7362.3	•	•	•		\$03F2C18
FK graphics					\$000000 to \$3F3F3F	
Background	7363.0	•	•	•		\$000000
Resolved contour	7363.1	•	•	•		\$03F3F3F
Subprograms and frame for zoom	7363.2	•	•	•		\$0003F00
Alternative solutions	7363.3	•	•	•		\$0003F00
Non-resolved contour	7363.4	•	•	•		\$03F0000

1.0 TNC 415B/425 Machine Parameters MP 7361 - MP 7363.4 03.01.95 5.2 62

Machining and Program Run

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
"Scaling factor" cycle in two or three axes	7410*		•	•	•	0 = 3 axes 1 = only in the machining plane	0
Tool data in TOUCH PROBE cycle	7411*		*	•	•	0 = the current tool data are overwritten with the calibrated data of the touch probe 1 = the calibrated tool data are retained	0
Cycles for milling pockets with free-programmed contour	7420*					0 to 31	%00000
• Slot milling direction		0	•	•		 0 = anti-clockwise slot milling of the pocket contours, clockwise for islands 1 = clockwise slot milling of the pocket contours, anti-clockwise for islands 	
• Sequence for clearing out and slot milling		1	•	•		0 = first slot milling, then clear out pocket 2 = first clear out pocket, then slot milling	
Merge programmed contours		2	*	•		0 = contours merged only if the tool center paths intersect 4 = contours merged if the programmed contours overlap	
•Clear out and slot milling to pocket depth for each peck		3	•	•		0 = clearing out and slot milling performed in one operation for all pecks 8 = for each peck, first perform slot milling and then feed clearing out (depending on bit 1) before next peck	
• Position after finishing a contour pocket (cycles 6, 15, 16, 21, 22, 23, 24)		4	-	05		 0 = the control moves to the position at which it was before the cycle call 16 = only the tool axis is lifted to clearance height after the cycle 	

^{*} accessible via code number 123

1.0 TNC 415B/425 Machine Parameters MP 7420 03.06.96 5.2 63

Function		MP No.	Bit	A	В	С	Input	AE-6 Entry value
Overlap-factor for pocket milling	1	7430*		•	•	*	0.1 to 1414	1
Arc-end point tolerance Linear contour		7431*		•	•	•	0.0001 to 0.016 [mm]	0,01
Output of M functions		7440*		•	•	•		
Programmed halt on M06			0				+ 0 = programmed halt on M06 + 1 = no programmed halt on M06	%00010
Output of M89, modal cycle call			1				+ 0 = no cycle call, normal code transfer of M89 at beginning of block + 2 = modal cycle call at end of block	
Axis standstill when an M function is output Exceptions: axis standstill always occur after M functions that result in a programmed halt (such as M00, M02 in case of STOP or CYCL-CALL block	S		2				+ 0 = program halt until acknowledgement of M function + 4 = no program halt; TNC does not wait for acknowledgement	
Select Kv factors (M105/106)			3				+ 0 = function not active + 8 = function active	
Reduced feed rate in the tool axis with M103	s		4				+ 0 = function active + 16 = function active	
Calculate tool change position		7450		80	•	•	0 = do not calculate	
from MP951.X in block scan	Χ		0				+1 = X axis	%00000
	Υ		1				+2 = Y axis	
	Z		2				+4 = Z axis	
	IV		3				+8 = IV. axis	
	V		4				+16 = V. axis	
Feed rate for reapproaching the							10 to 300 000 [mm/min]	
contour after a program interruption		7451.0		-	-	06		0
		7451.1		-	-	06		0
		7451.2		-	-	06		0
		7451.3		-	-	06		0
	V	7451.4		-	-	06		0

^{*} accessible via code number 123

1.0 TNC 415B/425 Machine Parameters MP 7430 - MP 7451.4 06.03.95 5.2 64

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Constant feed rate in corners	74 60 *	•	•	•	0 to 179.9999 [°]	10
Display mode and software limit switches for rotary axis	74 70 *	108	-	-	0 = 0 to ± 359.999° (software limit switches are not monitored) 1 = 0 to ± 99 999.9999 [°]	0
Datum in datum table	7475	•	•	•	0 = datum point is workpiece datum 1 = datum point is machine datum	0
Output of tool number or pocket number					0 to 6	
with TOOL CALL block	7480.0	•	•	•	 0 = no output 1 = output of tool number only when tool number changes (W262) 2 = output of tool number with every TOOL CALL (W262) 3 = output of pocket number (W262) and tool number (W264) only when tool number changes 4 = output of pocket number (W262) and tool number (W264) with every TOOL CALL 5 = output of pocket number (W262) and tool number (W264) only when tool number changes; pocket table does not change. 6 = output of pocket number (W264) with every TOOL CALL; pocket table does not change. 	2

1.0 TNC 415B/425 Machine Parameters MP 7460 - MP 7480.0 06.03.95 5.2 65

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
with TOOL-DEF blocks (only if MP7260 > 0)	7480.1	*	•	*	0 = no output 1 = output of tool number only when tool number changes (W262) 2 = output of tool number with every TOOL DEF (W262) 3 = output of pocket number (W262) and tool number (W264) only when tool number changes 4 = output of pocket number (W262) and tool number (W264) with every TOOL DEF	2
Number of traverse ranges	7490	•	•	•	0 = 1 range, 3 datums 1 = 3 ranges, 3 datums 2 = 1 range, 1 datum 3 = 3 ranges, 1 datum	0

^{*} accessible via code number 123

1.0 TNC 415B/425 Machine Parameters MP 7480.1 - MP 7490 03.01.95 5.2 66

Tilting the Working Plane

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Tilting the working plane	7500		80	٠		0 = function inactive	0
						1 = function active	
Swivel head geometry							
1. Parameter block							
selecting the transformed axis	7510		80	•		0 to 63	0
		0				+1 = X axis	
		1				+2 = Y axis	
		2				+4 = Z axis	
		3				+8 = A axis	
		4				+16 = B axis	
	7544	5	00			+32 = C axis	
supplementary identifier for transformation	7511	0	80	*		. O silsing bood	
		0				+0 = tilting head	
						+1 = tilting table	
		1				+0 = incremental dimensions (for tilting head)	
		'				+2 = absolute values referenced to the machine	
						datum (for tilting table)	
dimensions for transformation	7512		08	•		-99 999.9999 to +99 999.9999	
						0 = free tilting axis	
2. Parameter block	7520		80	•		0 to 63	0
	7521		80	•		0 to 3	0
	7522		80	•		-99 999.9999 to +99 999.9999	0

1.0 TNC 415B/425 Machine Parameters MP 7500- MP 7522 08.05.95 5.2 67

Function	MP	A	В	С	Input	_ AE-6
	No. Bit	+				Entry value
2. Dawawaatay blaak	7530	80	•		0 to 63	0
3. Parameter block	7531	08	•		0 to 3	0
	7532	80	•		-99 999.9999 to +99 999.9999	0
	7540	80	•		0 to 63	0
4. Parameter block	7541	80	•		0 to 3	0
	7542	80	•		-99 999.9999 to +99 999.9999	0
	7550	80	•		0 to 63	0
5. Parameter block	7551	08	•		0 to 3	0
	7552	80	•		-99 999.9999 to +99 999.9999	0
	7560	08	•		0 to 63	0
6. Parameter block	7561	08	•		0 to 3	0
	7562	80	•		-99 999.9999 to +99 999.9999	0
	7570	08	•		0 to 63	0
7. Parameter block	7571	80	•		0 to 3	0
	7572	80	•		-99 999.9999 to +99 999.9999	0
	7580	08	•		0 to 63	0
3. Parameter block	7581	08	•		0 to 3	0
	7582	08	•		-99 999.9999 to +99 999.9999	0
	7590	08	•		0 to 63	0
9. Parameter block	7591	08	•		0 to 3	0
	7592	08			-99 999.9999 to +99 999.9999	0

1.0 TNC 415B/425 Machine Parameters MP 7530 - MP 7592 08.05.95 5.2 68

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Feed rate and spindle override	7620		*	*			
Feed rate override, if rapid traverse button pressed in "program run"		0				+ 0 = feed rate override inactive + 1 = feed rate override active	% 1101
reserved		1					
 Feed rate override, if rapid traverse button pressed in "manual" or rapid traverse button and handwheel direction key pressed in "handwheel" 		2				+ 0 = feed rate override inactive + 4 = feed rate override active	
Override characteristic curve		3				+ 0 = feed rate and spindle override in 1% increm. + 8 = feed rate and spindle override in 0.01% increm., and non-linear characteristic curve	

Hardware

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Handwheel configuration	7640*	•	•	•	0 = no handwheel connected 1 = HR 330 (all keys evaluated by NC) 1) 2 = HR 130, HR 330 (all keys evaluated by NC) 2) 3 = HR 330 "RAPID" key by PLC I 162 "PLUS" key by PLC I 160 "MINUS" key by PLC I 161 4 = HR 332, evaluation of keys and LEDs depends on MP 7645.0 5 = HRA 110, multi-axis handwheel (3 x HR 150) 6 = HR 410, evaluation of keys and LEDs depends on MP 7645.0 ³⁾	0
Entry of interpolation factor	7641	•	•	•	0 = entry via keyboard 1 = entry via PLC module 9036	0

^{*} accessible via code number 123

1.0 TNC 415B/425 **Machine Parameters** MP 7640 - MP 7641 08.05.95 70

¹⁾ axis can only be switched by handwheel ²⁾ axis can be switched by handwheel and keyboard

³⁾ If the handwheel HR 410 does not receive any initializing parameters (MP 7645.X), it automatically switches to HR 332 mode (MP 7640 = 4).

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Initializing parameters for handwheel Assignment of 3. handwheel via axis selector switch (MP 7640 = 5)	7645.0	0	•	٠		 + 0 = position 1 (left stop) → Z axis position 2 → IV. axis position 3 → V. axis + 1 = position 1 → X axis position 2 → Y axis position 3 → V. axis position 4 → IV. axis position 5 → V. axis 	0
Evaluation of the keys and LEDs on HR 332 (MP 7640 = 4) HR 410 in HR 332 mode (MP 7640 = 4)	7645.0	2-7	•	•		+ 2 = position 3 → Z axis position 4 → IV. axis position 5 → V. axis reserved HR 332 0 = keys X, Y, Z, IV and their LEDs evaluated by NC remaining keys: PLC I 164 to 170 remaining LEDs: PLC O 100 to O 106 1 = keys: PLC I 160 to I 171 LEDs: PLC O 96 to O 107	0
HR 410 inn HR 410 mode (MP 7640 = 6)			-	٠		HR 410 0 = keys X, Y, Z, IV and their LEDs evaluated by NC remaining keys: PLC I 164 to 171 remaining LEDs: PLC O 100 to O 107 1 = keys: PLC I 160 to I 171 LEDs: PLC O 96 to O 107 0 = keys X, Y, Z, IV, actl. value transfer and their LEDs evaluated by NC remaining keys: PLC I 168 to 175 remaining LEDs: PLC O 100 to O 111 1 = keys: PLC I 160 to I 175 LEDs: PLC O 96 to O 111	0

1.0 TNC 415B/425 Machine Parameters MP 7645.0 08.05.95 5.2 71

Function	MP No. Bit	A	В	С	Input	AE-6 Entry value
Assignment of 3. handwheel via machine parameter (MP 7640 = 5)	7645.1	•	•		0 = simulation of 1. position of axis selector switch MP 7645.0 = 0 → Z axis MP 7645.0 = 1 → X axis + 1 = X axis + 2 = Y axis + 4 = Z axis + 8 = IV. axis + 16 = V. axis	0
Axis selection procedure (MP 7640 = 5)	7645.2	•	٠		0 = selection via axis selector switch according to MP 7645.0 1 = axis selection according to MP 7645.1	
reserved	7645.3 to 7645.7	•	•		no function	0
Count direction for handwheel	7650	•	•		0 = positive count direction 1 = negative count direction	0
Hysteresis for electronic handwheel	7660	•	•		0 to 65 535 [increments]	10
Minimum interpolation factor for handwheel	7670	•	104		0 to 10	0
Handwheel interpolation factor slow (HR 130/3xx/410) medium (HR 410) fast (HR 410)	7670.0 7670.1 7670.2	- - -	04 04 04		0 to 10	0 0 0
HR 410: handwheel % factor slow (HR 410) medium (HR 410) fast (HR 410)	7671.0 7671.1 7671.2	- - -	04 04 04		0 to 100 [%]	50 75 100

R H 1.0 TNC 415B/425 Machine Parameters MP 7645.1 - MP 7671.2 08.05.95 5.2 72

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Parameter with multiple	7680						%00011111
function							
 Memory function for axis 		0	•	•		0 = not stored	
direction keys						+1 = stored	
Re-approaching the contour		1	•	•		0 = inactive	
						+2 = active	
Block scan		2	•	•		0 = inactive	
						+4 = active	
 Interruption of block scan by 		3	•	•		0 = interruption	
"STOP" or by M06						+8 = no interruption	
 Include dwell time during block 		4	•	•		0 = dwell time is waited to end	
scan to change the direction of						+16 = dwell time is not waited to end	
rotation in a "tapping" cycle							
 Start calculation with block scan 		5	•	•		0 = start from cursor position	
						+32 = start from beginning of program	
 Tool length for blocks with surface 		6	-	•		0 = without DR2 from the tool table	
normal vector						+64 = with DR2 from the tool table	
Bit reserved		7	-	-			

1.0 TNC 415B/425 Machine Parameters MP 7680 08.05.95 5.2 73

Function	MP No.	Bit	A	В	С	Input	AE-6 Entry value
Incremental positioning after TOOL CALL	7682		ı	-	06	0 = tool length difference taken into account 1 = tool length difference ignored	0
Memory test at power-on	7690					0 to 7	%111
RAM		0	•	•	•	+0 = test +1 = no test	
EPROM		1	•	•	•	+0 = test	
Harddisk		2	-	-	•	+2 = no test +0 = test +4 = no test	

1.0 TNC 415B/425 Machine Parameters MP 7682 - MP 7690 06.03.95 5.2 74